



LK IHC Control®

Quick Guide

English

Lauritz Knudsen



by Schneider Electric

Contens

Welcome to LK IHC Control®	3
The contents of the box.....	3
PC system requirements	4
Network connection of the IHC Controller.....	5
Connection between PC and controller.....	6
The Controller connections	9
Introduction to the LED indications of the IHC Controller	10
Software installation and USB-connection	11
Setup Administrator program.....	15
Configuration of WIFI	21
Communication setup in IHC Visual®	22
Contact the IHC Controller from the browser.....	24
Placing the antenna.....	25
IHCRemote®	29
Installation on iOS and Android.....	30
Control your IHC installation from IHCTablet	31
Using symbols in your IHC installation.....	32
Register your IHC installation.....	33
Security.....	34
Trademark	34
For your safety	35

Welcome to LK IHC Control®

This quick guide contains the necessary information to get started with IHC Control®. You can use the wizard,

- If you install the complete IHC Control software and transfer IHC Visual® projects to the controller
- If you want to monitor and manage IHC Control installations.

Contents of the box

1. IHC Visual Controller
2. SD card
3. Ethernet cable
4. IHC Control Quick Guide
5. IHC wiring diagram (Main)
6. IHC wiring diagram (Alarm)
7. IHC wiring diagram (Heat control)
8. Antenna
9. Antenna cable (3 m)
10. Mounting bracket for the antenna

PC system requirements

Hardware


- 1 gigahertz (GHz) or faster 32-bit (x86) or 64-bit (x64) processor
- 1 gigabyte (GB) RAM (32-bit) or 2 GB RAM (64-bit)

Software

- Windows® Microsoft® 7 and higher
- Microsoft® Internet Explorer® 8 or later.

System requirements applies for all of the IHC Control programs.

Network connection of the IHC Controller



You can connect the IHC Controller to a local network using a router. If the network is connected to the Internet you can access the Controller through the Internet. The setup is explained in the helpfile.

With internet access you can view and control the installations with ServiceView and App's from your smartphone and iPads.

Update the firmware or upload an IHC Visual project to the controller through the USB connection or internet. We always suggest uploading projects and updating firmware through wired connections rather than wireless, see helpfile.

Connection between PC and Controller

You have two ways to connect your PC to the IHC Controller:

- USB connection
- Connection via a Local Area Network (LAN, 10/100/1000 Mbps)(*).

(*) For setting full access to a local network or internet access to IHC Visual, see page 17, bullet 6.

USB connection

Important: Install the software before you connect the PC and controller with the USB cable.



USB-cable




You need:

- A USB cable type A-male to type B-male (max. length 5 m.)
- A PC with a spare USB port.

Connection via the Internet?

A controller can connect to a network the same way as a computer. The controller will then work as a server that you can access via the Internet:



IP and Gateway address


The controller must have a fixed IP address (e.g. default IP address "192.168.1.3").

To be able to connect to the controller from the Internet, the router must have a fixed external IP address (e.g., "80.162.79.117") or be compatible with dynamic DNS address servers (e.g., <http://www.dyndns.com>).

The gateway address (e.g. GW = "192.168.1.1") is the internal IP address of the router.

See "Setup Administrator program" section for more information about how to assign an IP address to the Controller.

The IHC Controller connections



Introduction to the LED indications



OK

Always ON: The controller is booting up

1 Hz Flash: Operating OK, no data transmission
(normal operation)

2 Hz Flash: Operating OK, data transmission

5 Hz Flash: Firmware upgrade state

Flash 1 s. ON, 0.25 s. OFF: Error



ON: Low battery on some wireless products

OFF: Battery OK on all wireless products




Flashing: Communicating with wireless products

OFF: Not communicating with wireless products

Mounting the controller and antenna

1. Mount the controller on the DIN rail.
2. If you have any IHC-Wireless products:
(see p. 25-28 for detailed information about antenna):
 - a. Install the bracket outside the switchboard.
 - b. Mount the antenna cable onto the angle bracket.
 - c. Mount the antenna with the antenna cable.
 - d. Mount the antenna cable to the controller.
3. Connect the IHC power supply (24 V DC)




Software installation and USB connection

Important: Do not connect the USB cable yet.


You need: The controller, software and a USB cable (type A male to type B male, max. length 5.0 m).

1 You start the software installation by unzipping the ZIP file. Click **Install software** and the main menu should be displayed automatically. If not, open '**My computer**' or Windows® Explorer, then double click on the file Setup.exe. Click on Install IHC Control software **1**.



If the windows security window appears, choose "Install this driver software anyway".

2 Java™ Runtime is automatically installed. A dialog box is then displayed from which you can select one of three installation options:



If you select 'Installer', all software will automatically be installed, i.e:

- IHC Visual
- IHC FirmwareLoader
- IHC help files
- USB driver
- Adobe® Reader®.

If you select '**End user**', the following software will be automatically installed:

- IHC help files
- USB driver
- Adobe® Reader®.

In other words, the following programs are NOT installed:

- IHC FirmwareLoader
- IHC Visual.

If you select '**Custom**', you can manually select which programs are to be installed. However, it is not possible to deselect Java™ Runtime as this program is mandatory to run any IHC software.

IHC Help files

When you have installed the software, you can find the help file in the IHC Control section of your PC Start menu.


```
Start > Programs > LK IHC Control > Documentation > LK  
IHC Control helpfile
```

3 Connect your computer to th controller using a USB cable:



Setup Administrator program

1 Connect your computer to the controller using a USB cable (as described in the previous section). Open your Internet browser and enter **USB 1** in the browser. This will give you access to the controller's home page, just as if you were connected to any Internet website. If you are having trouble connecting by typing `usb`, type in the IP address 10.18.93.2.




2 Click on **Administrator 2**. Log into the IHC Administrator software selecting **USB** as the **Host address**. . . When you log in via **USB 3**, you do not need to supply a username or 'password'. If you login via LAN/Internet, use the default username **admin** as **username 4** and also **admin** as **password 5**. You can select **Auto Login 6**, if you want the system to remember your username and password⁽¹⁾. Click on **Login 7**.



(1): From security reasons we do not recommend to use **Auto Login**

3 The main menu of the administrator program includes all communication and access control configuration options. Start by clicking on **Network 1**.




4 **IP-address 2**: Enter the address you have chosen for your controller.

Web port 3 (http-traffic): You only have to change the default setting (port 80) if you have other servers using this number.


Secure port 4 (https-traffic): You normally do not need to change the default setting (port 443).

Subnet mask 5: You normally


do not need to change the default setting. **Gateway address 6**: Enter your router's internal address.




5 From the main menu of the IHC Administrator, scroll down the left window and click on **Access control** 1 .




6 This menu allows you to select the programs which are accessible from a USB connection, from a local network, and from the Internet. Select the programs that you wish to grant access to. For example, if you want to use IHC Visual via LAN/Internet, check fields 2 and 3. Click on **OK** 4, when you are finished.



7 Click on **User accounts** 1 in the IHC Administrator main menu.




8 You must create a user account for yourself. Click on **Add user** 2




9 Enter the username and password in the **Login profile** section 3 (NB! Case sensitive). This information is used when you communicate with the controller via the Internet. Under **Group** 4: Select **Administrators** 5.

This grants access to all programs. Fill out the rest of the personal information fields. Click on **Add user** 6.




10 You should now be able to see your new user profile in the list of users **1**.



11 If you wish to remove a user, select the user from the list and click on **Remove user** **2**. You will be asked to confirm your request. **NB!** You should ensure that the standard login profile (admin) is removed, especially if the controller can be accessed via the Internet. If you have logged in using the default login profile, you should:


- Create a new administration profile (points 8-9) with your own username and password.
- Log off from IHC Administrator.
- Log in using your new administrator profile.
- You can now delete the default login profile.



12 You can also create further users from the user menu, and you can edit the various user profiles by clicking on **Edit user** **3**.




13 If you want to use WIFI you have to use USB dongle **4**. Click on **WiFi** **5**. The wifi dongle is not included - has to be bought separately.




Configuration of WiFi

- 1 Open web browser and write USB in address box. Select administrator.
- 2 Select "WiFi enabled" and click on the Scan button and select network **1**. After selecting the network select the security type and encryption type used by network and then enter a **password**. Under "IP settings" fill in the IP address, Subnet mask and Gateway address.




Communication setup in IHC Visual®

1 If you have installed IHC Visual:
Start the program and click on
Controller 1 in the menu bar. Select
Communication setup 2.



2 Default settings: USB is used when
communicating via USB cable, the IP
address is used when communicating via
a network cable. The default address is
192.168.1.3, and the port number is 443 (can
be changed in IHC Administrator). **Select
USB or Enter IP address 3.**




3 Enter the IP address and port number **1**, you have assigned to the controller in IHC Administrator. Click on **OK** **2** to return to the previous menu.



The screenshot shows a dialog box titled "Enter IHC controller IP address". It contains two input fields: "IP address" with the value "10.131.225.200" and "Port" with the value "443". Below the fields are two buttons: "OK" and "Cancel". A red number "1" is placed above the IP address field, and a red number "2" is placed above the "OK" button.

4 Select the IP setting with the new address and port **3**. Check that the **Communication status** is OK **4**, and click on **OK** to finish **5**.



The screenshot shows a dialog box titled "Communication setup". It has three sections: "Communication interface" with a dropdown menu showing "10.131.225.200.443" and a red number "3" above it; "IHC Controller administrator account" with "Username" (admin) and "Password" (masked with dots) fields and an "Enter" button; and "Communication status" showing a green checkmark icon and the text "IHC Controller connected" with a red number "4" next to it. At the bottom are "OK", "Cancel", and "Apply" buttons. A red number "5" is placed above the "OK" button.

Access the IHC Controller from the browser


Via USB cable: Enter USB (alternatively type in: 10.18.93.2)

Via your Intranet: Enter the controller's IP address, e.g. 192.168.1.3


Via the Internet: To make the controller accesible, make sure that your router setup is correct. Port 80 and port 443 should be by default forwarded to the controller IP address. To setup your router accordingly, please contact your network administrator.

Once the router has been configured: enter your router's external IP address, e.g. 80.162.79.117.


If you do not use the default port number (80), you must type 'http://' in front of the IP address, and the port number after the IP address, e.g. 'http://192.168.1.1:8080' (where 8080 is the new port number).



Placing the antenna




Vertical mounting



Horizontal mounting

The signal sent from the controller's antenna spread in a symmetrical field as a “donut” around the antenna. You will experience the difference in the antenna's reach, depending on whether you mount it vertically or horizontally.

Signal paths



Reflections, diffusion and refraction means that the signal from the sender to

the recipient will flow in different directions. The resulting signal at the receiver will therefore be the sum of a number of signals which can both strengthen or reduce the original signal, depending on the place to observe the signal. In particular unfavorable situations we may find that the original signal is reduced so much that an area is perceived as “dead”, but a few centimeters next to it the signal is well received.

Reflections

Occurs when a radio wave reaches a different material, for example. walls, furniture and persons (~ mirror) (*).

Spreading

Occurs with sharp corners and small particles. The signal splits into new signals with their dissemination point (~ diffuse light).

Reduction

Materials have different ability to reduce signals (~ sunglasses).

Refractive


When a signal passes from one material to another material using a non-perpendicularly way, the signal will refract, i.e., the signal will change direction (~ light in the lenses).

(*) The parentheses indicate a known phenomenon from the telescope's world.

Hints


1. Place the antenna closest to the areas where you want good wireless connection.
2. Mounting up high is better than low. At the high position the antenna should be turned down to avoid the bracket shadows of the field.
3. Place the antenna so it is not covered. Not inside the cabinets, boards and similar.
4. Place the antenna far away from large metal objects, for example. radiators, refrigerators, iron-reinforced concrete etc.
5. Always use the supplied antenna bracket for attaching the antenna. This gives the antenna a distance from the wall, so that there are no reflections below. Never put the antenna at the bottom of a blackboard or in a cable tray.
6. Note that the antenna can be mounted both horizontally and vertically.
7. Place the antenna far away from other wireless systems as it reduces the risk of interference during dimming.
8. Imagine the antenna as an incandescent light bulb and the floors, walls and items in the house are transparent materials with different transparency. Wooden walls are nearly transparent, while iron-reinforced walls are almost opaque (use table on next page). Imagine whether you can see the light at the places where you will receive the wireless signals.

Example of the ideal location




Central location, giving the least distance to the most distant components.

There is no benefit with multiple antennas




When using the antenna splitter you can use multiple antennas to increase coverage. However, please note that the signal is reduced by half in the filter and reduced signal in cables, which can sometimes mean that there is no benefit with multiple antennas. This is shown by reducing the individual fields reach.

With attenuation



A powerful damping wall or radiator makes a central location not optimal.



This is better placing the antenna on the wall or radiator.

Material	Attenuation	Examples
Air	Very low	Open space, courtyard
Wood	Low	Doors, flooring, partitions
Plastic	Low	Partition walls
Glass	Low	Non-tinted windows
Tinted glass	Medium	Tinted windows
Water	Medium	Aquariums, fountains
Living creatures	Medium	Animals, humans, plants
Brick	Medium	Walls
Plaster	Medium	Partition wall
Ceramics	High	Tiles, bricks
Concrete	High	High-bearing walls, floors, pillars
Soil	Very high	Cellars, embankments, window boxes
Metal	Very high	Reinforced concrete, metal cabinet


IHCRemote® a smart remote control

With the app IHCRemote you can control and monitor your IHC Installation with an Apple or Android based smartphone.

Make the following changes in the controller settings.



Regardless of what smartphone you use.

- 1 Open Administrator with an internet browser. Check that the IP address is configured in "Network", see page 17 Section 2.





- 2 Back in the Administrator program's main menu, click **Access control** 1.

In the menu **Access control** select fields 2 and 3 to ensure that Scene View is available from both local networks and over the Internet.




Installation on iOS and Android™

- 1 On the iPhone, iPad or iPod Touch tap  to open "App Store" (Google Play™  on Android).




- ## 2 Search IHCRemote.

- 3 Press IHCRemote icon  to download application.

- 4** Set up the application easily by entering the controller's IP address, and username and password to the controller. The IHCRremote app now downloads all relevant information from the controller and stores it in the application.



- 5** You can create your own favorite list with the most used functions in the desired order. In addition, the application can be adapted to 140 different IHC symbols from the accompanying symbols.



Control your IHC installation from IHCTablet®




- Simple user interface
- Make your own control panel with minimal setup
- Personalize the interface with your own photos or floor plans
- Icons with feedback on the user interface - displaying the status of the IHC installation
- Active fields for texts and viewing websites such as Web Camera
- Control multiple IHC controllers
- Purchased through the App Store

Using symbols in your IHC installation

You can achieving a beautiful and functional user interface in your IHC installation, using symbols on your rockers. Symbols make it visually and easily identified individual touch function. The rockers you order in Tangent Designer on the Internet.

Tangent Designer

Du har pt købt for 0,00 DKK Gå til indkøbskurv



Tangent Designer

On our website you can design your own rockers with text and symbols.
The address bestil.lk.dk.



Register your IHC installation

If you register your IHC installation, we send you a ring binder that you can pass on to your customer. The ring binder contains material which is targeted to end users: documentation and USB memory stick for storing IHC project etc. To register your IHC installation visit <http://www.lk.dk/ihcreg>.

The screenshot shows the Schneider Electric website with the following elements:

- Header: Schneider Electric logo, navigation links (Produktkatalog, Produktskrivelser, Løsninger, Support, Om os), and a search icon.
- Breadcrumb: Home > Support > Support til professionelle > IHC-registrering
- Main Content Area:
 - Left sidebar: "Support til professionelle" with a sub-menu (Support til private, Find forhandler, Kontakt, Nyheder, Uddannelse, Lyddæmper LED guide).
 - Grid of links:
 - Manueller og hjælpefiler
 - Uddannelsescenter
 - Vigtig info om installationer
 - Fjernsupport i din skærm
 - Projekteringsmateriale
 - Bestil og download brochurer
 - Software - IHC®
 - Software - andet
 - FAQ
 - Kontakt sælgeren
 - IHC®-registrering**
 - Glossar

Below the grid, there is a section titled "Bestil en IHC®-slutbrugermappe" with the following text:

For at din kunde kan få mest muligt ud af en IHC®-installation, vil vi gerne sende dig en flot slutbrugermappe, som du kan videregive til kunden.

Mappen indeholder brugermanual samt en USB til back-up af installationen. Der er også plads til, at du kan indtaste noter og anden relevant dokumentation i mappen.



IHC training



Educationcenter

Find the right training on:
www.schneider-electric.com/kurser/dk
or scan the QR code



Security

Schneider Electric Denmark A / S can not be liable for the consequences of hacking or virus attacks on the controller. Data traffic between client and server use SSL encryption technology.

The technically qualified person who prepares the user interface (using Viewer programs), must ensure to minimize the risk of accidents (unintentional on / off of output). This is achieved by considering possible errors in the proposed interface and making appropriate settings in the Administrator program (access control and user accounts).

Trademark

Microsoft, Windows, Windows Vista and Internet Explorer are trademarks or registered trademarks of Microsoft Corporation.

Mac, Mac OS, AirPort, Safari, Bonjour, iPad, iPhone and iPod touch are trademarks or registered trademarks of Apple Inc.

Google Cloud Print, Google Chrome, Android, Google Play and Picasa are either registered trademarks or trademarks of Google Inc.

Java is registered trademark of Oracle.

For your safety



DANGER

Risk of serious damage to property and personal injury, e.g. from fire or electric shock, due to incorrect electrical installation.

Safe electrical installation can only be ensured if the person in question can prove basic knowledge in the following areas:

- *Connecting to electrical installations*
- *Connecting several electrical devices*
- *Laying electric cables*

These skills and experience are normally only possessed by skilled professionals who are trained in the field of electrical installation technology.

If these minimum requirements are not met or are disregarded in any way, you will be solely liable for any damage to property or personal injury.



DANGER

Risk of death from electric shock.


The outputs may carry an electrical current even when the device is switched off. Always disconnect the fuse in the incoming circuit from the supply before working on connected loads.



CAUTION

The device may be damaged!

- *Always operate the device according to the technical data provided.*
-



For more technical information, please contact the Technical support on +45 88 30 20 00. For technical information go to our website www.lk.dk.

Schneider Electric Danmark A/S
 Lautrupvang 1
 2750 Ballerup
 Tlf.: +45 88 30 20 00
www.schneider-electric.dk
www.lk.dk

As standards and products are under continuous changes, the information in this catalog is changed and is therefore not binding until correctness is confirmed by us.

Schneider Electric is the global specialist in energy optimization and management and is committed to helping people and organizations to make the most of their energy.