




M262 / LXM32S (SercosIII) Programming Example

MC_MoveAbsolute





Table of Contents

Introduction	3
Overview	3
Before You Begin	3
Start-Up and Test.....	5
Operations and Adjustments.....	6
Functional overview	7
Components	7
SERCOS Configuration	8
Sercos Master	8
Sercos Slaves	8
Axis configuration	9
Drive_X.....	9
Drive_Y.....	9
POU's 10	
Main program (MOTION_PRG)	10
AxisConfiguration (PRG).....	11
MotionBlocks (PRG).....	12
PowerON_Homing (PRG).....	14
Auto_MoveAbsolute (PRG).....	15
Visualizations	17
Main_VISU	17
DRIVE_X.....	17
DRIVE_Y	18



Introduction

Overview

This chapter gives the introduction.

Contents of this chapter

This chapter contains the following topics:

Topic	Page
Before you begin	03
Start-Up and Test	05
Operations and Adjustments	06

Before You Begin

General

The products specified in this document have been tested under actual service conditions. Of course, your specific application requirements may be different from those assumed for this and any related examples described herein. In that case, you will have to adapt the information provided in this and other related documents to your particular needs. To do so, you will need to consult the specific product documentation of the hardware and/or software components that you may add or substitute for any examples specified in this documentation. Pay particular attention and conform to any safety information, different electrical requirements and normative standards that would apply to your adaptation.

© 2014 Schneider Electric. All rights reserved

WARNING

REGULATORY INCOMPATIBILITY

Be sure that all equipment applied and systems designed comply with all applicable local, regional and national regulations and standards

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Please Note

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material. A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved. Failure to observe this information can result in injury or equipment damage.



The use and application of the information contained herein require expertise in the design and programming of automated control systems. Only the user or integrator can be aware of all the conditions and factors present during installation and setup, operation, and maintenance of the machine or process, and can therefore determine the automation and associated equipment and the related safeties and interlocks which can be effectively and properly used. When selecting automation and control equipment, and any other related equipment or software, for a particular application, the user or integrator must also consider any applicable local, regional or national standards and/or regulations.

Some of the major software functions and/or hardware components used in the proposed architectures and examples described in this document cannot be substituted without significantly compromising the performance of your application. Further, any such substitutions or alterations may completely invalidate any proposed architectures, descriptions, examples, instructions, wiring diagrams and/or compatibilities between the various hardware components and software functions specified herein and in related documentation. You must be aware of the consequences of any modifications, additions or substitutions.

A residual risk, as defined by EN/ISO 12100-1, Article 5, will remain if

- it is necessary to modify the recommended logic and if the added or modified components are not properly integrated in the control circuit.
- you do not follow the required standards applicable to the operation of the machine, or if the adjustments to and the maintenance of the machine are not properly made (it is essential to strictly follow the prescribed machine maintenance schedule).
- the devices connected to any safety outputs do not have mechanically-linked contacts.

CAUTION

EQUIPMENT INCOMPATIBILITY

Read and thoroughly understand all device and software documentation before attempting any component substitutions or other changes related to the application examples provided in the document

Failure to follow these instructions can result in injury, or equipment damage.



Start-Up and Test

Before using electrical control and automation equipment after design and installation, the application and associated functional safety system must be subjected to a start-up test by qualified personnel to verify correct operation of the equipment. It is important that arrangements for such testing be made and that enough time is allowed to perform complete and satisfactory testing.

CAUTION

EQUIPMENT OPERATION HAZARD

- Verify that all installation and setup procedures have been completed.
- Before operational tests are performed, remove all blocks or other temporary holding means used for shipment from all component devices
- Remove tools, meters, and debris from equipment.

Failure to follow these instructions can result in injury, or equipment damage.

Verify that the completed system, including the functional safety system, is free from all short circuits and grounds, except those grounds installed according to local regulations. If high-potential voltage testing is necessary, follow the recommendations in equipment documentation to help prevent injury or equipment damage.



Operations and Adjustments

General

Regardless of the care exercised in the design and manufacture of equipment or in the selection and ratings of components, there are hazards that can be encountered if such equipment is improperly installed and operated.

In some applications, such as packaging machinery, additional operator protection such as point-of-operation guarding must be provided. This is necessary if the hands and other parts of the body are free to enter the pinch points or other hazardous areas where serious injury can occur. Software products alone cannot protect an operator from injury. For this reason, the software cannot be substituted for or take the place of point-of-operation protection.

WARNING

UNGUARDED MACHINERY CAN CAUSE SERIOUS INJURY

- Do not use this software and related automation equipment on equipment which does not have point-of-operation protection.
- Do not reach into machinery during operation.

Failure to follow these instructions can result in death, serious injury, or equipment damage.


Ensure that appropriate safeties and mechanical/electrical interlocks related to point-of-operation protection have been installed and are operational before placing the equipment into service. All interlocks and safeties related to point-of-operation protection must be coordinated with the related automation equipment and software programming.

NOTE: Coordination of safeties and mechanical/electrical interlocks for point-of-operation protection is outside the scope of the examples and implementations suggested herein. It is sometimes possible to adjust the equipment incorrectly and this produce unsatisfactory or unsafe operation. Always use the manufacturer instructions as a guide to functional adjustments. Personnel who have access to these adjustments must be familiar with the equipment manufacturer instructions and the machinery used with the electrical equipment. Only those operational adjustments actually required by the machine operator should be accessible to the operator. Access to other controls should be restricted to help prevent unauthorized changes in operating characteristics.



Functional overview

Components



The Motion Controller TM262Mxxxx controls 2 Lexium32S devices over SERCOS III.

Minimum required LXM32S firmware versions:

- LXM32S drive firmware PR912.20 Version $\geq$ 1.06.03
- LXM32S SERCOS module firmware PR940.00 Version $\geq$ 1.08.04

The example program contents a basic

- Axis configuration 2 Linear Axis without software limits
- Switching ON the power stage (MC_Power)
- Homing the axis (MC_Home)
- Move absolute 2 axis (MC_MoveAbsolute)

A detailed error handling is not part of this example.



SERCOS Configuration

Sercos Master

Parameter	Type	Value	Default Value	Unit	Description
SercosPhaseChanger					
ActualState	Enumeration of DINT	NRT / -1	NRT / -1		Actual SERCOS state
DesiredPhase	Enumeration of DINT	Phase 4 / 4	Phase 4 / 4		Desired SERCOS phase
SercosCycleTimeConfig					
CycleTime	UDINT(1000000..4000000)	1000000	1000000		Sercos CycleTime (nsec)

This example uses the DEFAULT value of 1 ms for the Sercos cycle time

Sercos Slaves

X-Axis – Topology address 1

Parameter	Type	Value	Default Value	Unit	Description
Identification					
ConfiguredTopologyAddress	UINT(1..256)	1	1		Configured topological address
TopologyAddress	UINT				Physical position in the SERCOS loop
ConfiguredSercosAddress	UINT(0..511)	1	1		Configured Sercos address
SercosAddress	UINT				Sercos address (IDN S-0-1040.0.0, as read during phase-up)
IdentificationMode	Enumeration of UINT	Topology mode / 0	Topology mode / 0		Identification of slaves by topology or sercos address

Y-Axis – Topology address 2

Parameter	Type	Value	Default Value	Unit	Description
Identification					
ConfiguredTopologyAddress	UINT(1..256)	2	1		Configured topological address
TopologyAddress	UINT				Physical position in the SERCOS loop
ConfiguredSercosAddress	UINT(0..511)	2	1		Configured Sercos address
SercosAddress	UINT				Sercos address (IDN S-0-1040.0.0, as read during phase-up)
IdentificationMode	Enumeration of UINT	Topology mode / 0	Topology mode / 0		Identification of slaves by topology or sercos address



Axis configuration

Drive_X

Real axis with 360 user units / revolution
No mechanical gear (ratio 1:1)

Drive_X					
Parameters I/O Mapping User Cyclic Data Feature Configuration Information					
Parameter	Type	Value	Default Value	Unit	Description
Identification					General Sercos Identification
SercosDiagnostics					Diagnostic data for sercos devices
Axis					Axis_Ref representing the motor
Scaling					Scale increments into user position
IncrementResolution	DINT	131072	131072		Increment Resolution
PositionResolution	LREAL	360.0	360.0		Position Resolution
GearIn	UDINT	1	1		Gear In
GearOut	UDINT	1	1		Gear Out
ElectronicLabel					Electronic Label of the device
CoplaCommunicationModule					Electronic Label of the COPLA communication module
WorkingMode					Device working mode
DesiredState	Enumeration of UINT	Activated working mode / 1	Activated working mode / 1		Working mode: Simulated/Activated


Drive_Y

Real axis with 360 user units / revolution
No mechanical gear (ratio 1:1)

Drive_Y					
Parameters I/O Mapping User Cyclic Data Feature Configuration Information					
Parameter	Type	Value	Default Value	Unit	Description
Identification					General Sercos Identification
SercosDiagnostics					Diagnostic data for sercos devices
Axis					Axis_Ref representing the motor
Scaling					Scale increments into user position
IncrementResolution	DINT	131072	131072		Increment Resolution
PositionResolution	LREAL	360.0	360.0		Position Resolution
GearIn	UDINT	1	1		Gear In
GearOut	UDINT	1	1		Gear Out
ElectronicLabel					Electronic Label of the device
CoplaCommunicationModule					Electronic Label of the COPLA communication module
WorkingMode					Device working mode
DesiredState	Enumeration of UINT	Activated working mode / 1	Activated working mode / 1		Working mode: Simulated/Activated



POU's



Main program (MOTION_PRG)

```
1  PROGRAM Motion_PRG
2  VAR
3  END_VAR
4
5  // *****
6  // Initialization / Axis configuration
7  // *****
8  AxisConfiguration();
9  IF NOT GVL.gxInit_OK THEN // Configuration finished and SERCOS in PHASE 4 ?
10     RETURN;
11 END_IF
12 // *****
13 // Cyclic call of Motion function block
14 MotionBlocks();
15 // *****
16 // Sequence to power ON and home the drives
17 PowerON_Homing();
18 // *****
19 // Call of automatic example sequence
20 Auto_MoveAbsolute();
21 // *****
22
```



AxisConfiguration (PRG)


- Setup axis type to Linear without SW limits
- Phase up SERCOS to CP4

```
AxisConfiguration x
1 PROGRAM AxisConfiguration
2 VAR
3     iState      :INT;
4 END_VAR
5
6 // *****
7 // Axis configuration and SERCOS III phase up !!!
8 // *****
9 CASE iState OF
10 0: // Set Sercos Phase to NRT (-1)
11     GVL.gxInit_OK :=FALSE;
12     GVL.gSercosPhaseSet :=S3M.ET_SercosPhase.NRT;
13     IF SercosMaster.SercosPhaseChanger.ActualState = S3M.ET_SercosState.NRT THEN
14         iState :=iState + 1;
15     END_IF
16 1: // *****
17     // Axis Configuration
18     // *****
19     // Axis type
20     // Linear Axis without limits
21     Drive_X.Axis.SetAxisTypeLinearWithoutLimits();
22     Drive_Y.Axis.SetAxisTypeLinearWithoutLimits();
23     iState :=iState + 1;
24 2: // *****
25     // Set Sercos Phase 4
26     // *****
27     GVL.gSercosPhaseSet := S3M.ET_SercosPhase.Phase4;
28     IF SercosMaster.SercosPhaseChanger.ActualState = S3M.ET_SercosState.Phase4 THEN
29         GVL.gxInit_OK :=TRUE;
30         iState :=iState + 1;
31     END_IF
32 3: // *****
33     // Check for New - Configuration Command
34     // *****
35     IF NOT GVL.gxInit_OK THEN
36         iState :=0; // New phase up
37     END_IF
38 END_CASE
39 // *****
40 // Check Sercos Phase 4
41 SercosMaster.SercosPhaseChanger.DesiredPhase := GVL.gSercosPhaseSet;
42 IF SercosMaster.SercosPhaseChanger.ActualState = S3M.ET_SercosState.Phase4 THEN
43     GVL.gx_SercosInPhase4 :=TRUE;
44 ELSE
45     GVL.gx_SercosInPhase4 :=FALSE;
46 END_IF
47 // *****
```








MotionBlocks (PRG)

- Cyclic call of PLCOpen function blocks and other motion function blocks





Build IDN for homing method: IDN P-0-3027.0.12





PowerON_Homing (PRG)

```
PowerON_Homing X
1 PROGRAM PowerON_Homing
2 VAR
3     iState      :INT;
4     iErrorState :INT;
5 END_VAR
6
7 // *****
8 // Reset state machine if "Homing command = FALSE"
9 // *****
10 IF NOT GVL.gx_PowerON_Homing AND iState > 0 THEN
11     GVL.MC_Home_X.Execute :=FALSE;
12     GVL.MC_Home_Y.Execute :=FALSE;
13     GVL.MC_Power_X.Enable :=FALSE;
14     GVL.MC_Power_Y.Enable :=FALSE;
15     GVL.FB_SetHomingMethode_X.i_xExecute :=FALSE;
16     GVL.FB_SetHomingMethode_Y.i_xExecute :=FALSE;
17     GVL.gx_Homing_OK :=FALSE;
18     iState :=0;
19 END_IF
20 CASE iState OF
21 0: // *****
22     // Wait for start command -> Power ON
23     // *****
24     IF GVL.gx_PowerON_Homing THEN // Start Command from VISU Button
25         GVL.gx_PowerON_HomingBusy :=TRUE; // Set Sequence is BUSY (active)
26         GVL.MC_Power_X.Enable :=TRUE; // Enable power stage Drive X
27         GVL.MC_Power_Y.Enable :=TRUE; // Enable power stage Drive Y
28         IF GVL.MC_Power_X.Status AND GVL.MC_Power_Y.Status THEN // power stage enabled
29             iState :=iState + 1;
30         ELSIF GVL.MC_Power_X.Error OR GVL.MC_Power_Y.Error THEN // Error
31             iErrorState :=iState;
32             iState :=100;
33         END_IF
34     END_IF
35 1: // *****
36     // Set Homing Type P-0-3027.0.12 - Drive X
37     // 17 = Limit Switch negative
38     // 33 = Index pulse
39     // ...
40     // *****
41     GVL.ginHomingMethode_X :=33;//17;
42     GVL.FB_SetHomingMethode_X.i_xExecute :=TRUE;
43     IF GVL.FB_SetHomingMethode_X.q_xDone THEN
44         GVL.FB_SetHomingMethode_X.i_xExecute :=FALSE;
45         iState :=iState + 1;
46     ELSIF GVL.FB_SetHomingMethode_X.q_xError THEN
47         iState :=100;
48     END_IF
49 2: // *****
50     // Set Homing Type P-0-3027.0.12 - Drive Y
51     // 17 = Limit Switch negative
52     // 33 = Index pulse
53     // ...
54     // *****
55     GVL.ginHomingMethode_Y :=33;//17;
56     GVL.FB_SetHomingMethode_Y.i_xExecute :=TRUE;
57     IF GVL.FB_SetHomingMethode_Y.q_xDone THEN
58         GVL.FB_SetHomingMethode_Y.i_xExecute :=FALSE;
59         iState :=iState + 1;
60     ELSIF GVL.FB_SetHomingMethode_Y.q_xError THEN
61         iState :=100;
62     END_IF
63 END_CASE
```



```
57 3: // *****
58 // Homing Drive X and Y
59 // *****
60 GVL_MC_Home_X.Execute :=TRUE;
61 GVL_MC_Home_X.Position := 0;
62 GVL_MC_Home_Y.Execute :=TRUE;
63 GVL_MC_Home_Y.Position := 0;
64 IF GVL_MC_Home_X.Done AND GVL_MC_Home_Y.Done THEN // Homing completed X + Y
65     GVL_MC_Home_X.Execute :=FALSE;
66     GVL_MC_Home_Y.Execute :=FALSE;
67     iState :=iState + 1;
68 ELSIF GVL_MC_Home_X.Error OR GVL_MC_Home_X.CommandAborted OR GVL_MC_Home_Y.Error OR GVL_MC_Home_Y.CommandAborted THEN
69     iState :=100;
70 END_IF
71 4: // *****
72 // Homing completed
73 // *****
74 GVL_gx_PowerON_HomingBusy :=FALSE;
75 GVL_gx_Homing_OK :=TRUE; // Homing OK -> ready for automatic sequence
76 IF NOT GVL_gx_PowerON_Homing THEN // New command to start this sequence
77     GVL_MC_Power_X.Enable :=FALSE;
78     GVL_MC_Power_Y.Enable :=FALSE;
79     GVL_gx_Homing_OK :=FALSE;
80     iState :=0;
81 END_IF
82 100:// *****
83 // Abort/Error State
84 // *****
85 ;
86 END_CASE
```

Auto_MoveAbsolute (PRG)

Automatic example sequence where the axis moved by the FB MC_MoveAbsolute

```
Auto_MoveAbsolute X
1 PROGRAM Auto_MoveAbsolute
2 VAR
3     iState      :INT;
4 END_VAR
5
6 // *****
7 // Reset state machine if "AutomaticStart = FALSE"
8 // *****
9 IF NOT GVL_gx_Automatic_Start AND iState >0 THEN
10     GVL_MC_MoveAbsolute_X.Execute :=FALSE;
11     GVL_MC_MoveAbsolute_Y.Execute :=FALSE;
12     iState :=0;
13 END_IF
```




```
9 CASE iState OF
10 0: // *****
11 // Wait for START command
12 // *****
13 IF GVL.gx_Automatic_Start AND GVL.gx_Homing_OK THEN
14     GVL.gx_Automatic_Busy :=TRUE;
15     // Drive X
16     GVL.MC_MoveAbsolute_X.Position :=800;
17     GVL.MC_MoveAbsolute_X.Velocity :=1500;
18     GVL.MC_MoveAbsolute_X.Acceleration :=1500;
19     GVL.MC_MoveAbsolute_X.Deceleration :=1500;
20     GVL.MC_MoveAbsolute_X.Execute :=TRUE;
21     // Drive Y
22     GVL.MC_MoveAbsolute_Y.Position :=350;
23     GVL.MC_MoveAbsolute_Y.Velocity :=1500;
24     GVL.MC_MoveAbsolute_Y.Acceleration :=1500;
25     GVL.MC_MoveAbsolute_Y.Deceleration :=1500;
26     GVL.MC_MoveAbsolute_Y.Execute :=TRUE;
27     iState :=iState + 1;
28 ELSE
29     GVL.gx_Automatic_Busy :=FALSE;
30 END_IF
31 1: // *****
32 // Wait for target position reached
33 // *****
34 IF GVL.MC_MoveAbsolute_X.Done AND GVL.MC_MoveAbsolute_Y.Done THEN
35     GVL.MC_MoveAbsolute_X.Execute :=FALSE;
36     GVL.MC_MoveAbsolute_Y.Execute :=FALSE;
37     iState :=iState + 1;
38 ELSIF GVL.MC_MoveAbsolute_X.Error OR GVL.MC_MoveAbsolute_X.CommandAborted
39 OR GVL.MC_MoveAbsolute_Y.Error OR GVL.MC_MoveAbsolute_Y.CommandAborted THEN
40     iState :=100;
41 END_IF
42 2: // *****
43 // Move Drive Y to position 0
44 // *****
45 GVL.MC_MoveAbsolute_Y.Position :=0;
46 GVL.MC_MoveAbsolute_Y.Execute :=TRUE;
47 IF GVL.MC_MoveAbsolute_Y.Done THEN // target pos reached
48     GVL.MC_MoveAbsolute_Y.Execute :=FALSE;
49     iState :=iState + 1;
50 ELSIF GVL.MC_MoveAbsolute_Y.Error OR GVL.MC_MoveAbsolute_Y.CommandAborted THEN
51     iState :=100;
52 END_IF
53 3: // *****
54 // Move Drive X to position 0
55 // *****
56 GVL.MC_MoveAbsolute_X.Position :=0;
57 GVL.MC_MoveAbsolute_X.Execute :=TRUE;
58 IF GVL.MC_MoveAbsolute_X.Done THEN // target pos reached
59     GVL.MC_MoveAbsolute_X.Execute :=FALSE;
60     iState :=0; // state 0 -> repeat this sequence
61 ELSIF GVL.MC_MoveAbsolute_X.Error OR GVL.MC_MoveAbsolute_X.CommandAborted THEN
62     iState :=100;
63 END_IF
64
65 100:// *****
66 // Abort / Error State
67 // *****
68 GVL.gx_Automatic_Busy :=FALSE;
69 END_CASE
```




Visualizations

Main_VISU



DRIVE_X





DRIVE_Y

Drive 2 (Y)

Axis

Instance: %s

etAxisState: %s

stAxisError.etID: %s

stAxisError.etSource: %s

IrAcceleration: %3f

IrErrorStopDec: %3f

IrErrorStopJerk: %3f

IrModulePeriod: %3f

IrNegativeDirectionLimit: %3f

IrPositiveDirectionLimit: %3f

IrPosition: %3f

IrVelocity: %3f

xIsHomed

xIsLimited

xIsModule

MC_Power

%s

Enable

Status

Error

ErrorId: %s

MC_Home

%s

Execute

Done

Position: %2f

Busy

CAborted

Error

ErrorId: %s

MC_SetPosition

%s

Execute

Done

Position: %2f

Busy

Relative

Error

ErrorId: %s

MC_MoveAbsolute

%s

Execute

Done

Position: %2f

Velocity: %2f

Acc: %2f

Dec: %2f

Jerk: %2f

Direction: %s

Buffer: %s

ErrorId: %s

MC_Reset

%s

Execute

Done

Busy

Error

ErrorId: %s