

# MFB for Modicon M340 using Unity Pro Start-up Guide

05/2010

---

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2010 Schneider Electric. All rights reserved.

---

## Document Set

### Related Documents

The following related documentation may be consulted:

- Unity Pro Online Help
- MFB library on Unity Pro Online Help
- CD Documentation **Lexium 15** delivered with the product
- CD Documentation **Lexium 05** delivered with the product
- Unilink L for **Lexium 15LP** and Unilink MH for **Lexium 15MP/HP** Online Help
- PowerSuite for **ATV** Online Help
- PowerSuite for **Lexium 05** Online Help
- Lexium CT for **Lexium 32** Online Help



---

# Table of Contents



---

	<b>Safety Information</b> .....	<b>9</b>
	<b>About the Book</b> .....	<b>11</b>
<b>Part I</b>	<b>Start-up Guide for a Single Axis Application</b> .....	<b>13</b>
<b>Chapter 1</b>	<b>Foreword</b> .....	<b>15</b>
	General .....	16
	Availability of Blocks on the Various Servodrives .....	17
	Methodology .....	19
<b>Chapter 2</b>	<b>Application Configuration</b> .....	<b>21</b>
2.1	Hardware and Software Environments .....	22
	Application Architecture with a Lexium 05 .....	23
	Software Requirements .....	24
	Hardware Requirements .....	25
2.2	Configuration of the Application using Unity Pro .....	26
	Creating the Project .....	27
	Master Task Configuration .....	28
2.3	CANopen Bus Configuration .....	29
	Implementation Methodology for a CANopen Bus .....	30
	Configuration of the CANopen port .....	31
	Configuration of the CANopen Slave .....	32
	Checking the CANopen Bus Configuration .....	34
2.4	Axis Configuration using the Motion Tree Manager .....	35
	Motion Directory .....	36
	Axis Creation and Configuration .....	38
	The Variables Axis_Ref, Can_Handler, AxisParamDesc and Recipe .....	41
	Motion Directory Configuration Result .....	43
2.5	Configuring the Lexium 05 .....	44
	Configuring the Lexium 05 in PowerSuite .....	45
	Configuring the Lexium 05 with the User Interface .....	48
<b>Chapter 3</b>	<b>Application Programming</b> .....	<b>51</b>
	Declaration of Variables .....	52
	Programming the Example .....	53
	The CAN_HANDLER Function Block .....	54
	Management of the Axis' Operating and Stop Modes .....	56


	Motion Control . . . . .	57
	Motion Monitoring . . . . .	58
	Status and Axis Error Code Section . . . . .	59
	Backup and Transfer of the Servodrive Parameters . . . . .	60
	Transferring the Project between the Terminal and the PLC. . . . .	61
<b>Chapter 4</b>	<b>Application Debugging . . . . .</b>	<b>63</b>
	Tuning the Lexium 05 with PowerSuite . . . . .	64
	Using Data via the Animation Tables. . . . .	65
	Program Debugging. . . . .	67
	Using Data via the Operator Screens . . . . .	69
<b>Chapter 5</b>	<b>Operating the Application. . . . .</b>	<b>71</b>
	Management of the Recipes . . . . .	71
<b>Chapter 6</b>	<b>Application Maintenance. . . . .</b>	<b>73</b>
	Error Example . . . . .	74
	Replacing a Faulty Servodrive. . . . .	76
<b>Part II</b>	<b>Multi-Axis Application . . . . .</b>	<b>79</b>
<b>Chapter 7</b>	<b>Foreword. . . . .</b>	<b>81</b>
	Application Architecture with All Servodrives. . . . .	81
<b>Chapter 8</b>	<b>Compatibility of motion applications with Unity versions . . . . .</b>	<b>83</b>
		83
<b>Chapter 9</b>	<b>Lexium 32 Implementation for Motion Function Blocks . . . . .</b>	<b>85</b>
9.1	Adapting the Application to the Lexium 32. . . . .	86
	Application Architecture with Lexium 32 . . . . .	87
	Software Requirements . . . . .	88
	Hardware Requirements . . . . .	89
	CANopen Bus Configuration Lexium 32 . . . . .	90
9.2	Configuring the Lexium 32. . . . .	92
	Basic Parameters for Lexium 32 using Lexium CT . . . . .	92
9.3	Tuning the Lexium 32 . . . . .	95
	Tuning the Lexium 32 . . . . .	96
	Debugging the Lexium 32 . . . . .	97
<b>Chapter 10</b>	<b>Lexium 15MP/HP/LP Implementation for Motion Function Blocks . . . . .</b>	<b>99</b>
10.1	Adapting the Application to the Lexium 15MP/HP/LP . . . . .	100
	Application Architecture with Lexium 15MP/HP/LP . . . . .	101
	Software Requirements . . . . .	102
	Hardware Requirements . . . . .	103
10.2	CANopen Bus Configuration Lexium 15MP/HP/LP . . . . .	104
	Configuration of the CANopen Slave on CANopen bus. . . . .	104

10.3	Configuring the Lexium 15MP/HP/LP . . . . .	106
	Basic Parameters for Lexium 15MP using Unilink MH . . . . .	107
	Basic Parameters for Lexium 15LP using Unilink L . . . . .	109
	Specific Parameters for Lexium 15 MP/HP/LP using Unilink . . . . .	112
10.4	Tuning the Lexium 15MP/HP/LP . . . . .	114
	Debugging the axis . . . . .	114
<b>Chapter 11</b>	<b>ATV 31 Implementation for Motion Function Blocks . .</b>	<b>117</b>
11.1	Adapting the Application to the ATV 31 . . . . .	118
	Application Architecture with an ATV 31 . . . . .	119
	Software Requirements . . . . .	120
	Hardware Requirements . . . . .	121
11.2	CANopen Bus Configuration ATV 31 . . . . .	122
	Configuration of the CANopen Slave (ATV 31) on CANopen bus . . . . .	122
11.3	Configuring the ATV 31 . . . . .	124
	Configuring the ATV 31 in PowerSuite . . . . .	125
	Configuring the ATV 31 with the User Interface . . . . .	128
11.4	Tuning the ATV 31 . . . . .	130
	Tuning the ATV 31 with PowerSuite . . . . .	130
<b>Chapter 12</b>	<b>ATV 71 Implementation for Motion Function Blocks . .</b>	<b>131</b>
12.1	Adapting the Application to the ATV 71 . . . . .	132
	Application Architecture with an ATV 71 . . . . .	133
	Software Requirements . . . . .	134
	Hardware Requirements . . . . .	135
12.2	CANopen Bus Configuration ATV 71 . . . . .	136
	Configuration of the CANopen Slave (ATV 71) on CANopen bus . . . . .	136
12.3	Configuring the ATV 71 . . . . .	139
	Configuring the ATV 71 in PowerSuite . . . . .	140
	Configuring the ATV 71 with the User Interface . . . . .	143
12.4	Tuning the ATV 71 . . . . .	145
	Tuning the ATV 71 with PowerSuite . . . . .	145
<b>Chapter 13</b>	<b>IclA Implementation for Motion Function Blocks . . . . .</b>	<b>147</b>
13.1	Adapting the Application to the IclA . . . . .	148
	Application Architecture with an IclA . . . . .	149
	Software Requirements . . . . .	150
	Hardware Requirements . . . . .	151
13.2	CANopen Bus Configuration IclA . . . . .	152
	Configuration of the CANopen Slave (IclA) on CANopen bus . . . . .	152
13.3	Configuring the IclA . . . . .	155
	Configuring the IclA with DIP Switches . . . . .	155
13.4	Tuning the IclA . . . . .	156
	Configuring the IclA in IclA Easy . . . . .	157
	Tuning the IclA with IclA Easy . . . . .	160
<b>Index</b>	<b>. . . . .</b>	<b>161</b>



---

## Safety Information



---

### Important Information

#### NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

### **DANGER**

**DANGER** indicates an imminently hazardous situation which, if not avoided, **will result in** death or serious injury.

### **WARNING**

**WARNING** indicates a potentially hazardous situation which, if not avoided, **can result in** death or serious injury.

---

 **CAUTION**

**CAUTION** indicates a potentially hazardous situation which, if not avoided, **can result in** minor or moderate injury.

**CAUTION**

**CAUTION**, used without the safety alert symbol, indicates a potentially hazardous situation which, if not avoided, **can result in** equipment damage.


**PLEASE NOTE**

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and the installation, and has received safety training to recognize and avoid the hazards involved.

---

## About the Book



---

### At a Glance

#### Document Scope

This manual presents, using a documented example, how to use motion function blocks (MFB) with Modicon M340 using Unity Pro. These blocks enable simplified management of servodrives and servo-amplifiers using the CANopen bus.

Expert knowledge of Unity Pro software is required in order to use MFBs with it, since their implementation requires use of its standard functions (data editor, IODDT, etc.).

Moreover, it is advisable to have expert knowledge of the specialist area of motion control before developing and commissioning an application involving implementation of axis movements.

#### Validity Note

This documentation is valid from Unity Pro v5.0


#### User Comments

We welcome your comments about this document. You can reach us by e-mail at [techcomm@schneider-electric.com](mailto:techcomm@schneider-electric.com).



---

# Start-up Guide for a Single Axis Application



---

## Subject of this Part

This Part presents, in the form of a tutorial, an example of a motion control application implementing MFBs using Unity Pro.

## What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
1	Foreword	15
2	Application Configuration	21
3	Application Programming	51
4	Application Debugging	63
5	Operating the Application	71
6	Application Maintenance	73



---

# Foreword



---

## Subject of this Chapter

This chapter presents the specifications of the application as well as the methodology used in its development.

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
General	16
Availability of Blocks on the Various Servodrives	17
Methodology	19

## General

### Introduction

The MFB using Unity Pro offer is a new motion control functionality. Using the CANopen bus, it provides you with simplified access to the basic functions on servodrives and variable speed drive (VSD).

This functionality, which may be accessed via the project browser, allows you to:

- declare and configure axes in Unity Pro
- create motion control variables
- control the axes by using motion control elementary function blocks.

### Specifications

The purpose of the proposed application is to:

- manage the operating modes of a linear axis using a **Lexium 05**-type servodrive.
- move the axis to the home position, carry out reversing movements or move the axis to various positions
- provide the possibility of interrupting the motion in progress with a Stop command.

All provisions shall be taken to perform fault diagnostics and acknowledgement.

### Standards

The MFB library blocks comply with:

- PLCopen standard

## Availability of Blocks on the Various Servodrives

### Motion Function Blocks

Not all blocks are available on all hardware platforms. The blocks available on your Modicon M340 platform with CANopen fieldbus can be found in the following tables.


Type	Block name	ATV31 ATV312 (7.)	ATV71	Lexium 32	Lexium05	Lexium15 HP, MP, LP	lclA IFA, IFE, IFS
PLCopen motioncontrol V1.1	MC_ReadParameter	X	X	X	X	X	X
	MC_WriteParameter	X	X	X	X	X	X
	MC_ReadActualPosition			X	X	X	X
	MC_ReadActualVelocity (1.)	X	X	X	X	X	X
	MC_Reset	X	X	X	X	X	X
	MC_Stop	X	X	X	X	X	X
	MC_Power	X	X	X	X	X	X
	MC_MoveAbsolute			X	X	X	X
	MC_MoveRelative			X	X	X	
	MC_MoveAdditive			X	X		X
	MC_Home			X	X	X	X
	MC_MoveVelocity	X	X	X	X	X	X
	MC_ReadAxisError	X	X	X	X	X	X
	MC_ReadStatus	X	X	X	X	X	X
	MC_TorqueControl (1.)		X	X	X	X (3.)	
	MC_ReadActualTorque (1.)	X	X	X	X	X	
	MC_Jog (2.)			X	X	X,except 15 LP	X
Parameter set save and restore functions for management of recipes or replacement of faulty servodrives	TE_UploadDriveParam	X	X	X(6.)	X	X	X
	TE_DownloadDriveParam	X	X	X(6.)	X	X	X

Type	Block name	ATV31 ATV312 (7.)	ATV71	Lexium 32	Lexium05	Lexium15 HP, MP, LP	lclA IFA, IFE, IFS
Advanced functions for the <b>Lexium</b>	Lxm_GearPos				X(4.)	X(5.)	
	Lxm_GearPosS			X	X(4.)	X(5.)	
	Lxm_UploadMTask					X	
	Lxm_DownloadMTask					X	
	Lxm_StartMTask			X		X	
System function	CAN_Handler	X	X	X	X	X	X
<ol style="list-style-type: none"> <li>1. PLCopen V0.99 extension part 2</li> <li>2. Not PLCopen standard</li> <li>3. Only for firmware version <math>\geq 6.73</math></li> <li>4. Only for firmware version <math>\geq 1.403</math></li> <li>5. Only for firmware version <math>\geq 2.36</math></li> <li>6. The parameter list is a Lexium32Advanced drive parameter list</li> <li>7. Through an ATV 31 V1.7 CANopen Device configuration.</li> </ol>							

## Methodology

### Overview

The flowchart below lists the various stages involved in installing the application:



The table below details the tasks to be performed for each stage of the flowchart:

Step	Description
1	In Unity Pro: <ul style="list-style-type: none"> <li>● create the project and select the processor</li> </ul>
2	In Unity Pro: <ul style="list-style-type: none"> <li>● open a CANopen bus configuration</li> <li>● choose the CANopen slave in hardware catalog</li> <li>● attribute a topological address to the new device</li> <li>● check or set MFB function in the configuration window of device</li> <li>● enable CANopen configuration</li> <li>● check the accuracy of the configuration using the CANopen configuration tree structure in the project browser.</li> </ul>
3	Create the axes in the project browser's <b>Motion</b> directory. Define the variables associated with these axes during their creation
4	With the PowerSuite software: <ul style="list-style-type: none"> <li>● connect to the device</li> <li>● enter the required parameters for the correct operation of the CANopen communication (address, speed, etc.).</li> </ul>

<b>Step</b>	<b>Description</b>
5	Program the motion sequences using the appropriate functions blocks from the MFB library. Associate the variables defined during creation of the axis with the MFB blocks.
6	Debug the axis using PowerSuite. In Unity: <ul style="list-style-type: none"><li>● debug the program via the animation table</li><li>● use the data via the operator screens</li></ul>
7	manage the production recipes using the appropriate function blocks from the MFB library: <ul style="list-style-type: none"><li>● create and back up the recipes</li><li>● transfer data from the recipes</li></ul>
8	Data backup and restore procedures.

---

# Application Configuration

# 2

---

## Subject of this Chapter

This chapter describes the various stages involved in configuring the application.

## What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
2.1	Hardware and Software Environments	22
2.2	Configuration of the Application using Unity Pro	26
2.3	CANopen Bus Configuration	29
2.4	Axis Configuration using the Motion Tree Manager	35
2.5	Configuring the Lexium 05	44

## 2.1 Hardware and Software Environments

---

### Subject of this Section

This sub-section describes the hardware and software environments used in the application.

### What's in this Section?

This section contains the following topics:

Topic	Page
Application Architecture with a Lexium 05	23
Software Requirements	24
Hardware Requirements	25

## Application Architecture with a Lexium 05


### Overview

The proposed architecture is simple and designed to assimilate the implementation principles of motion control.

Other equipment can be added to this realistic architecture in order to manage several axes.

### Illustration

The following figure shows the architecture used in the application that includes a **Lexium 05**.



## Software Requirements

### Overview

To implement the example, it is essential to have certain items of software on single PC. In particular, this will allow you to configure, set parameters for and operate the various devices used.

The software architecture is composed of:

- Unity Pro, which is used to control the servodrive via the CANopen bus by programming movements
- Powersuite, which is used to set parameters and adjust the Lexium 05 servodrive

It is nonetheless possible to go without PowerSuite in certain cases by using the **Lexium 05** front panel user interface (*see page 48*).

### Versions

The following table lists the hardware and software versions used in the architecture (*see page 23*), enabling the use of MFBs in Unity Pro.

Hardware	Software version used in the example	Firmware Version
<b>Modicon M340</b>	Unity Pro V5.0	-
<b>Lexium 05</b>	PowerSuite for <b>Unity V5.0</b> V2.5, patch V2.2.0B	V1.403

## Hardware Requirements

### References of the Hardware Used

The following table lists the hardware used in the architecture (*see page 23*), enabling implementation of **Lexium 05** MFBs in Unity Pro.

Hardware	Reference
<b>Modicon M340</b> PLC	<b>BMX P34 2030</b>
<b>Modicon M340</b> power supply	<b>BMX CPS 2000</b>
<b>Modicon M340</b> rack	<b>BMX XBP 0800</b>
CANopen junction box between the <b>Modicon M340</b> and <b>Lexium 05</b> servodrive	<b>VW3CANTAP2</b>
RJ45 programming cable with RS485/RS232 adapter between the junction box and servodrive	<b>ACC2CRAAEF030</b>
<b>Lexium 05</b> servodrive	<b>LXM05AD10M2</b>
<b>Lexium 05</b> motor	<b>BSH0551T</b>

**NOTE:** The terminating resistor is integrated in the **Lexium 05**.

## 2.2 Configuration of the Application using Unity Pro

---

### Subject of this Section

This sub-section describes the hardware configuration using Unity Pro.

### What's in this Section?

This section contains the following topics:

Topic	Page
Creating the Project	27
Master Task Configuration	28


## Creating the Project

### At a Glance

Developing an application using Unity Pro involves creating a project associated with a PLC.

### Procedure for Creating a Project

The table below shows the procedure for creating the project using Unity Pro.

Step	Action
1	Launch the Unity Pro software,
2	Click on <b>File</b> then <b>New</b> then select a PLC,
	
3	To see all PLC versions, click on the box Show all versions.
4	Select the processor you wish to use from those proposed.
5	To create a project with specific values of project settings, check the box <b>Settings File</b> and use the browser button to localize the .XSO file (Project Settings file). It is also possible to create a new one. If the <b>Settings File</b> box is not checked, default values of project settings are used.
6	Confirm by clicking <b>OK</b> . The application inserts a rack and a power supply by default.

## Master Task Configuration

### General

The first operation you need to perform to create a program is to select the type of **Tasks**.

You are advised to program the servodrive movements using MFB blocks in the **MAST** task. This task must be scanned at regular intervals.

### ⚠ CAUTION


#### MFB BLOCKS UNEXPECTED BEHAVIOR

Do not mix MAST and FAST tasks. It is possible to use the FAST task to program the MFBs.

**Failure to follow these instructions can result in injury or equipment damage.**

### Configuration

The following table describes the procedure for setting the parameters of the **MAST** task:

Step	Action
1	In the <b>Project Browser</b> , expand the <b>Program</b> directory. The <b>MAST</b> directory is displayed.
2	Right-click on the <b>MAST</b> directory and then execute the <b>Properties</b> command in the contextual menu.
3	Click on <b>Properties</b> and the following dialog box appears:
	
4	Select the <b>Periodic</b> type of scanning.
5	Set the task period to 20.
6	Set the <b>Watchdog</b> value, which must be greater than the period value.
7	Click on <b>OK</b> to confirm the configuration.

---

## 2.3 CANopen Bus Configuration

---

### Subject of this Section

This section presents the CANopen bus configuration methodology.

### What's in this Section?


This section contains the following topics:

Topic	Page
Implementation Methodology for a CANopen Bus	30
Configuration of the CANopen port	31
Configuration of the CANopen Slave	32
Checking the CANopen Bus Configuration	34

## Implementation Methodology for a CANopen Bus

### Overview

The following flowchart shows the implementation methodology for a CANopen bus using Modicon M340.



## Configuration of the CANopen port

### At a Glance


With Unity Pro you can define the CANopen bus.

The CANopen bus master is a port integrated in the CPU.

First, the bus master must be configured.

### How to Configure the CANopen Bus Master



This table describes the procedure to configure the CANopen port using Unity Pro.


Step	Action
1	In the Unity Pro <b>Project Browser</b> , fully expand the <b>Configuration</b> directory and then double-click on PLC bus.
2	Double-click on CANopen port of PLC. <b>Result:</b> The port configuration window appears:
	
3	In the <b>Bus parameters</b> area, set 500 kBaud for the <b>transmission speed</b> . In the <b>Task</b> area, select <b>MAST</b> . In the <b>Outputs</b> area select <b>Reset</b> radio-button. (Strongly recommended)
4	Validate the configuration.
5	<b>Note:</b> We recommend using the IODDT T_COM_CO_BMX that corresponds to the CANopen port for the rest of the programming. Enter CAN for the <b>prefix name</b> . Close the window.

## Configuration of the CANopen Slave

### How to Configure the CANopen Slave

This table describes the procedure to configure the CANopen slave.

Step	Action																																																				
1	<p>In the Unity Pro <b>Project Browser</b>, fully expand the <b>Configuration</b> directory and then double-click on <b>CANopen</b>.</p> <p><b>Result:</b> The CANopen window appears:</p> 																																																				
2	<p>Select <b>Edit → New device</b>.</p> <p><b>Result:</b> The New Device window appears:</p>  <table border="1" data-bbox="477 1052 953 1372"> <thead> <tr> <th>Part Number</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>-</td> <td>CANopen drop</td> </tr> <tr> <td>(+) -</td> <td>Discrete</td> </tr> <tr> <td>(-) -</td> <td>Motion</td> </tr> <tr> <td>----</td> <td>ATV31_V1_1</td> <td>Ativar31 CANopen Slave DSP402 (TEATV3111E eds)</td> </tr> <tr> <td>----</td> <td>ATV31_V1_2</td> <td>Ativar31 CANopen Slave DSP402 (TEATV3112E eds)</td> </tr> <tr> <td>----</td> <td>ATV31T_V1_3</td> <td>Ativar31T CANopen Slave DSP402 (TEATV31T13E eds)</td> </tr> <tr> <td>----</td> <td>ATV61_V1_1</td> <td>ATV61 (TEATV6111E eds)</td> </tr> <tr> <td>----</td> <td>ATV71_V1_1</td> <td>ATV71 (TEATV7111E eds)</td> </tr> <tr> <td>----</td> <td>ICIA_IFA</td> <td>ICIA/IFA CANopen (ICIA/IFA eds)</td> </tr> <tr> <td>----</td> <td>ICIA_IFE</td> <td>ICIA/IFE CANopen (ICIA/IFE eds)</td> </tr> <tr> <td>----</td> <td>ICIA_IFS</td> <td>ICIA/IFS CANopen (ICIA/IFS eds)</td> </tr> <tr> <td>----</td> <td>ICIA_N065</td> <td>ICIA/N065 based on profiles DS301V4.01 and DSP402 V2.0 (BUC...</td> </tr> <tr> <td>----</td> <td>Lexium05</td> <td>DCX170 CANopen (TEDCX107_0100E eds)</td> </tr> <tr> <td>----</td> <td>Lexium05_MFB</td> <td>LXM05A PLCopen (LEXLXM05_MFB eds)</td> </tr> <tr> <td>----</td> <td>Lexium15LP_V1_4</td> <td>EDS for Lexium 15LP servodrive (TELEXM15LP_0142 eds)</td> </tr> <tr> <td>----</td> <td>Lexium15MH_V6_6</td> <td>EDS for Lexium 15MHP servodrive (TELEXM15MH_D661E eds)</td> </tr> <tr> <td>----</td> <td>Oscoder</td> <td>Oscoder - absolute rotary multi-turn encoders (TEXCOSB_0100E eds)</td> </tr> <tr> <td>(+) -</td> <td>Other</td> </tr> </tbody> </table>	Part Number	Description	-	CANopen drop	(+) -	Discrete	(-) -	Motion	----	ATV31_V1_1	Ativar31 CANopen Slave DSP402 (TEATV3111E eds)	----	ATV31_V1_2	Ativar31 CANopen Slave DSP402 (TEATV3112E eds)	----	ATV31T_V1_3	Ativar31T CANopen Slave DSP402 (TEATV31T13E eds)	----	ATV61_V1_1	ATV61 (TEATV6111E eds)	----	ATV71_V1_1	ATV71 (TEATV7111E eds)	----	ICIA_IFA	ICIA/IFA CANopen (ICIA/IFA eds)	----	ICIA_IFE	ICIA/IFE CANopen (ICIA/IFE eds)	----	ICIA_IFS	ICIA/IFS CANopen (ICIA/IFS eds)	----	ICIA_N065	ICIA/N065 based on profiles DS301V4.01 and DSP402 V2.0 (BUC...	----	Lexium05	DCX170 CANopen (TEDCX107_0100E eds)	----	Lexium05_MFB	LXM05A PLCopen (LEXLXM05_MFB eds)	----	Lexium15LP_V1_4	EDS for Lexium 15LP servodrive (TELEXM15LP_0142 eds)	----	Lexium15MH_V6_6	EDS for Lexium 15MHP servodrive (TELEXM15MH_D661E eds)	----	Oscoder	Oscoder - absolute rotary multi-turn encoders (TEXCOSB_0100E eds)	(+) -	Other
Part Number	Description																																																				
-	CANopen drop																																																				
(+) -	Discrete																																																				
(-) -	Motion																																																				
----	ATV31_V1_1	Ativar31 CANopen Slave DSP402 (TEATV3111E eds)																																																			
----	ATV31_V1_2	Ativar31 CANopen Slave DSP402 (TEATV3112E eds)																																																			
----	ATV31T_V1_3	Ativar31T CANopen Slave DSP402 (TEATV31T13E eds)																																																			
----	ATV61_V1_1	ATV61 (TEATV6111E eds)																																																			
----	ATV71_V1_1	ATV71 (TEATV7111E eds)																																																			
----	ICIA_IFA	ICIA/IFA CANopen (ICIA/IFA eds)																																																			
----	ICIA_IFE	ICIA/IFE CANopen (ICIA/IFE eds)																																																			
----	ICIA_IFS	ICIA/IFS CANopen (ICIA/IFS eds)																																																			
----	ICIA_N065	ICIA/N065 based on profiles DS301V4.01 and DSP402 V2.0 (BUC...																																																			
----	Lexium05	DCX170 CANopen (TEDCX107_0100E eds)																																																			
----	Lexium05_MFB	LXM05A PLCopen (LEXLXM05_MFB eds)																																																			
----	Lexium15LP_V1_4	EDS for Lexium 15LP servodrive (TELEXM15LP_0142 eds)																																																			
----	Lexium15MH_V6_6	EDS for Lexium 15MHP servodrive (TELEXM15MH_D661E eds)																																																			
----	Oscoder	Oscoder - absolute rotary multi-turn encoders (TEXCOSB_0100E eds)																																																			
(+) -	Other																																																				

Step	Action
3	Set 2 in Topological Address. Choose Lexium05_MFB for the slave device.
4	Click on OK to confirm the choice. <b>Result:</b> The CANopen window appears with the new device selected: <div data-bbox="436 326 1050 786" style="border: 1px solid black; padding: 5px; margin: 10px 0;">  </div>
5	Select <b>Edit</b> → <b>Open module</b> . If MFB has not already been selected, choose it in the Function area.
6	Select the tab <b>Error Control</b> . Verify that <b>Node Heartbeat Producer time</b> value is equal to 300ms.
7	You will be asked to validate your modifications when closing the Device and CANopen windows.

## Checking the CANopen Bus Configuration


### At a Glance

The CANopen bus is represented in the **Configuration** directory of the project browser.

After having selected and enabled the CANopen configuration, the CANopen slaves appear in the **Project Browser**.

The topological address of the CANopen bus is calculated automatically by Unity Pro. This value cannot be modified.

The diagram below shows the CANopen bus with slave device from the tutorial example:



---

## 2.4 Axis Configuration using the Motion Tree Manager

---

### Subject of this Section

This sub-section describes the **Motion** directory added to Unity Pro's project browser. It also presents a procedure for creating the axis in this directory.

### What's in this Section?

This section contains the following topics:

Topic	Page
Motion Directory	36
Axis Creation and Configuration	38
The Variables Axis_Ref, Can_Handler, AxisParamDesc and Recipe	41
Motion Directory Configuration Result	43

## Motion Directory


### At a Glance

The **Motion** directory of the structural view of the project allows you to access the declaration and configuration of the servodrives.

When declaring a servodrive, various information is required, such as:

- the name given to the servodrive
- the type of servodrive
- the CANopen address of the servodrive
- the reference of the servodrive
- the version of the servodrive
- the input of variable names associated to the axis.

The following diagram shows an example of a tree structure for the **Motion** directory:



In this diagram, the name given to the servodrive is 'Axis\_Z'.

A recipe is linked, by default, each time an axis is created. It is possible to create several recipes (*see page 60*).

## Accessible Services

The **Motion** directory gives you access to the following services, which can be reached via the contextual menu:

Directory	Service
<b>Motion</b>	<b>New axis:</b> allows you to create a new axis.
<b>Axis</b>	<b>New recipe:</b> allows you to create a new recipe. <b>Delete:</b> allows you to delete an axis. <b>Properties:</b> allows you to access the axis properties.
<b>Recipe</b>	<b>Delete:</b> allows you to delete a recipe. <b>Properties:</b> allows you to access the recipe properties.

## Axis Creation and Configuration

### General


The **Motion** directory is used to declare an axis.



This creation allows you to simplify the management and programming of an axis using Unity Pro.


**NOTE:** For any modification to a device on the CANopen bus, those servodrives unaffected by the modification do not need to be reconfigured.

### Creating an Axis

Carry out the following actions:

Step	Action
1	Right-click on the <b>Motion</b> directory and then execute the <b>New axis</b> command in the contextual menu.
2	Clicking on the <b>New axis</b> command will open a dialog box with three tabs.
3	<p>In the <b>General</b> tab,</p> <ul style="list-style-type: none"> <li>● enter:           <ul style="list-style-type: none"> <li>● a name</li> </ul> </li> <li>● select:           <ul style="list-style-type: none"> <li>● a servodrive from the list</li> <li>● a compatible CANopen address</li> </ul> </li> </ul> <p><b>Note:</b> If the CANopen addresses have not as yet been defined, leave <b>&lt;No link&gt;</b> in the list. It is possible to continue development of the application if <b>&lt;No link&gt;</b> is assigned to a compatible CANopen address.</p> <p>When the CANopen addresses have been defined, select an address in the compatible drive list.</p> <p>In this tab, the <b>Axis_Z</b> is configured as follows:</p> 

Step	Action
4	<p>In the <b>Axis Parameters</b> tab, select:</p> <ul style="list-style-type: none"> <li>● the reference of the servodrive</li> <li>● the minimum version of the servodrive's firmware</li> </ul> <p>In this tab, the <b>Axis_Z</b> is configured as follows:</p>  <p><b>Note:</b> You are advised to check for consistency between the version of the servodrive's firmware and the version declared in Unity Pro. The version is used to define the drive parameters. During the servodrive init by the <code>CAN_HANDLER</code> MFB function block, the version is tested.</p>
5	<p>In the <b>Variables Name</b> tab, enter:</p> <ul style="list-style-type: none"> <li>● a name for the <code>Axis_Ref</code> type variable linked to the servodrive</li> <li>● a name for the <code>Can_Handler</code> type variable linked to the servodrive</li> </ul> <p>In this tab, the <b>Axis_Z</b> is configured as follows:</p> 
6	Click on <b>OK</b> to confirm the selections.

Step	Action
7	<p>Right-click on the <b>Recipe_0</b> sub-directory and then select <b>Properties</b> in the contextual menu. It is then possible to modify the recipe and parameter variables created by default when creating the axis.</p> <p><b>Notes :</b> Tick the Initial Values saving Enabled checkbox allows to include the recipe in the application. This functionality is available for M340 V2.0 or later firmware versions, see the recipe variable. (see page 41)</p> <p>In this window, the variables for the <b>Axis_Z</b> are named by default as follows:</p>  <p>The image shows two overlapping windows. On the left is the 'Project Browser' window with a tree view. The tree is expanded to show 'Motion' &gt; 'Axis_Z' &gt; 'Recipe_0'. On the right is a 'Variables' dialog box. It has a title bar 'Variables name' and a close button. It contains two text input fields: 'Recipe variable name:' with the value 'Recipe_0' and 'Parameter description variable name:' with the value 'AxisParamDesc_0'. Below these fields is a checkbox labeled 'Initial values saving Enabled' which is currently unchecked. At the bottom of the dialog are three buttons: 'OK', 'Cancel', and 'Help'.</p>
8	Click on <b>OK</b> to confirm the configuration.

**NOTE:** It is possible to create several recipes for the same axis (there is one by default). Loading of the required recipe, depending on the request, is performed by the TE\_DOWNLOADDRIVEPARAMETER (see *Unity Pro, Motion Function Blocks, Block Library*) block.

This MFB library block is used to:

- load parameters to a new servodrive if the previous one is faulty.
- load a new recipe to a servodrive during a production change, for example

You can delete the recipe if you can not use it.

**NOTE:** The memory size of unlocated data for the management of a recipe by servodrive type is around 2 Kwords.

## The Variables `Axis_Ref`, `Can_Handler`, `AxisParamDesc` and `Recipe`

### At a Glance

For each axis creation, four variables are created:

- A `Can_Handler`-type variable automatically created by motion browser, which can be renamed using the axis directory
- An `Axis_Ref`-type variable which can be renamed using the axis directory
- A byte table type variable (ARRAY[...] OF BYTE) named by default `Recipe_x` (where `x` is a value) but which can be renamed using the `Recipe_x` directory
- An unsigned integer table type variable (ARRAY[...] OF UINT) named `AxisParamDesc_x` (where `x` is a value) and which may not be renamed

### `Can_Handler`

This variable is an EFB type variable. It is named after the CANopen manager variable.

It is declared in the **Variables Name** tab during Axis Creation (*see page 38*).

It must be used in the program as the instance of the `CAN_HANDLER` (*see page 54*) MFB function block.

### `Axis_Ref`

This variable is an `AXIS_REF`-type structured variable named after the axis reference variable.

It is declared in the **Variables Name** tab during Axis Creation (*see page 38*).

It must be specified in the input parameter for each MFB block used by the axis.

### `AxisParamDesc`

This variable is an unsigned integer table type variable (ARRAY[...] OF UNIT). It is automatically created during Axis Creation (*see page 38*). It is named after the parameter description variable which can be seen in the `Recipe_x` properties of the axis.

This variable must be specified in the `TE_UPLOADDRIVEPARAMETER` (*see Unity Pro, Motion Function Blocks, Block Library*) and `TE_DOWNLOADDRIVEPARAMETER` (*see Unity Pro, Motion Function Blocks, Block Library*) blocks' `PARAMETERLIST` input parameter taken from the MFB library and useful for recipe creation or for replacing the axis if it is faulty.

This variable:

- cannot be modified,
- is identical if the axes declared in the application have the same references and firmware version.

## Recipe

This variable is a byte table type variable (ARRAY[...] OF BYTE). It is automatically created during Axis Creation (see page 38). It is named after the recipe variable which can be seen in the `Recipe_x` properties of the axis.

This variable must be specified in the `TE_UPLOADDRIVEPARAMETER` (see *Unity Pro, Motion Function Blocks, Block Library*) or `TE_DOWNLOADDRIVEPARAMETER` (see *Unity Pro, Motion Function Blocks, Block Library*) block's `PARAMETERSET` input parameter taken from the MFB library and useful for recipe creation or for replacing the axis if it is faulty.

The variable name may be modified using the `Recipe_x` properties of the axis.

The recipe can be included in the application :

The application can be updated with a storage in the initial values either with 'update Init Values with Current values' command or using the %S94 bit. Consequently, the STU or XEF file will include the values got from the drive after a TE\_Upload calling . Finally, tick the 'Initial Values saving Enabled' checkbox to make this functionality available.


**NOTE:** By default, Initial Value saving Enabled checkbox is not ticked.

**NOTE:** Initial Values saving Enabled functionality is available for M340 V2.0 or later firmware versions.

## Motion Directory Configuration Result

### In the Project Browser

The following diagram shows the tree structure for the **Motion** directory after configuration:



### In the Data Editor

The following screen shows the variables that are created in the data editor during the creation of the axes. To access this screen, double-click on the **Variables & FB instances** directory in the project browser:

Name	Type	Addr.	Value	Comment
Recipe_0	ARRAY[0..190] OF BYTE			
Axis_Ref_Z	AXIS_REF			Variable declared for axis: Axis_Z
AxisParamDesc_D	ARRAY[0..218] OF UINT			Type: 306, Ref: 12592, Ver: 1.03

The variable `Can_Handler_Z` may be accessed by clicking on the **Function blocks** tab.

## 2.5 Configuring the Lexium 05

---

### Aim of this Section

This section describes the basic servodrive configurations using PowerSuite for **Lexium 05** and the servodrive's front panel user interface.

### What's in this Section?

This section contains the following topics:

Topic	Page
Configuring the Lexium 05 in PowerSuite	45
Configuring the Lexium 05 with the User Interface	48

## Configuring the Lexium 05 in PowerSuite

### Overview

With PowerSuite, users can define installed device bases, and describe their associated configurations and communication settings.

PowerSuite then gives access to a group of actions for editing or transferring the configurations and for connecting to the devices.

PowerSuite's navigation principle associates a configuration interface with each device type, making it possible to control, tune and monitor them.

**NOTE:** The required signals, i.e LIMN, LIMP, REF must be wired or deactivated by the tuning software.

### Connecting to the Lexium 05


This table describes the procedure for connecting to the **Lexium 05**:


Step	Action
1	Connect your PC, on which PowerSuite for <b>Lexium 05</b> is installed, to the <b>RJ45</b> connector on the servodrive to be configured.
2	Start PowerSuite for <b>Lexium 05</b> , <b>Result:</b> the following start-up screen is displayed:

Step	Action
3	Choose <b>Action</b> and then <b>Connect</b> . <b>Result:</b> a text box is displayed.
4	Type a project name (Lexium05_MFB) and then click on <b>OK</b> . <b>Result:</b> a transfer confirmation window is displayed.
5	Press <b>Alt F</b> to start transferring data from the servodrive to the connected work station.

### Basic Lexium 05 Configuration

This table describes the procedure for entering basic settings:

Step	Action
1	<p>Following a connection and transfer of the device's configurations, PowerSuite displays a configuration screen in a new window that gives access to device control, tuning and monitoring functions.</p> <p>In the tree structure displayed, choose <b>CANopen</b> in the <i>Communication</i> directory.</p> <p><b>Result:</b> the following window is displayed:</p> 
2	Double-click on the value in the <b>ID_COAD</b> line, <b>Current Value</b> column, and type the <b>Lexium 05</b> CANopen address.
3	Double-click on the value in the <b>ID_COBD</b> line, <b>Current Value</b> column and choose the CANopen bus baud rate.
4	Save the CANopen settings to EEPROM with the command <b>Configuration</b> → <b>Save to EEPROM</b> . <b>Note:</b> it is possible to adjust the servodrive's settings with the same procedure.

Step	Action																																
5	<p>Once the settings have been adjusted, use the command <b>Configuration → Disconnect</b> to disconnect.  <b>Result:</b> the following screen is displayed, showing the data saved locally:</p>  <p>The screenshot shows the PowerSuite application window. The left sidebar contains a tree view with 'My devices' expanded to show 'LEXIUM_MFB' (selected), 'Motor', and 'Modbus keypad multidrop'. Below it are 'My configurations' and 'Connections'. The main area displays 'LEXIUM_MFB' with the following data:</p> <p><b>Characteristics</b></p> <table border="1" data-bbox="710 488 920 711"> <tr><td>Reference</td><td>LXM05AD10M2</td></tr> <tr><td>Nominal Power</td><td>0,75kW</td></tr> <tr><td>Supply Voltage</td><td>200/240 V1~</td></tr> <tr><td>Maximum transient current (peak)</td><td>10 Apk</td></tr> <tr><td>Maximum continuous current (rms)</td><td>4 Arms</td></tr> <tr><td>Interface</td><td>CANopen, Modbus RTU, P/D, +/-10V</td></tr> </table> <p><b>Structure</b></p> <table border="1" data-bbox="710 781 1098 959"> <thead> <tr> <th>Card</th> <th>Reference</th> <th>Serial number</th> <th>Version</th> <th>Vendor name</th> </tr> </thead> <tbody> <tr> <td>Device</td> <td>LXM05AD10M2</td> <td>01510007438</td> <td>P840.10 V1.01E03</td> <td>Telemecanique</td> </tr> <tr> <td>Control Board</td> <td>Control part-number</td> <td></td> <td></td> <td>Telemecanique</td> </tr> <tr> <td>Motor</td> <td>BSH0551T Family: BSH Size: 9 Length: 7</td> <td></td> <td></td> <td>Telemecanique</td> </tr> </tbody> </table> <p><b>Configuration(s)</b></p> <p>Name: LEXIUM_MFB  Software release: P840.10V1.0E03</p>	Reference	LXM05AD10M2	Nominal Power	0,75kW	Supply Voltage	200/240 V1~	Maximum transient current (peak)	10 Apk	Maximum continuous current (rms)	4 Arms	Interface	CANopen, Modbus RTU, P/D, +/-10V	Card	Reference	Serial number	Version	Vendor name	Device	LXM05AD10M2	01510007438	P840.10 V1.01E03	Telemecanique	Control Board	Control part-number			Telemecanique	Motor	BSH0551T Family: BSH Size: 9 Length: 7			Telemecanique
Reference	LXM05AD10M2																																
Nominal Power	0,75kW																																
Supply Voltage	200/240 V1~																																
Maximum transient current (peak)	10 Apk																																
Maximum continuous current (rms)	4 Arms																																
Interface	CANopen, Modbus RTU, P/D, +/-10V																																
Card	Reference	Serial number	Version	Vendor name																													
Device	LXM05AD10M2	01510007438	P840.10 V1.01E03	Telemecanique																													
Control Board	Control part-number			Telemecanique																													
Motor	BSH0551T Family: BSH Size: 9 Length: 7			Telemecanique																													
6	<p>The Lexium 05 must be turned off and then turned back on in order to apply the new settings.</p>																																

## Configuring the Lexium 05 with the User Interface


### Overview

A user interface is integrated in the **Lexium 05**. With this interface, you can:

- put the device online
- configure the device
- carry out a diagnostic







### Interface Menu Structure

The following graphic presents an overview of access to the interface's main menus:



## Basic Settings

The following table describes the procedure for entering basic settings (CANopen address and speed) with the interface.

Step	Action
1	Press the <b>ENT</b> button on the interface. <b>Result:</b> the <b>SET</b> (Setting) menu is displayed on the interface's status indicator.
2	Press the  button several times to access the <b>COM</b> menu. <b>Result:</b> the <b>COM</b> (Communication) menu is displayed on the interface's status indicator.
3	Press the <b>ENT</b> button on the interface. <b>Result:</b> the <b>COAD</b> (CANopen Address) submenu is displayed on the interface's status indicator.
4	Press <b>ENT</b> again. <b>Result:</b> a value corresponding to the device's CANopen address is displayed.
5	Press the  button to decrease, or the  button to increase the CANopen address value. Press <b>ENT</b> when the desired CANopen address is displayed (3). <b>Result:</b> the value is confirmed and the <b>COAD</b> (CANopen Address) submenu is displayed again.
6	Press <b>ESC</b> once to return to the <b>COAD</b> submenu.
7	Press the  button to access the <b>COBD</b> (CANopen Baud) submenu. Press <b>ENT</b> . <b>Result:</b> a value corresponding to the device's CANopen speed is displayed.
8	Press the  button to decrease, or the  button to increase the CANopen baud rate value. Press <b>ENT</b> when the desired CANopen speed is displayed (500). <b>Result:</b> the value is confirmed and the <b>COBD</b> (CANopen Baud) submenu is displayed again.
9	Press <b>ESC</b> several times to return to the main display ( <b>RDY</b> by default).



---

# Application Programming

# 3

---

## Subject of this Chapter

This chapter describes the various development phases of the application program.

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Declaration of Variables	52
Programming the Example	53
The <code>CAN_HANDLER</code> Function Block	54
Management of the Axis' Operating and Stop Modes	56
Motion Control	57
Motion Monitoring	58
Status and Axis Error Code Section	59
Backup and Transfer of the Servodrive Parameters	60
Transferring the Project between the Terminal and the PLC	61

## Declaration of Variables

### At a Glance

In addition to the variables associated with the axis when it is created in the **Motion** directory, other variables must be declared.

They must be assigned to:

- Input or output parameters of the MFB blocs
- Operator Screen (*see page 69*) objects.

They allow you to use certain data and to control the axis with blocks from the MotionFunctionBlock library.

### Declaration in the Data Editor

The table below summarizes the variables to be created in the data editor for the tutorial example:

Name	Type	Comment
Cmd_Home_Z	BOOL	Return axis to home position command
Cmd_Mvt_Z	BOOL	Move axis command
Cmd_Run_Z	BOOL	Run axis command
Cmd_Stop_Z	BOOL	Stop axis command
Cmd_Reset_Z	BOOL	Acknowledge axis command
Cmd_Upload_Z	BOOL	Save axis data in a recipe table command
Cmd_Download_Z	BOOL	Transfer data from recipe table to axis command
Axis_OK_Z	BOOL	Axis recognized by CANopen bus
Position_Z	DINT	Value of axis position
Velocity_Z	DINT	Value of axis speed
Recipe_Z	ARRAY[0..190] OF BYTE	Buffer variable for management of recipes
CAN	T_COM_CO_BMX	IODDT that manages CANOpen port

**NOTE:** the size of the recipe management table complies with that of the recipes created by the **Motion** directory.

## Programming the Example

### At a Glance

Just after declaration and parameter setting of the hardware, motion programming is the second development phase of the tutorial example.

Axis programming is divided up into:


- declaration of variables
- an operator screen which is used to view and control the axis
- structured programming in several sections

### Declaring the Sections

The table below presents a summary of the program sections to create

Section name	Language	Description
CAN_Handler <i>(see page 54)</i>	FBD	This section allows you to check that the parameters of the axis correspond to reality.
Operating_mode <i>(see page 56)</i>	FBD	This section allows you to power up the servodrives and to check the axes.
Cmd_Mvt <i>(see page 57)</i>	FBD	This section allows you to set a homing reference point for the axis and to then control it in absolute motion.
Control_Mvt <i>(see page 58)</i>	FBD	This section is used to determine the position and speed of the axis.
Status_Axes <i>(see page 59)</i>	FBD	This section is used to determine the status of the axis and to carry out diagnostics for an event.
Recipe <i>(see page 60)</i>	FBD	This section allows you to save or restore a servodrive's data.

The diagram below shows the program structure after the programming sections have been created:



## The CAN\_HANDLER Function Block

### At a Glance

The use of the CAN\_HANDLER (see *Unity Pro, Motion Function Blocks, Block Library*) **MFB** function block is **essential** and **mandatory** in the programming of the axis. The program section with this **MFB** function block must be associated with the same task of the CANopen bus master (see page 31).

It allows you to check:


- the CANopen communication
- consistency between the software configuration and the connected physical device.

This block uses the two variables that belong to the axis' directory. The `Can_Handler_Z` variable must be used as instance and the `Axis_Ref_Z` variable must be assigned to the block's `AXIS` input parameter.

### Inserting and Instantiating a Block


This table describes the procedure for inserting and select the instance of a block in a program section:

Step	Action
1	Right click in an empty field in the FBD section to display the contextual menu.
2	Execute the <b>FFB Input Assistant..</b> command in the contextual menu. <b>Result:</b> The Function Input Assistant opens.
3	Click on the ... icon on the <b>FFB Type</b> line. <b>Result:</b> the <b>FFB Type Selection</b> window opens.
4	Expand <b>Libraries</b> → <b>MotionFunctionBlock</b> and click on <b>MFB</b> . <b>Result:</b> all of the blocks from the <b>MotionFunctionBlock</b> library are displayed on the right-hand side of the <b>FFB Type Selection</b> window.
5	Select the <code>CAN_HANDLER</code> block and confirm your choice by clicking on <b>OK</b> . <b>Result:</b> The <b>FFB Input Assistant..</b> window is displayed, set up by the <code>CAN_HANDLER</code> block.
6	Click on the ... icon on the <b>Instance</b> line. <b>Result:</b> the <b>FB Instance Selection</b> window opens.

Step	Action
7	<p>Select the <code>Can_Handler_Z</code> instance and confirm your choice by clicking on <b>OK</b>.  <b>Result:</b> The <code>Can_Handler_Z</code> variable is displayed in the <b>Instance</b> field:</p> 
8	<p>Confirm the block configuration by clicking on <b>OK</b>.  <b>Result:</b> the FDB section is displayed again. A symbol is added to the mouse cursor.</p>
9	<p>Click on an empty field in the FDB section.  <b>Result:</b> the <code>CAN_HANDLER</code> block, instantiated by the <code>Can_Handler_Z</code> variable is inserted in the FDB section.</p>
10	<p>Specify the input and output parameters as defined in the contents.</p>

## Contents

The screen below shows the section result:



`CAN.SLAVE_ACTIV_2` corresponds to the active slave bit created by the `IODDT_T_COM_CO_BMX`.

The input parameter `NETWORKOPERATIONAL` must be assigned to a bit that validates the correct operation of the CANopen network.

The assignment of this parameter left to the discretion of the developer. It depends on the philosophy of the process and the way the bus is managed.

For example, this parameter may be connected to an object or to a `T_COM_CO_BMX` (see *Modicon M340 with Unity Pro, CANopen, User manual*)-type `IODDT` equation.

## Management of the Axis' Operating and Stop Modes


### At a Glance

This section is made up of the following MFB blocks:

- MC\_POWER (see *Unity Pro, Motion Function Blocks, Block Library*), which is used to disable or enable the servodrives
- MC\_STOP (see *Unity Pro, Motion Function Blocks, Block Library*), which is used to stop any movement in progress
- MC\_RESET (see *Unity Pro, Motion Function Blocks, Block Library*), which is used to initialize the function blocks and to acknowledge servodrive faults.

### Contents

The screen below shows a part of the section to develop:



The blocks are instantiated to variables input directly in the **Instance** zone of the **FFB Input Assistant** to facilitate subsequent diagnostics using the animation tables.

## Motion Control


### At a Glance

This programming section is made up of the following MFB blocks:

- MC\_HOME (see *Unity Pro, Motion Function Blocks, Block Library*), which allows a homing reference point to be set for the axis before then launching it in absolute motion
- MC\_MOVEABSOLUTE (see *Unity Pro, Motion Function Blocks, Block Library*), which allows the axis to make an absolute movement.

### Contents

The screen below shows the part of the section:



For the tutorial example, the section is made up of a type of sequence of reversing movements.

The outward motion is conditioned by the `Cmd_Mvt_Z` bit from the operator screen (see page 69).

The return motion is conditioned by the end of the outward motion.

The position unit is **USR** and the velocity unit is **rpm**.

The Homing type `HTYPE` value (34) corresponds to an homing within a single turn, positive direction of rotation.

## Motion Monitoring


### At a Glance

This section is made up of the MC\_READACTUALPOSITION (see *Unity Pro, Motion Function Blocks, Block Library*) and MC\_READACTUALVELOCITY (see *Unity Pro, Motion Function Blocks, Block Library*) MFB blocks.

These blocks are used to determine the exact position and speed of the axis.

### Contents

The screen below shows a part of the section to develop:



Whilst the `Axis_OK_Z` bit is enabled, the position and speed values are continuously displayed on the operator screen (see page 69).

## Status and Axis Error Code Section


### At a Glance

This section is made up of the following MFB blocks:

- MC\_READSTATUS (see *Unity Pro, Motion Function Blocks, Block Library*), which is used to determine the drive status (see *Unity Pro, Motion Function Blocks, Block Library*)
- MC\_READAXISERROR (see *Unity Pro, Motion Function Blocks, Block Library*), which is used to determine the error values according to the type of errors on the drive and to deduce their causes (see *Unity Pro, Motion Function Blocks, Block Library*).

### Contents

The screen below shows a part of the section:



The `UPLOAD_Z.ERROR` and `DOWNLOAD_Z.ERROR` variables must be added to the OR block after the recipe (see page 60) section has been created.

## Backup and Transfer of the Servodrive Parameters


### At a Glance

This programming section is made up of the following MFB blocks:

- **TE\_UPLOADDRIVEPARAM** (see *Unity Pro, Motion Function Blocks, Block Library*), which is used to back up the configuration of a servodrive in a data table
- **TE\_DOWNLOADDRIVEPARAM** (see *Unity Pro, Motion Function Blocks, Block Library*), which is used to transfer the data table parameters to a servodrive.

### Contents

The screen below shows the Recipe section:



If **Cmd\_Upload\_Z** is enabled, the servodrive configuration is saved in the data table **Recipe\_Z** (buffer variable for the recipes).

If **Cmd\_Download\_Z** is enabled, the servodrive configuration is restored by the data table **Recipe\_Z**.

## Transferring the Project between the Terminal and the PLC

### At a Glance

Transferring a project allows you to copy the current project from the terminal to the current PLC's memory (PLC that has its address selected).

### Project Analysis and Generation

To perform analysis and generation of a project at the same time, carry out the following actions:

Step	Action
1	Activate the <b>Rebuild All Project</b> command in the <b>Build</b> menu. <b>Result:</b> the project is analyzed and generated by the software.
2	Any errors detected are displayed in the information window at the bottom of your screen.

### Project Backup



To back up the project, carry out the following actions:

Step	Action
1	Activate the <b>Save As</b> command in the <b>File</b> menu.
2	If necessary, select the directory to which the project will be saved (disk and path).
3	Enter the file name: <b>MFB_Lexium05</b> .
4	Confirm with <b>Save</b> . <b>Result:</b> the project is saved as <b>MFB_Lexium05.STU</b> .

### Transferring the Project to the PLC

You must carry out the following actions to transfer the current project to a PLC:

Step	Action
1	Use the <b>PLC →Define the address</b> command. Enter <b>SYS</b> if you are using a <b>USB</b> media that is directly connected from the PC (terminal) to the PLC.
2	Switch to online mode using the <b>PLC →Connection</b> command.

Step	Action
3	<p>Activate the <b>PLC</b> →<b>Transfer Project to PLC</b> command.  <b>Result:</b> the screen used to transfer the project between the terminal and the PLC is displayed:</p> 
4	<p>Activate the <b>Transfer</b> command.</p>
5	<p>If the project has not been generated in advance, the screen below will be displayed allowing you to generate it before the transfer (<b>Rebuild All then Transfer</b>) or interrupt the transfer (<b>Cancel Transfer</b>).</p> 
6	<p>Transfer progress is displayed on screen. At any moment, you can interrupt the transfer by using the <b>Esc</b> key. In this case, the PLC project will be invalid.  <b>Note:</b> In the event that the project is transferred to a Flash Eprom memory card, the transfer can take several minutes.</p>

---

# Application Debugging



---

## Subject of this Chapter

This chapter describes the possibilities for debugging the application using Unity Pro and PowerSuite for **Lexium 05**.

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Tuning the Lexium 05 with PowerSuite	64
Using Data via the Animation Tables	65
Program Debugging	67
Using Data via the Operator Screens	69



## Tuning the Lexium 05 with PowerSuite

### In Advance

We recommend tuning the axis kinematic before the program automatically starts it.

### Tuning Example

The following table gives an example of kinematic tuning:

Step	Action
1	Connect ( <i>see page 45</i> ) to the <b>Lexium 05</b> .
2	<p>After a connection and transfer of the device's configurations, PowerSuite opens a new window with the configuration screen, which gives access to device control, tuning and monitoring functions.</p> <p>The following figure shows part of the new window. This lower window provides access to <b>Lexium 05</b> command functions:</p> 
3	Place the <b>Command</b> zone cursor on <b>Active</b> .
4	Place the <b>Enable</b> zone cursor on <b>On</b> .
5	Click the <b>Reset</b> button to clear any problems.
6	Click the <b>Test Run</b> button.
7	Enter the value 0,1 in the <b>CUR_I_target</b> zone.
8	<p>Place the <b>CURref</b> zone cursor on <b>On</b>.</p> <p><b>Result:</b> the motor runs and the sub-window is animated:</p> 
9	Place the <b>Command</b> zone cursor on <b>Inactive</b> once tuning has been finalized.

## Using Data via the Animation Tables

### At a Glance


The animation table is the Unity Pro' basic tool for viewing and forcing the status of variables.

**NOTE:** Unity Pro also offers a graphic tool called **Operator Screens** which is designed to facilitate use of the application (*see page 69*).

An animation table is divided into 3 areas that include:

- the **Mode** area
- the **Command** area
- the **Display** area

Animation table:





### Creating an Animation Table

The table below presents the procedure for creating an animation table:

Step	Action
1	Right-click on the <b>Animation Tables</b> directory in the project browser. <b>Result:</b> the contextual menu is displayed.
2	Select <b>New Animation Table</b> . <b>Result:</b> a table properties window is displayed.
3	Click on OK to create the table, which is given a default name. <b>Result:</b> the animation table is displayed.

## Adding Data to the Animation Table

The table below presents the procedure for creating data to view or force in the animation table:

Step	Action
1	In the <b>Table</b> window, click on the empty line in the <b>Name</b> column.
2	There are two possible ways of adding data: <ul style="list-style-type: none"> <li>● Enter the variable directly</li> <li>● Click on the  icon to display the instance selection window in order to select the variable</li> </ul>
3	Enter or select the respective variables. <ul style="list-style-type: none"> <li>● Cmd_Home_Z to issue an return axis to home position command</li> <li>● Cmd_Mvt_Z to issue a move axis command</li> <li>● Cmd_Run_Z to issue a run axis command</li> <li>● Cmd_Stop_Z to issue a stop axis command</li> <li>● Cmd_Reset_Z to issue an axis acknowledgement command</li> <li>● Cmd_Upload_Z to issue a save axis data to a recipe table command</li> <li>● Cmd_Download_Z to issue a transfer data from the recipe table to the axis command</li> <li>● Axis_OK_Z to view the axis recognized by the CANopen bus</li> <li>● Position_Z to determine the value of the axis position</li> <li>● Velocity_Z to determine the value of the axis speed</li> </ul> <p><b>Result:</b> the animation table looks like this.</p> 

## Program Debugging

### At a Glance


After transferring the program and running the axis using Powersuite for **Lexium 05**, the process is commissioned.

An animation table is a commissioning solution used to monitor, modify and/or force the values of variables.

The sets of parameters of the axis may be accessed and modified in Unity Pro using the MFB messaging blocks MC\_READPARAMETER (see *Unity Pro, Motion Function Blocks, Block Library*) and MC\_WRITEPARAMETER (see *Unity Pro, Motion Function Blocks, Block Library*).

### Modification Mode

The following screen shows the animation table in modification mode:



This table is used to determine the status of the MC\_POWER block's input and output parameters.


To access this mode, click on the **Modify** button in the mode selection zone.

**NOTE:** this operation may be assigned to other function blocks.

**NOTE:** the animation table is dynamic only in online mode (display of variable values).

### Modifying Values

The tutorial example uses Boolean variables. To modify a Boolean value, carry out the following actions:

Step	Action
1	Use the mouse to select the Boolean variable you wish to modify.
2	Click on the  button corresponding to the desired value, or execute the <b>Set to 0</b> or <b>Set to 1</b> commands in the contextual menu.

**Starting the System**

The following table describes the procedure for starting the system used in the example:

Step	Action
1	Set the variable <code>Cmd_Run_Z</code> to 1. <b>Result:</b> the variable <code>Axis_OK_Z</code> changes to 1.
2	Set the variable <code>Cmd_Reset_Z</code> to 1.
3	Set the variable <code>Cmd_Home_Z</code> to 1. <b>Result:</b> the axis is referenced.
4	To rotate the axis, set the variable <code>Cmd_Mvt_Z</code> to 1. <b>Result:</b> the axis starts to turn and the values of the variables <code>Position_Z</code> and <code>Velocity_Z</code> are no longer set to 0.
5	To stop the axis from rotating: <ul style="list-style-type: none"><li>● set the variable <code>Cmd_Stop_Z</code> to 1</li><li>● set the variable <code>Cmd_Mvt_Z</code> to 0</li></ul> <b>Result :</b> the axis stops rotating.
6	To start to rotate the axis again and complete the movement: <ul style="list-style-type: none"><li>● set the variable <code>Cmd_Stop_Z</code> to 0</li><li>● set the variable <code>Cmd_Mvt_Z</code> to 1</li></ul> <b>Result:</b> the axis starts to rotate again and completes its movement.

## Using Data via the Operator Screens

### At a Glance


When a project is created, it common for there to be no input cards, output cards and supervision. To lessen the impact of this problem, using the Unity Pro operator screen associated with unlocated bits and words allows you to carry out initial debugging of the program.

In the tutorial example, the operator screen is used to:

- view data from the servodrives
- send commands to the servodrives

### Representation

The representation below symbolizes the operating example which is used to control the axis and indicate the variables to be assigned to the objects (push button, LED and text):





---

# Operating the Application

# 5

---

## Management of the Recipes

### At a Glance

The TE\_UPLOADDRIVEPARAM (see *Unity Pro, Motion Function Blocks, Block Library*) and TE\_DOWNLOADDRIVEPARAM (see *Unity Pro, Motion Function Blocks, Block Library*) blocks are used to manage the production recipes.

An example of the procedure for creating and managing recipes is described in this section.

**NOTE:** for flexible machines, it is possible to manage several parameter recipes.

### Creating and backing up the recipes

The table describes the procedure for creating recipes:

Step	Action
1	Create the recipes (see page 38) using the <b>Axis_Z</b> directory. <b>Result:</b> new recipe variables ( <code>Recipe_0</code> , <code>Recipe_1</code> , etc.) are automatically created in the Data Editor (see page 43).
2	Create a variable corresponding to the type of recipe variables. This variable is named in the <code>Recipe_Z</code> tutorial example. <code>Recipe_Z</code> acts as a buffer when backing up or transferring data. <b>Note:</b> it is essential to check <b>Allow dynamic arrays [ANY_ARRAY_XXX]</b> located in <b>Tools</b> → <b>Project options</b> → <b>Tab: Language extensions</b> → <b>Zone: Data type</b> to be able to use table type variables such as the recipes.
3	Configure the servodrive's parameters using Powersuite (see page 45). These initial settings are used to configure a recipe.

Step	Action
4	<p>Perform a backup of the parameters using the TE_UPLOADDRIVEPARAM (see <i>Unity Pro, Motion Function Blocks, Block Library</i>) block in the buffer variable <code>Recipe_Z</code>.</p> <p>The backup was successful if the bits of the MC_READSTATUS (see <i>Unity Pro, Motion Function Blocks, Block Library</i>) block are as follows:</p> <ul style="list-style-type: none"> <li>● DOWNLOADING (see <i>Unity Pro, Motion Function Blocks, Block Library</i>) is set to 0</li> <li>● STANDSTILL (see <i>Unity Pro, Motion Function Blocks, Block Library</i>) is set to 1</li> </ul>
5	<p>Transfer the data backed up in the <code>Recipe_Z</code> buffer variable to the <code>Recipe_0</code> variable.</p>
6	<p>Repeat steps 3 and 4 to transfer the data backed up in the <code>Recipe_Z</code> buffer variable to the <code>Recipe_1</code> variable.</p> <p>The following programming presents a data transfer example based on the value of PRODUCTION:</p> <pre> IF UPLOAD_Z.DONE AND PRODUCTION=0 THEN Recipe_0:=Recipe_Z; END_IF; IF UPLOAD_Z.DONE AND PRODUCTION=1 THEN Recipe_1:=Recipe_Z; END_IF;                     </pre>

### Transfer Data from the Recipes

The table describes the procedure to transfer recipe data to the servodrive (for a production change, for example):

Step	Action
1	<p>Reload the <code>Recipe_Z</code> buffer variable based on the value of PRODUCTION (type of production requested).</p> <pre> IF Cmd_Download_Z AND PRODUCTION=0 THEN Recipe_Z:=Recipe_0; END_IF; IF Cmd_Download_Z AND PRODUCTION=1 THEN Recipe_Z:=Recipe_1; END_IF;                     </pre>
2	<p>Transfer the parameter data, using the <code>Recipe_Z</code> buffer variable's TE_DOWNLOADDRIVEPARAM (see <i>Unity Pro, Motion Function Blocks, Block Library</i>) block, to the servodrive.</p>
3	<p>The transfer was successful if the bits of the MC_READSTATUS (see <i>Unity Pro, Motion Function Blocks, Block Library</i>) block are as follows:</p> <ul style="list-style-type: none"> <li>● DOWNLOADING (see <i>Unity Pro, Motion Function Blocks, Block Library</i>) is set to 0</li> <li>● STANDSTILL (see <i>Unity Pro, Motion Function Blocks, Block Library</i>) is set to 1</li> </ul>

---

# Application Maintenance

# 6

---

## Subject of this Chapter

This chapter describes the procedure involved in replacing a servodrive after a fault has been diagnosed.

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Error Example	74
Replacing a Faulty Servodrive	76

## Error Example

### At a Glance

The MC\_ReadAxisError function is used to recover system errors.

If an error or warning occurs, the block specifies a code by applying a value to the AXISFAULTID, AXISDIAGID and AXISWARNINGID output parameters.

### Error Codes


The following table shows the **Lexium 05** error codes:

	Lexium 05
AxisFaultId	SigLatched 301C:08
AxisDiagId	WarnLatched 301C:0C
AxisWarningId	StopFault 603F:0

**NOTE:** refer to the CANopen documentation for **Lexium 05** to identify the error.

### Finding Errors

The table below describes a procedure for finding faults following an error or warning code.

Step	Action
1	<p>The AxisFault output parameter equals 1.                      The AxisFaultId output parameter displays an error value.                      The graph below shows the error generated:</p> 

---

Step	Action
2	Refer to the CANopen documentation of the <b>Lexium 05</b> and look for the code SigLatched 301C:08.
3	The AxisFaultID value is set to 4194304. This binary value means that bit 22 is set to one. Refer to the CANopen documentation of the <b>Lexium 05</b> and look for the code 'SigLatched' 301C:08. Bit 22 for 'SigLatched' designates a lag error.
4	Reduce the speed constants in absolute block or external load or acceleration.
5	Execute the <code>MC_Reset</code> block.

## Replacing a Faulty Servodrive

### At a Glance

If the servodrive fails, it may be necessary to swap it for an identical servodrive (reference). To do this, you are advised to save the adjustment parameters to a data table using the `TE_UPLOADDRIVEPARAMETER` (see *Unity Pro, Motion Function Blocks, Block Library*) block.

The `TE_DOWNLOADDRIVEPARAM` (see *page 60*) block then allows you to restore the saved data to a new servodrive.

### Data Backup

The table below describes the procedure used to back up the servodrive's data using the `TE_UPLOADDRIVEPARAMETER` (see *Unity Pro, Motion Function Blocks, Block Library*) block:

Step	Action
1	Disable the Enable parameter, which belongs to the <code>MC_POWER</code> (see <i>Unity Pro, Motion Function Blocks, Block Library</i> ) block. <b>Result:</b> the servodrive switches to Disable (see <i>Unity Pro, Motion Function Blocks, Block Library</i> ) mode.
2	Enable the input parameter <code>Execute</code> . <b>Result:</b> the servodrive switches to Downloading (see <i>Unity Pro, Motion Function Blocks, Block Library</i> ) mode. The data table assigned to the output parameter <code>PARAMETERSET</code> is filled in. <b>Note:</b> Please back up data to a <code>.DAT</code> file using <b>PLC → Transfer PLC data to the file</b> if the PLC has no memory card.

## Restoring Data

The table below describes the procedure used to restore the servodrive's data using the TE\_DOWNLOADDRIVEPARAM (see page 60) block:

Step	Action
1	Disable the Enable parameter, which belongs to the MC_POWER (see <i>Unity Pro, Motion Function Blocks, Block Library</i> ) block. <b>Result:</b> the servodrive switches to Disable (see <i>Unity Pro, Motion Function Blocks, Block Library</i> ) mode.
2	Change the servodrive. The new servodrive must have the same references as the faulty servodrive. <b>Note:</b> make sure you take all the necessary precautions when changing the servodrive.
3	Configure the new servodrive with the basic parameters (see page 45) (CANopen address, speed) or using the keypad on the front panel.
4	Enable the block's input parameter <code>Execute</code> . <b>Result:</b> the servodrive switches to Downloading (see <i>Unity Pro, Motion Function Blocks, Block Library</i> ) mode. The data table assigned to the input parameter <code>PARAMETERSET</code> loads the input <code>PARAMETERLIST</code> which corresponds to the servodrive parameter.



---

# Multi-Axis Application



---

## Aim of this Part

This part describes the other hardware available for the Motion Function Blocks offer with a Modicon M340 running Unity Pro.

The **Lexium 05** servodrive was used in the previous part to carry out an example. This part begins with a presentation of the following servodrives in a full architecture:

- **Lexium 32**
- **Lexium 15**
- **ATV 31**
- **ATV 71**
- **IclA**

Following this presentation, configuration of each of the servodrives is described, detailing differences with the **Lexium 05** so as to carry out the same example.

## What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
7	Foreword	81
8	Compatibility of motion applications with Unity versions	83
9	Lexium 32 Implementation for Motion Function Blocks	85
10	Lexium 15MP/HP/LP Implementation for Motion Function Blocks	99
11	ATV 31 Implementation for Motion Function Blocks	117
12	ATV 71 Implementation for Motion Function Blocks	131
13	IclA Implementation for Motion Function Blocks	147



---

# Foreword

# 7

---


## Application Architecture with All Servodrives

### Overview

Following is a presentation of the usage of available hardware (servodrives), via an architecture, for implementing Motion Function Blocks in Unity Pro.

### Illustration

The following figure shows the architecture used in the application that includes all servodrives:





---

## Compatibility of motion applications with Unity versions

# 8

---

### Compatibility of XEF files

Unity Target version	Unity Source version	
	V3.x/V4.0 M340 Proc < V2.0	>=V4.0 M340 Proc >=V2.0
V3.x M340 < V2.0	Partially compatible in case of usage of Lexium15.	NC.
>=V4.0	PC.	FC.

NC : Not compatible. The motion parts are ignored during the import.  
PC : Partially compatible : the new axis type are ignored with an error message during the import : the application is imported by the sections using the drives that are in error. The new firmware version are downgraded to the highest available in the Unity version with a warning during import, if the drives is present in the catalog for Mirano CPU. If not, the import is aborted.  
FC : Fully compatible.

**NOTE: 1.** : The news EFB causes errors in the sections using them.

**NOTE: 2.** : Processor M340>=V2.0: initial value saving enabled support.

---

## Compatibility of STA files

Unity Target Version	Unity Souce Version		
	V3.x/V4.0 application without motion	V3.x/V4.0 with M340 < V2.0	>=V4.0 with M340 >= V2.0
V3.x	FC	PC	NC
>=V4.0	FC	FC	FC

NC: Not compatible  
PC: Partially compatible: compatible only for applications with drive supported by the Unity which is opening the application, in case of drives type or firmware versions evolutions. The application can be opened but can not be modified deeply.  
FC: Full compatible.

---

# Lexium 32 Implementation for Motion Function Blocks

# 9

---

## Aim of this Chapter

This chapter presents the implementation of Lexium 32 servodrives according to the methodology (*see page 19*) described in the quick start guide (*see page 13*) with a Lexium 05. It only details the differences and actions for Lexium 32.

## What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
9.1	Adapting the Application to the Lexium 32	86
9.2	Configuring the Lexium 32	92
9.3	Tuning the Lexium 32	95

## 9.1 Adapting the Application to the Lexium 32

---

### Aim of this Section

This section presents adaptation of an application to the **Lexium 32** with an architecture, hardware and software requirements.

In this section Lexium 32 means else a Lexium 32 Advanced reference (LXM 32A...) else a Lexium 32 Modular reference (LXM 32 M...)

### What's in this Section?

This section contains the following topics:

Topic	Page
Application Architecture with Lexium 32	87
Software Requirements	88
Hardware Requirements	89
CANopen Bus Configuration Lexium 32	90

## Application Architecture with Lexium 32


### At a Glance

The proposed structure represents a simple structure which is designed to demonstrate motion control implementation principles.

This realistic structure may well be expanded upon with other devices in order to manage several axes.

### Illustration

The figure below shows the structure used in the application:




## Software Requirements

### Overview

Following the software requirements presented in the Quick Start Guide (see page 24), Lexium CT is used for configuring and tuning the **Lexium 32**.

### Functional Diagram for the Lexium 32

The following diagram shows the different functions performed by the PLC and the servodrive:



### Versions

The following table lists the hardware and software versions used in the Architecture (see page 101), enabling the use of MFBs in Unity Pro.

Device	Software version used in the example	Version of firmware
<b>Modicon M340</b>	Unity Pro V5.0	>2.0
<b>Lexium 32</b>	Lexium CT V1.0	V1.x for Lexium 32 Advanced V1.y for Lexium 32 Modular

## Hardware Requirements

### References of the Hardware Used

The following table lists the hardware used in the architecture (*see page 87*), enabling implementation of **Lexium 32** MFBs in Unity Pro.

Hardware	Reference
<b>Modicon M340 PLC</b>	<b>BMX P34 20302</b>
<b>Modicon M340 power supply</b>	<b>BMX CPS 2000</b>
<b>Modicon M340 rack</b>	<b>BMX XBP 0800</b>
<b>Lexium 32 Advanced</b>	<b>LXM32AU90M2</b>
<b>Lexium 32 connection cable to CANopen port of the PLC</b>	<b>TCSCCN4F 3M3T/CAN</b>
CANopen Line terminator	TCSCAR013M120
Motor for <b>Lexium 32</b>	<b>BSH055**</b>

## CANopen Bus Configuration Lexium 32


### Overview

The implementation methodology for a CANopen bus using Modicon M340 is to:

- Upgrade the hardware catalog
- Configure (see page 31) the CANopen port of the CPU
- Declare the slave chosen from the hardware catalog (see paragraph below)
- Configure the slave
- Enable the configuration using Unity Pro
- Check (see page 34) the CANopen bus in the Project browser




### How to Upgrade the Hardware Catalog

This table describes the procedure to configure the CANopen slave.

Step	Action
1	<p>Open the Hardware Catalog  <b>Start →Program →Schneider Electric →Socollaborative →UnityPro → Hardware Catalog Manager</b>  <b>Result:</b>The Hardware Catalog Manager window appears:</p> 
2	<p>In the menu tab, click on File ==&gt;Import User Devices, then import the LXM32_MFB.cpx file in the directory ...Application Data\Schneider Electric\ConfCatalog\Database\Motion (this file can be located in a hidden directory).</p>

## How to Configure the CANopen Slave

This table describes the procedure to configure the CANopen slave.

Step	Action
1	<p>In the Unity Pro <b>Project Browser</b>, fully expand the <b>Configuration</b> directory and then double-click on <b>CANopen</b>.</p> <p><b>Result:</b> The CANopen window appears:</p> 
2	<p>Select <b>Edit</b> → <b>New device</b>.</p> <p><b>Result:</b> The New Device window appears:</p> 
3	<p>Set 3 in Topological Address.</p> <p>For the slave device choose Lexium 32.</p>
4	<p>Click on OK to confirm the choice.</p> <p><b>Result:</b> The CANopen window appears with the new device selected:</p> 
5	<p>Select <b>Edit</b> → <b>Open module</b>.</p> <p>If MFB has not already been selected, choose it in the Function area.</p>
6	<p>You will be asked to validate your modifications when closing the Device and CANopen windows.</p>

## 9.2                    **Configuring the Lexium 32**

---




### **Basic Parameters for Lexium 32 using Lexium CT**

#### **At a Glance**

Lexium CT is a commissioning tool for axes intended for motion control applications. Its graphic user interface provides a simple method for configuring the parameters of a **Lexium 32**-type servodrive.


## Connecting to Lexium 32

This table describes the procedure for connecting to **Lexium 32**.

Step	Action																																																																																																																																																																																																																														
1	<p>Start Lexium CT. Click on <b>Connection</b> and then select <b>ModbusSerialLine connection</b> connection. The Connection window is displayed:</p>  <p>Select the COM-Port Validate by OK The following screen appears:</p> 																																																																																																																																																																																																																														
2	<p>When configuration has been established, this general screen appears:</p>  <table border="1"> <thead> <tr> <th>Name</th> <th>Value</th> <th>Unit</th> <th>Description</th> <th>Range</th> <th>Modbus</th> </tr> </thead> <tbody> <tr><td>IOFunc_DI0</td><td>TouchProbe_1</td><td></td><td>Function Input DI0</td><td>...</td><td>1784</td></tr> <tr><td>IOFunc_DI1</td><td>Reference switch (REF)</td><td></td><td>Function Input DI1</td><td>...</td><td>1788</td></tr> <tr><td>IOFunc_DI2</td><td>Positive limit switch (LMP)</td><td></td><td>Function Input DI2</td><td>...</td><td>1798</td></tr> <tr><td>IOFunc_DI3</td><td>Negative limit switch (LMN)</td><td></td><td>Function Input DI3</td><td>...</td><td>1803</td></tr> <tr><td>IOFunc_DI4</td><td>Free available</td><td></td><td>Function Input DI4</td><td>...</td><td>1802</td></tr> <tr><td>IOFunc_DI5</td><td>Free available</td><td></td><td>Function Input DI5</td><td>...</td><td>1804</td></tr> <tr><td>IOFunc_DO0</td><td>No fault</td><td></td><td>Function Output DO0</td><td>...</td><td>1810</td></tr> <tr><td>IOFunc_DO1</td><td>Active</td><td></td><td>Function Output DO1</td><td>...</td><td>1812</td></tr> <tr><td>IOFunc_DO2</td><td>Free available</td><td></td><td>Function Output DO2</td><td>...</td><td>1814</td></tr> <tr><td>SPVn_lim</td><td>10</td><td>1/min</td><td>Speed limitation via input</td><td>1.9999</td><td>1596</td></tr> <tr><td>SPVn_clmp</td><td>10</td><td>1/min</td><td>Speed limit for Zero Clamp</td><td>0.1000</td><td>1616</td></tr> <tr><td>SPVn_lim</td><td>10.0</td><td>%</td><td>Current limitation via input</td><td>0.3000</td><td>1614</td></tr> <tr><td>SPVnWinTm</td><td>0</td><td>ms</td><td>Monitoring of time window</td><td>0.3099</td><td>1594</td></tr> <tr><td>SPVn_DiFFn</td><td>0.0010</td><td>rev/ulo</td><td>Monitoring of position deviation</td><td>0.0.9999</td><td>1598</td></tr> <tr><td>SPVn_DiFFn</td><td>10</td><td>1/min</td><td>Monitoring of speed deviation</td><td>1.9999</td><td>1588</td></tr> <tr><td>SPVn_Thresho</td><td>10</td><td>1/min</td><td>Monitoring of speed value</td><td>1.9999</td><td>1590</td></tr> <tr><td>SPVn_Thresho</td><td>1.0</td><td>%</td><td>Monitoring of current value</td><td>0.3000</td><td>1602</td></tr> <tr><td>SPVSeErrn1</td><td>0</td><td></td><td>First selective error entry</td><td>0.85535</td><td>15116</td></tr> <tr><td>SPVSeErrn2</td><td>0</td><td></td><td>Second selective error entry</td><td>0.85535</td><td>15118</td></tr> <tr><td>SPVSeWarn1</td><td>0</td><td></td><td>First selective warning entry</td><td>0.85535</td><td>15120</td></tr> <tr><td>SPVSeWarn2</td><td>0</td><td></td><td>Second selective warning entry</td><td>0.85535</td><td>15122</td></tr> <tr><td>RESn_Ext</td><td>Internal Resistor</td><td></td><td>Braking resistor control</td><td>0.1</td><td>1268</td></tr> <tr><td>RESn_P</td><td>10</td><td>W</td><td>Nominal power of external braking resistor</td><td>1.32787</td><td>1318</td></tr> <tr><td>RESn_R</td><td>100.00</td><td>Ohm</td><td>Resistance value of external braking resistor</td><td>1.327.87</td><td>1318</td></tr> <tr><td>RESn_ton</td><td>1</td><td>ms</td><td>Max. permissible switch-on time of external braking</td><td>1.30000</td><td>1314</td></tr> <tr><td>BRK_release</td><td>0</td><td>ms</td><td>Time delay during opening/releasing the holding</td><td>0.1000</td><td>1294</td></tr> <tr><td>BRK_hold</td><td>0</td><td>ms</td><td>Time delay during closing of holding brake</td><td>0.1000</td><td>1296</td></tr> <tr><td>ESMscale</td><td>4096</td><td>inc</td><td>Encoder simulation - setting of resolution</td><td>0.85535</td><td>1322</td></tr> <tr><td>HMDiagPass</td><td>DeviceStatus</td><td></td><td>HMI display when motor rotates</td><td>0.2</td><td>14852</td></tr> <tr><td>HMIlocked</td><td>not locked</td><td></td><td>Lock HMI</td><td>0.1</td><td>14850</td></tr> <tr><td>IOCfgLMP</td><td>normally closed</td><td></td><td>Signal evaluation LMP</td><td>0.2</td><td>1568</td></tr> <tr><td>IOCfgLMN</td><td>normally closed</td><td></td><td>Signal evaluation LMN</td><td>0.2</td><td>1566</td></tr> <tr><td>IOCfgRef</td><td>normally closed</td><td></td><td>Signal evaluation REF</td><td>1.2</td><td>1564</td></tr> <tr><td>SPV_SW_LimIn</td><td>zone</td><td></td><td>Monitoring of software limit switches</td><td>0.3</td><td>1542</td></tr> <tr><td>SPVswLimNur</td><td>2147483848</td><td>usr</td><td>Negative position limit for software limit switch</td><td>...</td><td>1548</td></tr> <tr><td>SPVswLimPos</td><td>2147483847</td><td>usr</td><td>Positive position limit for software limit switch</td><td>...</td><td>1544</td></tr> </tbody> </table>	Name	Value	Unit	Description	Range	Modbus	IOFunc_DI0	TouchProbe_1		Function Input DI0	...	1784	IOFunc_DI1	Reference switch (REF)		Function Input DI1	...	1788	IOFunc_DI2	Positive limit switch (LMP)		Function Input DI2	...	1798	IOFunc_DI3	Negative limit switch (LMN)		Function Input DI3	...	1803	IOFunc_DI4	Free available		Function Input DI4	...	1802	IOFunc_DI5	Free available		Function Input DI5	...	1804	IOFunc_DO0	No fault		Function Output DO0	...	1810	IOFunc_DO1	Active		Function Output DO1	...	1812	IOFunc_DO2	Free available		Function Output DO2	...	1814	SPVn_lim	10	1/min	Speed limitation via input	1.9999	1596	SPVn_clmp	10	1/min	Speed limit for Zero Clamp	0.1000	1616	SPVn_lim	10.0	%	Current limitation via input	0.3000	1614	SPVnWinTm	0	ms	Monitoring of time window	0.3099	1594	SPVn_DiFFn	0.0010	rev/ulo	Monitoring of position deviation	0.0.9999	1598	SPVn_DiFFn	10	1/min	Monitoring of speed deviation	1.9999	1588	SPVn_Thresho	10	1/min	Monitoring of speed value	1.9999	1590	SPVn_Thresho	1.0	%	Monitoring of current value	0.3000	1602	SPVSeErrn1	0		First selective error entry	0.85535	15116	SPVSeErrn2	0		Second selective error entry	0.85535	15118	SPVSeWarn1	0		First selective warning entry	0.85535	15120	SPVSeWarn2	0		Second selective warning entry	0.85535	15122	RESn_Ext	Internal Resistor		Braking resistor control	0.1	1268	RESn_P	10	W	Nominal power of external braking resistor	1.32787	1318	RESn_R	100.00	Ohm	Resistance value of external braking resistor	1.327.87	1318	RESn_ton	1	ms	Max. permissible switch-on time of external braking	1.30000	1314	BRK_release	0	ms	Time delay during opening/releasing the holding	0.1000	1294	BRK_hold	0	ms	Time delay during closing of holding brake	0.1000	1296	ESMscale	4096	inc	Encoder simulation - setting of resolution	0.85535	1322	HMDiagPass	DeviceStatus		HMI display when motor rotates	0.2	14852	HMIlocked	not locked		Lock HMI	0.1	14850	IOCfgLMP	normally closed		Signal evaluation LMP	0.2	1568	IOCfgLMN	normally closed		Signal evaluation LMN	0.2	1566	IOCfgRef	normally closed		Signal evaluation REF	1.2	1564	SPV_SW_LimIn	zone		Monitoring of software limit switches	0.3	1542	SPVswLimNur	2147483848	usr	Negative position limit for software limit switch	...	1548	SPVswLimPos	2147483847	usr	Positive position limit for software limit switch	...	1544
Name	Value	Unit	Description	Range	Modbus																																																																																																																																																																																																																										
IOFunc_DI0	TouchProbe_1		Function Input DI0	...	1784																																																																																																																																																																																																																										
IOFunc_DI1	Reference switch (REF)		Function Input DI1	...	1788																																																																																																																																																																																																																										
IOFunc_DI2	Positive limit switch (LMP)		Function Input DI2	...	1798																																																																																																																																																																																																																										
IOFunc_DI3	Negative limit switch (LMN)		Function Input DI3	...	1803																																																																																																																																																																																																																										
IOFunc_DI4	Free available		Function Input DI4	...	1802																																																																																																																																																																																																																										
IOFunc_DI5	Free available		Function Input DI5	...	1804																																																																																																																																																																																																																										
IOFunc_DO0	No fault		Function Output DO0	...	1810																																																																																																																																																																																																																										
IOFunc_DO1	Active		Function Output DO1	...	1812																																																																																																																																																																																																																										
IOFunc_DO2	Free available		Function Output DO2	...	1814																																																																																																																																																																																																																										
SPVn_lim	10	1/min	Speed limitation via input	1.9999	1596																																																																																																																																																																																																																										
SPVn_clmp	10	1/min	Speed limit for Zero Clamp	0.1000	1616																																																																																																																																																																																																																										
SPVn_lim	10.0	%	Current limitation via input	0.3000	1614																																																																																																																																																																																																																										
SPVnWinTm	0	ms	Monitoring of time window	0.3099	1594																																																																																																																																																																																																																										
SPVn_DiFFn	0.0010	rev/ulo	Monitoring of position deviation	0.0.9999	1598																																																																																																																																																																																																																										
SPVn_DiFFn	10	1/min	Monitoring of speed deviation	1.9999	1588																																																																																																																																																																																																																										
SPVn_Thresho	10	1/min	Monitoring of speed value	1.9999	1590																																																																																																																																																																																																																										
SPVn_Thresho	1.0	%	Monitoring of current value	0.3000	1602																																																																																																																																																																																																																										
SPVSeErrn1	0		First selective error entry	0.85535	15116																																																																																																																																																																																																																										
SPVSeErrn2	0		Second selective error entry	0.85535	15118																																																																																																																																																																																																																										
SPVSeWarn1	0		First selective warning entry	0.85535	15120																																																																																																																																																																																																																										
SPVSeWarn2	0		Second selective warning entry	0.85535	15122																																																																																																																																																																																																																										
RESn_Ext	Internal Resistor		Braking resistor control	0.1	1268																																																																																																																																																																																																																										
RESn_P	10	W	Nominal power of external braking resistor	1.32787	1318																																																																																																																																																																																																																										
RESn_R	100.00	Ohm	Resistance value of external braking resistor	1.327.87	1318																																																																																																																																																																																																																										
RESn_ton	1	ms	Max. permissible switch-on time of external braking	1.30000	1314																																																																																																																																																																																																																										
BRK_release	0	ms	Time delay during opening/releasing the holding	0.1000	1294																																																																																																																																																																																																																										
BRK_hold	0	ms	Time delay during closing of holding brake	0.1000	1296																																																																																																																																																																																																																										
ESMscale	4096	inc	Encoder simulation - setting of resolution	0.85535	1322																																																																																																																																																																																																																										
HMDiagPass	DeviceStatus		HMI display when motor rotates	0.2	14852																																																																																																																																																																																																																										
HMIlocked	not locked		Lock HMI	0.1	14850																																																																																																																																																																																																																										
IOCfgLMP	normally closed		Signal evaluation LMP	0.2	1568																																																																																																																																																																																																																										
IOCfgLMN	normally closed		Signal evaluation LMN	0.2	1566																																																																																																																																																																																																																										
IOCfgRef	normally closed		Signal evaluation REF	1.2	1564																																																																																																																																																																																																																										
SPV_SW_LimIn	zone		Monitoring of software limit switches	0.3	1542																																																																																																																																																																																																																										
SPVswLimNur	2147483848	usr	Negative position limit for software limit switch	...	1548																																																																																																																																																																																																																										
SPVswLimPos	2147483847	usr	Positive position limit for software limit switch	...	1544																																																																																																																																																																																																																										

## Basic Parameters

This table describes the procedure for inputting the basic parameters:

Step	Action																																																																																																
1	<p>Click on the <b>Basic Configuration</b></p> <p>The <b>Basic Configuration</b> window appears:</p>  <table border="1"> <thead> <tr> <th>Name</th> <th>Value</th> <th>Unit</th> <th>Description</th> <th>Range</th> <th>Modbus</th> </tr> </thead> <tbody> <tr> <td>Kipointerface</td> <td>ABInput</td> <td></td> <td>Signal selection position interface</td> <td>0, 1</td> <td>1294</td> </tr> <tr> <td>DIbaud</td> <td>0</td> <td></td> <td>DIbaud address (code number)</td> <td>1, 03</td> <td>1059</td> </tr> <tr> <td>MIbaud</td> <td>1</td> <td></td> <td>Modbus address</td> <td>1, 247</td> <td>8540</td> </tr> <tr> <td>MBbaud</td> <td>19.2Kb</td> <td></td> <td>Modbus Baud rate</td> <td>9600, 38400</td> <td>8539</td> </tr> <tr> <td>CAbaud</td> <td>2</td> <td></td> <td>CANopen address (code number)</td> <td>1, 127</td> <td>1664</td> </tr> <tr> <td>CANbaud</td> <td>125Kb</td> <td></td> <td>CANopen Baud rate</td> <td>50, 1000</td> <td>1665</td> </tr> <tr> <td>CTRL_n_max</td> <td>3000</td> <td>1/min</td> <td>Speed limitation</td> <td>0, 12000</td> <td>4394</td> </tr> <tr> <td>CTRL_1_max</td> <td>400.0</td> <td>%</td> <td>Current limitation</td> <td>0, 3000</td> <td>4376</td> </tr> <tr> <td>LLM_1_maxGET</td> <td>400.0</td> <td>%</td> <td>Current limitation for Quick Stop</td> <td>0, 3000</td> <td>4378</td> </tr> <tr> <td>LLM_1_maxSET</td> <td>400.0</td> <td>%</td> <td>Current limitation for stall</td> <td>0, 3000</td> <td>4380</td> </tr> <tr> <td>ESMactive</td> <td>Enable/Off</td> <td></td> <td>Disabled/Enable ESM functionality</td> <td>0, 2</td> <td>1142</td> </tr> <tr> <td>ESMscale</td> <td>4096</td> <td>inc</td> <td>Encoder simulation - setting of resolution</td> <td>0, 65535</td> <td>1322</td> </tr> <tr> <td>Mains_choke</td> <td>no</td> <td></td> <td>Mains choke</td> <td>0, 1</td> <td>1344</td> </tr> <tr> <td>ROTdirection</td> <td>clockwise</td> <td></td> <td>Definition of direction of rotation</td> <td>0, 1</td> <td>1360</td> </tr> <tr> <td>Ulimns_reduce</td> <td>off</td> <td></td> <td>Reduced input mains voltage on 1 phase devices</td> <td>0, 1</td> <td>1346</td> </tr> </tbody> </table> <p>This screen is used to set parameters for the servodrive's CANopen address, the bus speed and the units used for acceleration, speed and position.</p>	Name	Value	Unit	Description	Range	Modbus	Kipointerface	ABInput		Signal selection position interface	0, 1	1294	DIbaud	0		DIbaud address (code number)	1, 03	1059	MIbaud	1		Modbus address	1, 247	8540	MBbaud	19.2Kb		Modbus Baud rate	9600, 38400	8539	CAbaud	2		CANopen address (code number)	1, 127	1664	CANbaud	125Kb		CANopen Baud rate	50, 1000	1665	CTRL_n_max	3000	1/min	Speed limitation	0, 12000	4394	CTRL_1_max	400.0	%	Current limitation	0, 3000	4376	LLM_1_maxGET	400.0	%	Current limitation for Quick Stop	0, 3000	4378	LLM_1_maxSET	400.0	%	Current limitation for stall	0, 3000	4380	ESMactive	Enable/Off		Disabled/Enable ESM functionality	0, 2	1142	ESMscale	4096	inc	Encoder simulation - setting of resolution	0, 65535	1322	Mains_choke	no		Mains choke	0, 1	1344	ROTdirection	clockwise		Definition of direction of rotation	0, 1	1360	Ulimns_reduce	off		Reduced input mains voltage on 1 phase devices	0, 1	1346
Name	Value	Unit	Description	Range	Modbus																																																																																												
Kipointerface	ABInput		Signal selection position interface	0, 1	1294																																																																																												
DIbaud	0		DIbaud address (code number)	1, 03	1059																																																																																												
MIbaud	1		Modbus address	1, 247	8540																																																																																												
MBbaud	19.2Kb		Modbus Baud rate	9600, 38400	8539																																																																																												
CAbaud	2		CANopen address (code number)	1, 127	1664																																																																																												
CANbaud	125Kb		CANopen Baud rate	50, 1000	1665																																																																																												
CTRL_n_max	3000	1/min	Speed limitation	0, 12000	4394																																																																																												
CTRL_1_max	400.0	%	Current limitation	0, 3000	4376																																																																																												
LLM_1_maxGET	400.0	%	Current limitation for Quick Stop	0, 3000	4378																																																																																												
LLM_1_maxSET	400.0	%	Current limitation for stall	0, 3000	4380																																																																																												
ESMactive	Enable/Off		Disabled/Enable ESM functionality	0, 2	1142																																																																																												
ESMscale	4096	inc	Encoder simulation - setting of resolution	0, 65535	1322																																																																																												
Mains_choke	no		Mains choke	0, 1	1344																																																																																												
ROTdirection	clockwise		Definition of direction of rotation	0, 1	1360																																																																																												
Ulimns_reduce	off		Reduced input mains voltage on 1 phase devices	0, 1	1346																																																																																												
2	<p>For the tutorial example, from this screen set or select the following:</p> <ul style="list-style-type: none"> <li>● In the servodrive zone: <ul style="list-style-type: none"> <li>● The CANopen address to 2</li> <li>● The baud rate of the bus to 500 Kbaud (<i>see MFB using Unity Pro, Start-up Guide</i>)</li> </ul> </li> </ul>																																																																																																
3	<p>Click <b>Items</b> → <b>Parameter</b> → <b>Save device parameters</b> in EEPROM to confirm the <b>SIMPLYSTART_BASICCONFIGURATION</b>.</p> <p><b>Result:</b> The <b>SIMPLYSTART_BASICCONFIGURATION</b> is saved and the main screen is displayed again.</p>																																																																																																
4	Click on <b>Exit</b> .																																																																																																

**NOTE:** For information on how to adjust parameters correctly, please refer to the drive documentation

---

## 9.3 Tuning the Lexium 32

---

### Aim of this Section

This section gives an example of tuning the **Lexium 32** with Lexium CT.

### What's in this Section?

This section contains the following topics:

Topic	Page
Tuning the Lexium 32	96
Debugging the Lexium 32	97

## Tuning the Lexium 32

### Operating modes

The various operating modes can be selected from the tabs in the Operating modes windows.


The windows is subdivided into two sections:

- Tabs for the selected operating mode and for setting specific parameters (top section)
- Display of status information (bottom section)

The user can switch between the tabs in the Operating Modes window without interfering with a currently active operating mode.

### Profile Velocity

In the operating mode Profile Velocity, the drive accelerates to an adjustable target speed of rotation. You can set a motion profile with values for acceleration and deceleration ramps



## Debugging the Lexium 32

### Pre-requisite

You are recommended to debug the axis dynamics before it is automatically started by the program.

### Description


The commissioning software provides the “**Recording / Tuning**” function for visualizing internal device data during movements. The connected device stores the movement data to an internal memory for a defined recording period and then sends it to the PC. The PC processes the data and displays it in the form of charts or tables.

Recorded data can be saved on the PC, and can be archived or printed for documentation purposes.

Use the menu **Item** → **Functions** → **Record / Tuning...** to start the “record” function.


### Illustration

The screen below can be accessed by clicking on the **Oscilloscope** tab:



## Description Buttons

The buttons below can be accessed by clicking:




1. Start recording
2. Stop recording
3. Zoom in, y axis
4. Zoom out, y axis
5. Infinitely variable zoom, x axis and y axis
6. Zoom selected rectangle.
7. 1nd display of values for a specific time
8. Change displayed values for first display
9. 2nd display of values for a specific time.
10. Change displayed values for second display
11. Restore original display
12. Invert y axis
13. Display table of recorded values
14. Enter description
15. Show/hide configuration
16. Print recording

## Recording

The desired parameters are selected in the “Available signals” input field. A maximum of 4 parameters can be selected. If a parameter is no longer required, it can be deselected by a double-click on the name of the parameter.

The desired recording increment is select in the “Timebase” input field. The smaller the “Time base”, the smaller the maximum recording time will be.



---

# Lexium 15MP/HP/LP Implementation for Motion Function Blocks

# 10

---

## Aim of this Chapter

This chapter presents the implementation of Lexium 15MP/HP/LP servodrives according to the methodology (*see page 19*) described in the quick start guide (*see page 13*) with a Lexium 05. It only details the differences and actions for Lexium 15MP/HP/LP.

## What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
10.1	Adapting the Application to the Lexium 15MP/HP/LP	100
10.2	CANopen Bus Configuration Lexium 15MP/HP/LP	104
10.3	Configuring the Lexium 15MP/HP/LP	106
10.4	Tuning the Lexium 15MP/HP/LP	114

## 10.1            **Adapting the Application to the Lexium 15MP/HP/LP**

---

### **Aim of this Section**

This section presents adaptation of the application to the **Lexium 15MP/HP/LP** with an architecture, and hardware and software requirements.

### **What's in this Section?**

This section contains the following topics:

<b>Topic</b>	<b>Page</b>
Application Architecture with Lexium 15MP/HP/LP	101
Software Requirements	102
Hardware Requirements	103

## Application Architecture with Lexium 15MP/HP/LP


### At a Glance

The proposed structure represents a simple structure which is designed to assimilate the motion control implementation principles.

This realistic structure may well be expanded upon with other devices in order to manage several axes.

### Illustration

The figure below shows the structure used in the application:



## Software Requirements


### Overview

As regards the software requirements presented in the quick start guide (*see page 24*), PowerSuite is used for configuring and tuning the **Lexium 05**.

PowerSuite for **Lexium 05** enables on-lining of the axis and guarantees a simple method for configuring the parameters of a **Lexium 05** servodrive. Unilink L/MH for **Lexium 15••** does the same, but for **Lexium 15••** servodrive.

### Functional Diagram for the Lexium 15••

The following diagram shows the different functions performed by the PLC and the servodrive:



### Versions

The following table lists the hardware and software versions used in the architecture (*see page 101*), enabling the use of MFBs in Unity Pro.

Device	Software version used in the example	Version of firmware
<b>Modicon M340</b>	Unity Pro V4.0	-
<b>Lexium 15LP</b>	Unilink V1.5	V1.45 only MFB Function V2.36 Managed by MTM
<b>Lexium 15MH</b>	Unilink V4.0	Compatible since V6.64

## Hardware Requirements

### References of the Hardware Used

The following table lists the hardware used in the architecture (*see page 101*), enabling implementation of **Lexium 15MP** MFBs in Unity Pro.

Hardware	Reference
<b>Modicon M340 PLC</b>	<b>BMX P34 2030</b>
<b>Modicon M340 power supply</b>	<b>BMX CPS 2000</b>
<b>Modicon M340 rack</b>	<b>BMX XBP 0800</b>
<b>Lexium 15MP Servodrive</b>	<b>LXM15MD28N4</b>
<b>Lexium 15MP connection cable to CANopen port of the PLC</b>	<b>TLA CD CBA ***</b>
CANopen connector for <b>Lexium 15MP</b>	<b>AM0 2CA 001 V000</b>
Motor for <b>Lexium 15MP</b>	<b>BPH055**</b>

The following table lists the hardware used in the architecture (*see page 101*), enabling implementation of **Lexium 15LP** MFBs in Unity Pro.

Hardware	Reference
<b>Modicon M340 PLC</b>	<b>BMX P34 2030</b>
<b>Modicon M340 power supply</b>	<b>BMX CPS 2000</b>
<b>Modicon M340 rack</b>	<b>BMX XBP 0800</b>
<b>Lexium 15LP Servodrive</b>	<b>LXM15LD13M3</b>
<b>Lexium 15MP connection cable to CANopen port of the PLC</b>	<b>TLA CD CBA ***</b>
CANopen connector for <b>Lexium 15LP</b>	<b>AM0 2CA 001 V000</b>
Motor for <b>Lexium 15LP</b>	<b>AKM 31E</b>

**NOTE:** the line terminator is an interrupter built into the **AM0 2CA 001 V000** CANopen connector.

## 10.2 CANopen Bus Configuration Lexium 15MP/HP/LP

### Configuration of the CANopen Slave on CANopen bus



#### Overview


The implementation methodology for a CANopen bus using Modicon M340 is to:

- configure (see page 31) the CANopen port of the CPU,
- declare the slave chosen from the hardware catalog (see paragraph below),
- configure the slave,
- enable the configuration using Unity Pro,
- check (see page 34) the CANopen bus in the Project browser.

#### How to Configure the CANopen Slave

This table describes the procedure to configure the CANopen slave.

Step	Action
1	<p>In the Unity Pro <b>Project Browser</b>, fully expand the <b>Configuration</b> directory and then double-click on <b>CANopen</b>.</p> <p><b>Result:</b> The CANopen window appears:</p> 
2	<p>Select <b>Edit</b> → <b>New device</b>.</p> <p><b>Result:</b> The New Device window appears:</p> 

Step	Action
3	Set 3 in Topological Address. For the slave device choose Lexium15LP_V1_4 for a Lexium 15LP or Lexium15MH_V6_61for a Lexium 15MP.
4	Click on OK to confirm the choice. <b>Result:</b> The CANopen window appears with the new device selected: 
5	Select <b>Edit →Open module</b> . If MFB has not already been selected, choose it in the Function area.
6	You will be asked to validate your modifications when closing the Device and CANopen windows.

## 10.3 Configuring the Lexium 15MP/HP/LP

---

### Aim of this Section

This section describes the basic servodrive configurations using **Unilink L/MH** for **Lexium 15MP/HP/LP**.

### What's in this Section?

This section contains the following topics:

Topic	Page
Basic Parameters for Lexium 15MP using Unilink MH	107
Basic Parameters for Lexium 15LP using Unilink L	109
Specific Parameters for Lexium 15 MP/HP/LP using Unilink	112

## Basic Parameters for Lexium 15MP using Unilink MH



### At a Glance

Unilink is a commissioning tool for axes intended for motion control applications.

Its graphic user interface provides a simple method for configuring the parameters of a **Lexium 15MP**-type servodrive.


### Connecting to Lexium 15MP

This table describes the procedure for connecting to **Lexium 15MP** :

Step	Action
1	<p>Start Unilink MH via <b>Start</b> → <b>Program</b> → <b>Unilink</b> → <b>Unilink MH</b>. A communication window is displayed on main window of Unilink MH:</p>  <p>If the port that you are using is available (i.e. is not being used by other devices or programs), the name COM1, COM2, COM3, COM4, COM5, COM6, COM7, COM8, COM9, COM10 appears in black. Otherwise, it appears in grey.</p>
2	<p>Click on one of these communication ports (the port that you use on your PC) to transfer the values of the servodrive parameters to your PC. When communication has been established, this general screen appears:</p> 

## Basic Parameters

This table describes the procedure for inputting the basic parameters:

Step	Action
1	<p>Click on the <b>Basic Setup</b> button in the general screen. The <b>Basic Setup</b> window appears:</p>  <p>This screen is used to set parameters for the servodrive's CANopen address, the bus speed and the units used for acceleration, speed and position.</p>
2	<p>For the tutorial example, from this screen set or select the following:</p> <ul style="list-style-type: none"> <li>● In the servodrive zone: <ul style="list-style-type: none"> <li>● the CANopen address to 2</li> <li>● the baud rate of the bus to 500 Kbaud (<i>see page 31</i>)</li> </ul> </li> <li>● In the Unit (<i>see Unity Pro, Motion Function Blocks, Block Library</i>) zone: <ul style="list-style-type: none"> <li>● the acceleration in ms-&gt;VLIM</li> <li>● the speed in rpm</li> <li>● the position in μm</li> </ul> </li> </ul>
3	<p>Click on the <b>Motor Selection</b>, <b>Current</b>, <b>Resolver</b> buttons to declare the motor and the feedback parameters. <b>Note:</b> for information on how to declare the motor correctly, please refer to the motor documentation.</p>
4	<p>Click <b>OK</b> to confirm the basic configuration. <b>Result:</b> the basic setup is saved and the main screen is displayed again. <b>Note:</b> when certain ASCII parameters have been enabled, a window appears asking you to save changes to the servodrive's EEPROM memory. Click on <b>OK</b> to restart the servodrive and update the memory.</p>
5	<p>Click on <b>Exit</b>.</p>

## Basic Parameters for Lexium 15LP using Unilink L

### At a Glance

Unilink is a commissioning tool for axes intended for motion control applications.

Its graphic user interface provides a simple method for configuring the parameters of a **Lexium 15LP**-type servodrive.



### Connecting to Lexium 15LP



This table describes the procedure for connecting to **Lexium 15LP** :

Step	Action
1	Start Unilink L via <b>Start</b> → <b>Program</b> → <b>Unilink</b> → <b>Unilink L</b> . <b>Result:</b> a window ask you if you would like to connect to the drive
2	Click on the <b>Yes</b> button. <b>Result:</b> a window to select the device appears.
3	Select <b>RS-232</b> and click on the <b>OK</b> button. <b>Result:</b> a window of RS-232 settings appears.
4	Set the serial port (COM1 to COM10), the Baud Rate (38400), the Timeout (2000ms).
5	Click on the <b>OK</b> button. <b>Result:</b> Unilink L software appears.

## Basic Parameters

This table describes the procedure for inputting the basic parameters:

Step	Action
1	<p>Click on the <b>Setup wizard</b> on the browser.  <b>Result:</b>the <b>Drive Setup</b> screen in the main frame appears:</p> 
2	<p>Select the <b>Complete Setup</b> on the screen.  <b>Result:</b> the browser with all configurations links appears.</p>
3	<p>Click on the <b>Basic Setup</b> on the browser.  <b>Result:</b> the <b>Basic Setup</b> screen in the main frame appears:</p>  <p>This screen is used to set parameters of the power supply.</p>

Step	Action
4	<p>Click on the <b>Units/Mechanical</b> on the browser. The <b>Units/Mechanical</b> screen in the main frame appears:</p>  <p>For the tutorial example, from this screen set or select the following:</p> <ul style="list-style-type: none"> <li>● In the User Units zone: <ul style="list-style-type: none"> <li>● the acceleration in ms-&gt;VLIM</li> <li>● the speed in rpm</li> <li>● the position in µm</li> </ul> </li> </ul>
5	<p>Click on the <b>CAN / Field Bus Settings</b> on the browser. The <b>CAN / Field Bus Settings</b> screen in the main frame appears:</p>  <p>For the tutorial example, from this screen set or select the following:</p> <ul style="list-style-type: none"> <li>● In the General Field Bus and CAN Bus Settings zones: <ul style="list-style-type: none"> <li>● the CANopen address to 3</li> <li>● the baud rate of the bus to 500 Kbauds</li> </ul> </li> </ul>
6	<p>Click on the <b>Motor, Resolver</b> folders on the browser to declare the motor and the feedback parameters. <b>Note:</b> for information on how to declare the motor correctly, please refer to the motor documentation.</p>
7	<p>Save the parameters via <b>Drive → Save to EEPROM</b>. <b>Result:</b> the basic setup is saved and the main screen is displayed again.</p>



## Specific Parameters for Lexium 15 MP/HP/LP using Unilink


### At a Glance

Specific parameters are entered in addition to the basic (*see MFB using Unity Pro, Start-up Guide*) parameters. These specific parameters supplement the configuration of **Lexium 15 MP/HP/LP** by modifying certain ASCII codes using the **Terminal** window.

### Specific Parameters

This table describes the procedure for inputting the specific parameters of **Lexium 15 MP/HP/LP**:

Step	Action
1	<p>Click on the  <b>Terminal</b> icon on the general page. The <b>Terminal</b> window is displayed:</p>  <p>This screen is used to fully configure the connection point of a <b>Lexium 15MP/HP/LP</b>.</p>
2	<p>For Lexium 15 MP/HP i enter in the <b>Command</b> field:</p> <ul style="list-style-type: none"> <li>● DRVCNFG 1050670</li> </ul> <p>For Lexium 15 LP enter in the <b>Command</b> field:</p> <ul style="list-style-type: none"> <li>● INPT2 x1.5 task time, or IN20Mode42 either <b>MAST</b> or <b>FAST</b></li> </ul>
3	Click on <b>Apply</b> to confirm the configuration of this ASCII parameter.
4	<p>For Lexium 15 MP/HP repeat the steps by entering in the <b>Command</b> field:</p> <ul style="list-style-type: none"> <li>● DRVCNFG2 64</li> <li>● INPT x1.5 task time <b>MAST</b> or <b>FAST</b></li> <li>● ENGAGE 1</li> </ul>

Step	Action
5	Click on <b>OK</b> to confirm the last <b>Command</b> and return to the general page.
6	 <p>Click on the <b>Save</b> icon on the general page to save the basic and specific parameters to the servodrive's EEPROM memory.</p>
7	Close the general window and click on <b>DIS</b> to disconnect from the servodrive.

## Command

Enter the ASCII command here, with the corresponding parameters. Confirm the entry with **RETURN** or press the **APPLY** button to start the transmission.

### CAUTION

#### UNEXPECTED APPLICATION BEHAVIOR

Before sending the ASCII command, ensure that is appropriate to the equipment.

**Failure to follow these instructions can result in injury or equipment damage.**

## 10.4 Tuning the Lexium 15MP/HP/LP

### Debugging the axis

#### Pre-requisite

You are recommended to debug the axis dynamics before it is automatically started by the program.

#### Description


The oscilloscope is one way of carrying out the debug operation.

It allows you to:

- display up to three variables simultaneously, as a function of time
- save the recorded measurements to a data medium in CSV format (can be used with MS-Excel)
- load a CSV data file and restore the curves on the oscilloscope diagram
- use certain services

#### Illustration for Lexium 15MH

The screen below can be accessed by clicking on the **Unilink MH** menu's **Tools** → **Oscilloscope**:




## How to start service for Lexium 15MH

The table below explains how to use a service function with a Lexium 15MH:

Step	Action
1	On the field <b>Service</b> , select one of the service functions ( <i>see page 116</i> ) described below.
2	Click on the <b>Parameters</b> button.
3	Set the corresponding parameter.
4	Then start the function by using the <b>Start</b> button.
5	The function will continue to be performed until you click on the <b>Stop</b> button or press the function key <b>F9</b> .

## Illustration for Lexium 15LP

The screen below can be accessed by clicking the folder **Oscilloscope** on the **Unilink L** browser's:



## How to start service for Lexium 15LP

The table below explains how to use a service function with a Lexium 15LP:

Step	Action
1	Click on the <b>Motion Services</b> tab..
2	Select one of the service functions ( <i>see page 116</i> ) described below.
3	Click on the <b>Parameters</b> button.
4	Set the corresponding parameter.
5	Then start the function by using the <b>Start</b> button.
6	The function will continue to be performed until you click on the <b>Stop</b> button.

## Service Functions

The table below explains how to use a service function:

<b>Direct current</b>	Apply a direct current to the motor with adjustable size and electrical field-vector angle. The changeover from speed control to current control is made automatically, commutation is made independently of the feedback (resolver or similar). The rotor locks onto a stator pole.
<b>Speed</b>	Operates the drive at constant speed. An internal digital setpoint is provided (speed is adjustable).
<b>Torque</b>	Operates the drive with constant current. An internal digital setpoint is provided (current is adjustable). The changeover from speed control to current control is made automatically, commutation is made independently of the feedback (resolver or similar).
<b>Reversing mode</b>	Operates the drive in reversing mode, with separately adjustable speed and reversing time for each direction of rotation.
<b>Motion task</b>	Starts the motion task that is selected in the screen page "Entry of service parameters".
<b>Zero</b>	Function used for feedback setting in conjunction with the positioning phase. This function can only be accessed in OMODE2.

**NOTE:** For further information, please refer to the Unilink software user manual.

**NOTE:** Once the parameters have been correctly set, you are advised to save them in EEPROM and to make a backup copy of them in a file.

---

# ATV 31 Implementation for Motion Function Blocks

# 11

---

## Aim of this Chapter

This chapter presents the implementation of an ATV 31 servodrive according to the methodology (*see page 19*) described in the quick start guide (*see page 13*) with a Lexium 05. It only details the differences and actions for an ATV 31.

## What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
11.1	Adapting the Application to the ATV 31	118
11.2	CANopen Bus Configuration ATV 31	122
11.3	Configuring the ATV 31	124
11.4	Tuning the ATV 31	130

## 11.1 Adapting the Application to the ATV 31

---

### Aim of this Section

This section presents adaptation of the application to the **ATV 31** with an architecture, and hardware and software requirements.

### What's in this Section?

This section contains the following topics:

Topic	Page
Application Architecture with an ATV 31	119
Software Requirements	120
Hardware Requirements	121

## Application Architecture with an ATV 31


### Overview

The proposed architecture is simple and designed to assimilate the implementation principles of motion control.

Other equipment can be added to this realistic architecture in order to manage several axes.

### Illustration

The following figure shows the architecture used in the application that includes an **ATV 31**.



## Software Requirements

### Overview

As regards the software requirements presented in the quick start guide (*see page 113*), PowerSuite is used for configuring and tuning the **ATV 31**.

Powersuite for **Lexium 05** enables on-lining of the axis and guarantees a simple method for configuring the parameters of a **Lexium 05** servodrive. PowerSuite for **ATV 31** does the same, but for an **ATV 31** servodrive.

It is nonetheless possible to go without PowerSuite in certain cases by using the **ATV 31** front panel user interface (*see page 128*).

### Versions

The following table lists the hardware and software versions used in the architecture (*see page 119*), enabling the use of MFBs in Unity Pro.

Hardware	Earliest version of software	Version of firmware
<b>Modicon M340</b>	Unity Pro V4.0	-
<b>ATV 31</b>	PowerSuite for <b>ATV 31</b> V2.00	V1.7 : Entry existing on Unity V3.1 + new MFB profile for V4.0

**NOTE:** ATV31 V1.7 compatible with V1.2 functions.

---

## Hardware Requirements

### References of the Hardware Used

The following table lists the hardware used in the architecture (*see page 119*), enabling implementation of **ATV 31** MFBs in Unity Pro.

Hardware	Reference
<b>Modicon M340 PLC</b>	<b>BMX P34 2030</b>
<b>Modicon M340 power supply</b>	<b>BMX CPS 2000</b>
<b>Modicon M340 rack</b>	<b>BMX XBP 0800</b>
CANopen junction box between the <b>Modicon M340</b> and <b>ATV 31</b> servodrive	<b>VW3CANTAP2</b>
PC connection kit	<b>VW3A8106</b>
<b>ATV 31</b> servodrive	<b>ATV31H037M2</b>

**NOTE:** The terminating resistor is integrated in the junction box and must be ON.

# 11.2 CANopen Bus Configuration ATV 31

## Configuration of the CANopen Slave (ATV 31) on CANopen bus



### Overview


The implementation methodology for a CANopen bus using Modicon M340 is to:

- configure (see page 31) the CANopen port of the CPU,
- declare the slave chosen from the hardware catalog (see paragraph bellow),
- configure the slave,
- enable the configuration using Unity Pro,
- check (see page 34) the CANopen bus in the Project browser.

### How to Configure the CANopen Slave

This table describes the procedure to configure the CANopen slave.

Step	Action
1	<p>In the Unity Pro <b>Project Browser</b>, fully expand the <b>Configuration</b> directory and then double-click on <b>CANopen</b>.</p> <p><b>Result:</b> The CANopen window appears:</p> 
2	<p>Select <b>Edit</b> → <b>New device</b>.</p> <p><b>Result:</b> The New Device window appears:</p> 

Step	Action
3	Set 4 in Topological Address. For the slave device choose ATV31_V1_2.
4	Click on OK to confirm the choice. <b>Result:</b> The CANopen window appears with the new device selected:  The screenshot shows a window titled 'CANopen'. At the top, there is a 'Bus:' dropdown menu set to 'CANopen.com1/thead.01.M' and a 'Connections configured: 1' indicator. The main area displays a network diagram with several nodes. One node is highlighted with a red border and contains a 3D image of an ATV31_V1_2 motor drive. The node is labeled '4' and has a small icon next to it. The motor drive image is labeled 'ATV31_V1_2' at the bottom.
5	Select <b>Edit</b> → <b>Open module</b> . If MFB has not already been selected, choose it in the Function area.
6	You will be asked to validate your modifications when closing the Device and CANopen windows.

## 11.3                    **Configuring the ATV 31**

---

### **Aim of this Section**

This section describes the basic servodrive configurations using PowerSuite for **ATV 31** and the servodrive's front panel user interface.

### **What's in this Section?**

This section contains the following topics:

<b>Topic</b>	<b>Page</b>
Configuring the ATV 31 in PowerSuite	125
Configuring the ATV 31 with the User Interface	128

## Configuring the ATV 31 in PowerSuite

### Overview


With PowerSuite, users can define installed device bases, and describe their associated configurations and communication settings.

PowerSuite then gives access to a group of actions for editing or transferring the configurations and for connecting to the devices.

PowerSuite's navigation principle associates a configuration interface with each device type, making it possible to control, tune and monitor them.


### Connecting to the ATV 31


This table describes the procedure for connecting to the **ATV 31**:

Step	Action
1	Connect your PC, on which PowerSuite for <b>ATV 31</b> is installed, to the <b>RJ45</b> connector on the servodrive to be configured.
2	Start PowerSuite for <b>ATV 31</b> , <b>Result:</b> the following start-up screen is displayed: 
3	Choose <b>Action</b> and then <b>Connect</b> . <b>Result:</b> a text box is displayed.
4	Type a project name (ATV31_MFB) and then click on <b>OK</b> . <b>Result:</b> a transfer confirmation window is displayed.
5	Press <b>Alt F</b> to start transferring data from the servodrive to the connected work station.

## Basic ATV 31 Configuration

This table describes the procedure for entering basic settings:

Step	Action
1	<p>Following a connection and transfer of the device's configurations, PowerSuite displays a configuration screen in a new window that gives access to device control, tuning and monitoring functions.                      Use the command <b>Display</b> → <b>Configuration</b>.                      In the tree structure displayed, choose <b>Communication</b> in the <i>Communication</i> directory.  <b>Result:</b> the following window is displayed:</p> 
2	<p>In the <b>ADCO</b> line, the CANopen address must be set to 4.</p>

Step	Action
3	In the <b>BDCO</b> line, the CANopen bus speed must be set to 500.
4	<p>Close the window to disconnect.</p> <p><b>Note:</b> it is possible to adjust the servodrive's settings with the same procedure.</p> <p><b>Result:</b> the following screen is displayed, showing the data saved locally:</p>  <p>The screenshot shows the Powersuite software interface. The left pane displays a tree view with the following structure:</p> <ul style="list-style-type: none"> <li>My devices       <ul style="list-style-type: none"> <li>ATV31_MFB           <ul style="list-style-type: none"> <li>Serial point-to-point</li> <li>Serial multidrop</li> </ul> </li> </ul> </li> <li>My configurations       <ul style="list-style-type: none"> <li>Altivar drives           <ul style="list-style-type: none"> <li>ATV31               <ul style="list-style-type: none"> <li>ATV31_MFB</li> </ul> </li> </ul> </li> </ul> </li> <li>Connections       <ul style="list-style-type: none"> <li>Serial point-to-point</li> <li>Serial multidrop</li> <li>Eth. bridge point-to-point</li> <li>Eth. bridge multidrop</li> <li>Ethernet Modbus/TCP</li> </ul> </li> </ul> <p>The main display area shows the configuration for <b>ATV31_MFB</b>. The sections are:</p> <ul style="list-style-type: none"> <li><b>Characteristics</b> <ul style="list-style-type: none"> <li>DEVICE: ATV31 H037M2</li> <li>Reference: Product on heatsink</li> <li>Hardware type: Europe</li> <li>Range: 0.37kW 0.5HP</li> <li>Nominal power: 220/240 single phase</li> <li>Supply voltage: 3.3 A</li> <li>Continuous output current: 5A</li> <li>Max. transient current: 5A</li> </ul> </li> <li><b>Structure</b> <ul style="list-style-type: none"> <li>DEVICE           <ul style="list-style-type: none"> <li>Serial number: XXX43E009909</li> <li>Version: V1.2IE03</li> <li>Vendor name: TELEMECANIQUE</li> </ul> </li> <li>Control board           <ul style="list-style-type: none"> <li>Serial number: Unknown</li> <li>Version: V1.2IE03</li> </ul> </li> <li>HMI board           <ul style="list-style-type: none"> <li>Version: V1.1IE02</li> </ul> </li> </ul> </li> <li><b>Configuration</b> <ul style="list-style-type: none"> <li>Configurations           <ul style="list-style-type: none"> <li>conf1: ATV31 ATV31_MFB ATV31H037M2</li> </ul> </li> </ul> </li> </ul> <p>A small image of a cat is visible on the right side of the main display area.</p>

## Configuring the ATV 31 with the User Interface


### Overview

A user interface is integrated in the **ATV 31**. With this interface, you can:

- put the device online
- configure the device
- carry out a diagnostic


### Interface Menu Structure






The following graphic presents an overview of access to the interface's main menus:



### Basic Settings

The following table describes the procedure for entering basic settings (CANopen address and speed) with the interface.

Step	Action
1	Press the <b>ENT</b> button on the interface. <b>Result:</b> the <b>SET</b> (Setting) menu is displayed on the interface's status indicator.
2	Press the  button several times to access the <b>COM</b> menu. <b>Result:</b> the <b>COM</b> (Communication) menu is displayed on the interface's status indicator.
3	Press the <b>ENT</b> button on the interface. <b>Result:</b> the <b>COAD</b> (CANopen Address) submenu is displayed on the interface's status indicator.

Step	Action
4	Press <b>ENT</b> again. <b>Result:</b> a value corresponding to the device's CANopen address is displayed.
5	Press the  button to decrease, or the  button to increase the CANopen address value. Press <b>ENT</b> when the desired CANopen address is displayed (4). <b>Result:</b> the value is confirmed and the <b>COAD</b> (CANopen Address) submenu is displayed again.
6	Press the  button to access the <b>COBD</b> (CANopen Baud) submenu. Press <b>ENT</b> . <b>Result:</b> a value corresponding to the device's CANopen speed is displayed.
7	Press the  button to increase, or the  button to decrease the CANopen baud rate value. Press <b>ENT</b> when the desired CANopen speed is displayed (500). <b>Result:</b> the value is confirmed and the <b>COBD</b> (CANopen Baud) submenu is displayed again.
8	Press <b>ESC</b> several times to return to the main display ( <b>RDY</b> by default).

# 11.4 Tuning the ATV 31



## Tuning the ATV 31 with PowerSuite

### In Advance

We recommend tuning the axis kinematic before the program automatically starts it.

### Tuning Example

The following table gives an example of kinematic tuning:

Step	Action
1	Connect (see page 125) to the <b>ATV 31</b> .
2	<p>After a connection and transfer of the device's configurations, PowerSuite opens a new window with the configuration screen, which gives access to device control, tuning and monitoring functions.</p> <p>The following figure shows part of the new window. This lower window provides access to <b>ATV 31</b> command functions:</p> 
3	Place the <b>Command</b> zone cursor on <b>Active</b> .
4	Click the <b>Reset</b> button to clear any problems (if status is red).
5	Enter the value 1 in the <b>Frequency reference</b> zone.
6	<p>Click the <b>Test Run</b> button.</p> <p><b>Result:</b> the motor runs and the sub-window is animated:</p> 
7	Place the <b>Command</b> zone cursor on <b>Inactive</b> once tuning has been finalized.

---

# ATV 71 Implementation for Motion Function Blocks

# 12

---

## Aim of this Chapter

This chapter presents the implementation of an ATV 71 servodrive according to the methodology (*see page 19*) described in the quick start guide (*see page 13*) with a Lexium 05. It only details the differences and actions for an ATV 71.

## What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
12.1	Adapting the Application to the ATV 71	132
12.2	CANopen Bus Configuration ATV 71	136
12.3	Configuring the ATV 71	139
12.4	Tuning the ATV 71	145

## 12.1                    **Adapting the Application to the ATV 71**

---

### **Aim of this Section**

This section presents adaptation of the application to the **ATV 71** with an architecture, and hardware and software requirements.

### **What's in this Section?**

This section contains the following topics:

<b>Topic</b>	<b>Page</b>
Application Architecture with an ATV 71	133
Software Requirements	134
Hardware Requirements	135

## Application Architecture with an ATV 71


### Overview

The proposed architecture is simple and designed to assimilate the implementation principles of motion control.

Other equipment can be added to this realistic architecture in order to manage several axes.

### Illustration

The following figure shows the architecture used in the application that includes an **ATV 71**.



## Software Requirements

### Overview

As regards the software requirements presented in the quick start guide (*see page 13*), PowerSuite is used for configuring and tuning the **ATV 71**.

PowerSuite for Lexium 05 enables on-lining of the axis and guarantees a simple method for configuring the parameters of a **Lexium 05** servodrive. PowerSuite for **ATV 71** does the same, but for an **ATV 71** servodrive.

It is nonetheless possible to go without PowerSuite in certain cases by using the **ATV 71** front panel user interface (*see page 143*).

### Versions

The following table lists the hardware and software versions used in the architecture (*see page 133*), enabling the use of MFBs in Unity Pro.

Hardware	Earliest version of software	Version of firmware
<b>Modicon M340</b>	Unity Pro V4.0	-
<b>ATV 71</b>	PowerSuite for <b>ATV 71</b> V2.00	Compatible since V1.1, V 1.7 managed by MTM

## Hardware Requirements

### References of the Hardware Used

The following table lists the hardware used in the architecture (*see page 133*), enabling implementation of **ATV 71** MFBs in Unity Pro.

Hardware	Reference
<b>Modicon M340</b> PLC	<b>BMX P34 2030</b>
<b>Modicon M340</b> power supply	<b>BMX CPS 2000</b>
<b>Modicon M340</b> rack	<b>BMX XBP 0800</b>
CANopen junction box between the <b>Modicon M340</b> and <b>ATV 71</b> servodrive	<b>VW3CANTAP2</b>
RJ45 programming cable with RS485/RS232 adapter between the junction box and servodrive	<b>ACC2CRAAEF030</b>
<b>ATV 71</b> servodrive	<b>ATV71H075N2Z</b>

**NOTE:** The terminating resistor is integrated in the junction box and must be ON.

## 12.2 CANopen Bus Configuration ATV 71

---

### Configuration of the CANopen Slave (ATV 71) on CANopen bus



#### Overview


The implementation methodology for a CANopen bus using Modicon M340 is to:

- configure (*see page 31*) the CANopen port of the CPU,
- declare the slave chosen from the hardware catalog (*see paragraph bellow*),
- configure the slave,
- enable the configuration using Unity Pro,
- check (*see page 34*) the CANopen bus in the Project browser.

## How to Configure the CANopen Slave

This table describes the procedure to configure the CANopen slave.

Step	Action
1	<p>In the Unity Pro <b>Project Browser</b>, fully expand the <b>Configuration</b> directory and then double-click on <b>CANopen</b>.</p> <p><b>Result:</b> The CANopen window appears:</p> 
2	<p>Select <b>Edit</b> → <b>New device</b>.</p> <p><b>Result:</b> The New Device window appears:</p> 
3	<p>Set 5 in Topological Address.</p> <p>For the slave device choose ATV71_V1_1.</p>

Step	Action
4	<p>Click on OK to confirm the choice.  <b>Result:</b> The CANopen window appears with the new device selected:</p>  <p>The screenshot shows a window titled 'CANopen'. At the top, there is a status bar with 'Bus: 3', a dropdown menu showing 'CANopen comm head 01.00', and 'Connections configured: 1'. The main area displays a network diagram with several nodes. One node is highlighted with a larger, detailed image of an 'ATV71 VLS' motor module, indicating it is the selected device.</p>
5	<p>Select <b>Edit → Open module</b>.                      If MFB has not already been selected, choose it in the Function area.</p>
6	<p>You will be asked to validate your modifications when closing the Device and CANopen windows.</p>

---

## 12.3      **Configuring the ATV 71**

---

### **Aim of this Section**

This section describes the basic servodrive configurations using PowerSuite for **ATV 71** and the servodrive's front panel user interface.

### **What's in this Section?**

This section contains the following topics:

<b>Topic</b>	<b>Page</b>
Configuring the ATV 71 in PowerSuite	140
Configuring the ATV 71 with the User Interface	143

## Configuring the ATV 71 in PowerSuite

### Overview


With PowerSuite, users can define installed device bases, and describe their associated configurations and communication settings.

PowerSuite then gives access to a group of actions for editing or transferring the configurations and for connecting to the devices.

PowerSuite's navigation principle associates a configuration interface with each device type, making it possible to control, tune and monitor them.


### Connecting to the ATV 71


This table describes the procedure for connecting to the **ATV 71**:

Step	Action
1	Connect your PC, on which PowerSuite for <b>ATV 71</b> is installed, to the <b>RJ45</b> connector on the servodrive to be configured.
2	Start PowerSuite for <b>ATV 71</b> , <b>Result:</b> the following start-up screen is displayed: 
3	Choose <b>Action</b> and then <b>Connect</b> . <b>Result:</b> a text box is displayed.
4	Type a project name (ATV71_MFB) and then click on <b>OK</b> . <b>Result:</b> a transfer confirmation window is displayed.
5	Press <b>Alt F</b> to start transferring data from the servodrive to the connected work station.

## Basic ATV 71 Configuration

This table describes the procedure for entering basic settings:

Step	Action
1	<p>Following a connection and transfer of the device's configurations, PowerSuite displays a configuration screen in a new window that gives access to device control, tuning and monitoring functions.</p> <p>In the tree structure displayed, choose <b>Communication</b> in the <i>Communication</i> directory.</p> <p><b>Result:</b> the following window is displayed:</p> 
2	<p>In the <b>ADCO</b> line, the CANopen address must be set to 5.</p>

Step	Action																														
3	<p>In the <b>BDCO</b> line, the CANopen bus speed must be set to 500.  <b>Note:</b> it is possible to adjust the servodrive's settings with the same procedure.</p>																														
4	<p>Once the settings have been adjusted, use the command <b>Configuration</b> → <b>Disconnect</b> to disconnect.  <b>Result:</b> the following screen is displayed, showing the data saved locally:</p>  <p>The screenshot shows the PowerSuite application window. On the left is a tree view under 'My devices' with 'ATV71' selected. The main area displays 'ATV71' and its characteristics:</p> <table border="1" data-bbox="696 527 875 695"> <thead> <tr> <th>Reference</th> <td>ATV71H075N4Z</td> </tr> </thead> <tbody> <tr> <td>Nominal Power</td> <td>0,75kW</td> </tr> <tr> <td>Supply Voltage</td> <td>380/480 V1-</td> </tr> <tr> <td>Maximum transient current</td> <td>3,5 A</td> </tr> <tr> <td>Continuous output current</td> <td>2,3 A</td> </tr> </tbody> </table> <p>Below this is a 'Structure' table:</p> <table border="1" data-bbox="696 782 1053 922"> <thead> <tr> <th>Card</th> <th>Reference</th> <th>Serial number</th> <th>Version</th> <th>Vendor name</th> </tr> </thead> <tbody> <tr> <td>Device</td> <td>ATV71H075N4</td> <td>9217821317921431</td> <td>V1.1IE01</td> <td>Telemecanique</td> </tr> <tr> <td>Control Board</td> <td>Control part-number</td> <td>02461310245256</td> <td>V1.1IE01</td> <td>Telemecanique</td> </tr> <tr> <td>Motor</td> <td>Power part-number</td> <td>2211280153</td> <td>V1.1IE01</td> <td>Telemecanique</td> </tr> </tbody> </table> <p>At the bottom, the 'Configuration(s)' section shows:</p> <p>Name: ATV71  Software release: V1.1IE01</p> <p>The screenshot also shows a small image of the 'Altivar 71' servodrive unit.</p>	Reference	ATV71H075N4Z	Nominal Power	0,75kW	Supply Voltage	380/480 V1-	Maximum transient current	3,5 A	Continuous output current	2,3 A	Card	Reference	Serial number	Version	Vendor name	Device	ATV71H075N4	9217821317921431	V1.1IE01	Telemecanique	Control Board	Control part-number	02461310245256	V1.1IE01	Telemecanique	Motor	Power part-number	2211280153	V1.1IE01	Telemecanique
Reference	ATV71H075N4Z																														
Nominal Power	0,75kW																														
Supply Voltage	380/480 V1-																														
Maximum transient current	3,5 A																														
Continuous output current	2,3 A																														
Card	Reference	Serial number	Version	Vendor name																											
Device	ATV71H075N4	9217821317921431	V1.1IE01	Telemecanique																											
Control Board	Control part-number	02461310245256	V1.1IE01	Telemecanique																											
Motor	Power part-number	2211280153	V1.1IE01	Telemecanique																											

## Configuring the ATV 71 with the User Interface

### Overview


A user interface is integrated in the **ATV 71**. With this interface, you can:

- put the device online
- configure the device
- carry out a diagnostic

**NOTE:** There is a more user-friendly graphic display terminal, for instance for diagnosing faults.







### Interface Menu Structure

The following graphic presents an overview of access to the interface's main menus:



## Basic Settings

The following table describes the procedure for entering basic settings (CANopen address and speed) with the interface.

Step	Action
1	Press the <b>ENT</b> button on the interface. <b>Result:</b> the <b>SET</b> (Setting) menu is displayed on the interface's status indicator.
2	Press the  button several times to access the <b>COM</b> menu. <b>Result:</b> the <b>COM</b> (Communication) menu is displayed on the interface's status indicator.
3	Press the <b>ENT</b> button on the interface. <b>Result:</b> the <b>COAD</b> (CANopen Address) submenu is displayed on the interface's status indicator.
4	Press <b>ENT</b> again. <b>Result:</b> a value corresponding to the device's CANopen address is displayed.
5	Press the  button to decrease, or the  button to increase the CANopen address value. Press <b>ENT</b> when the desired CANopen address is displayed (5). <b>Result:</b> the value is confirmed and the <b>COAD</b> (CANopen Address) submenu is displayed again.
6	Press the  button to access the <b>COBD</b> (CANopen Baud) submenu. Press <b>ENT</b> . <b>Result:</b> a value corresponding to the device's CANopen speed is displayed.
7	Press the  button to increase, or the  button to decrease the CANopen baud rate value. Press <b>ENT</b> when the desired CANopen speed is displayed (500). <b>Result:</b> the value is confirmed and the <b>COBD</b> (CANopen Baud) submenu is displayed again.
8	Press <b>ESC</b> several times to return to the main display ( <b>RDY</b> by default).

## 12.4 Tuning the ATV 71



### Tuning the ATV 71 with PowerSuite

#### In Advance

We recommend tuning the axis kinematic before the program automatically starts it.

#### Tuning Example

The following table gives an example of kinematic tuning:

Step	Action
1	Connect ( <i>see page 140</i> ) to the <b>ATV 71</b> .
2	<p>After a connection and transfer of the device's configurations, PowerSuite opens a new window with the configuration screen, which gives access to device control, tuning and monitoring functions.</p> <p>The following figure shows part of the new window. This lower window provides access to <b>ATV 71</b> command functions:</p> 
3	Place the <b>Command</b> zone cursor on <b>Active</b> .
4	Click the <b>Reset</b> button to clear any problems.
5	Enter the value 10 in the <b>Frequency reference</b> zone.
6	<p>Click the <b>Test Run</b> button.</p> <p><b>Result:</b> the motor runs and the sub-window is animated:</p> 
7	Place the <b>Command</b> zone cursor on <b>Inactive</b> once tuning has been finalized.



---

# IclA Implementation for Motion Function Blocks

# 13

---

## Aim of this Chapter

This chapter presents the implementation of an IclA servodrive according to the methodology (*see page 19*) described in the quick start guide (*see page 13*) with a Lexium 05. It only details the differences and actions for an IclA.

## What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
13.1	Adapting the Application to the IclA	148
13.2	CANopen Bus Configuration IclA	152
13.3	Configuring the IclA	155
13.4	Tuning the IclA	156

## 13.1 Adapting the Application to the IcIA

---

### Aim of this Section

This section presents adaptation of the application to the **IcIA** with an architecture, and hardware and software requirements.

### What's in this Section?

This section contains the following topics:

Topic	Page
Application Architecture with an IcIA	149
Software Requirements	150
Hardware Requirements	151

## Application Architecture with an IcIA


### Overview

The proposed architecture is simple and designed to assimilate the implementation principles of motion control.

Other equipment can be added to this realistic architecture in order to manage several axes.

### Illustration

The following figure shows the architecture used in the application that includes an **IcIA IFS**.



## Software Requirements

### Overview

As regards the software requirements presented in the quick start guide (*see page 13*), IclA Easy is used for configuring and tuning the **IclA**.

PowerSuite for Lexium 05 enables on-lining of the axis and guarantees a simple method for configuring the parameters of a **Lexium 05** servodrive. IclA Easy does the same, but for an **IclA** servodrive.

It is nonetheless possible to go without IclA Easy for basic settings by using the **IclA** switches (*see page 155*), since this is the only way to configure such settings.

### Versions

The following table lists the hardware and software versions used in the architecture (*see page 149*), enabling the use of MFBs in Unity Pro.

Hardware	Earliest version of software	Version of firmware
<b>Modicon M340</b>	Unity Pro V4.0	-
<b>IclA</b>	<b>EasylclA</b> V1.104	<b>IclA IFA</b> compatible since V1.1007 <b>IclA IFE</b> compatible since V1.1007 <b>IclA IFS</b> compatible since V1.1007

## Hardware Requirements

### References of the Hardware Used

The following table lists the hardware used in the architecture (*see page 149*), enabling implementation of **IcIA** MFBs in Unity Pro.

Hardware	Reference
<b>Modicon M340 PLC</b>	<b>BMX P34 2030</b>
<b>Modicon M340 power supply</b>	<b>BMX CPS 2000</b>
<b>Modicon M340 rack</b>	<b>BMX XBP 0800</b>
CANopen SUB-D9-Way female connector (bended at 90° + additional SUB-D9-Way connector to connect a PC on the bus)	<b>TSX CAN KCDF 90TP</b>
CANopen preassembled cordset with moulded female SUB-D9-Way connectors at both end	<b>TSX CAN CADD03</b>
Dongle PCAN PS/2 for IcIA Easy (parallel-to-CAN converter)	<b>IPEH-002019</b>
CANopen cable	<b>TSX CAN CA50</b>
<b>IcIA servodrive</b>	<b>IFS61/2-CAN-DS/-I-B54/0-001RPP41</b>

**NOTE:** The terminating resistor is integrated in the **IcIA** and must be ON (*see page 155*).

## 13.2 CANopen Bus Configuration IclA

---

### Configuration of the CANopen Slave (IclA) on CANopen bus



#### Overview


The implementation methodology for a CANopen bus using Modicon M340 is to:

- configure (*see page 31*) the CANopen port of the CPU,
- declare the slave chosen from the hardware catalog (*see paragraph bellow*),
- configure the slave,
- enable the configuration using Unity Pro,
- check (*see page 34*) the CANopen bus in the Project browser.

#### How to Configure the CANopen Slave

This table describes the procedure to configure the CANopen slave.

Step	Action																																						
1	<p>In the Unity Pro <b>Project Browser</b>, fully expand the <b>Configuration</b> directory and then double-click on <b>CANopen</b>.</p> <p><b>Result:</b> The CANopen window appears:</p> 																																						
2	<p>Select <b>Edit</b> → <b>New device</b>.</p> <p><b>Result:</b> The New Device window appears:</p>  <table border="1" data-bbox="248 678 724 998"> <thead> <tr> <th>Part Number</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>-</td> <td>CANopen drop</td> </tr> <tr> <td>-</td> <td>Discrete</td> </tr> <tr> <td>-</td> <td>Motion</td> </tr> <tr> <td>ATV31_V1_1</td> <td>Altivar31 CANopen Slave DSP402 (TEATV3111E eds)</td> </tr> <tr> <td>ATV31_V1_2</td> <td>Altivar31 CANopen Slave DSP402 (TEATV3112E eds)</td> </tr> <tr> <td>ATV31T_V1_3</td> <td>Altivar31 CANopen Slave DSP402 (TEATV31T13E eds)</td> </tr> <tr> <td>ATV61_V1_1</td> <td>ATV61 (TEATV6111E eds)</td> </tr> <tr> <td>ATV71_V1_1</td> <td>ATV71 (TEATV7111E eds)</td> </tr> <tr> <td>icIA_IFA</td> <td>icIA-FA CANopen (icIA-FA eds)</td> </tr> <tr> <td>icIA_IFE</td> <td>icIA-FE CANopen (icIA-FE eds)</td> </tr> <tr> <td>icIA_IFS</td> <td>icIA-FS CANopen (icIA-FS eds)</td> </tr> <tr> <td>icIA_NO65</td> <td>icIAN065 based on profiles DS301V401 and DSP402_V20 (BUC...</td> </tr> <tr> <td>Lexium05</td> <td>DCX170 CANopen (TEDCX107_0100E eds)</td> </tr> <tr> <td>Lexium05_MFB</td> <td>LXM05A PLCopen (LEXLXM05_MFB EDS)</td> </tr> <tr> <td>Lexium15LP_V1_4</td> <td>EDS for Lexium 15LP servodrive (TELEXM15LP_0142 eds)</td> </tr> <tr> <td>Lexium15MH_V6_6</td> <td>EDS for Lexium 15MHP servodrive (TELEXM15MH_0661E eds)</td> </tr> <tr> <td>Oscoder</td> <td>Oscoder - absolute rotary multium encoders (TEXCCB_0100E eds)</td> </tr> <tr> <td>-</td> <td>Other</td> </tr> </tbody> </table>	Part Number	Description	-	CANopen drop	-	Discrete	-	Motion	ATV31_V1_1	Altivar31 CANopen Slave DSP402 (TEATV3111E eds)	ATV31_V1_2	Altivar31 CANopen Slave DSP402 (TEATV3112E eds)	ATV31T_V1_3	Altivar31 CANopen Slave DSP402 (TEATV31T13E eds)	ATV61_V1_1	ATV61 (TEATV6111E eds)	ATV71_V1_1	ATV71 (TEATV7111E eds)	icIA_IFA	icIA-FA CANopen (icIA-FA eds)	icIA_IFE	icIA-FE CANopen (icIA-FE eds)	icIA_IFS	icIA-FS CANopen (icIA-FS eds)	icIA_NO65	icIAN065 based on profiles DS301V401 and DSP402_V20 (BUC...	Lexium05	DCX170 CANopen (TEDCX107_0100E eds)	Lexium05_MFB	LXM05A PLCopen (LEXLXM05_MFB EDS)	Lexium15LP_V1_4	EDS for Lexium 15LP servodrive (TELEXM15LP_0142 eds)	Lexium15MH_V6_6	EDS for Lexium 15MHP servodrive (TELEXM15MH_0661E eds)	Oscoder	Oscoder - absolute rotary multium encoders (TEXCCB_0100E eds)	-	Other
Part Number	Description																																						
-	CANopen drop																																						
-	Discrete																																						
-	Motion																																						
ATV31_V1_1	Altivar31 CANopen Slave DSP402 (TEATV3111E eds)																																						
ATV31_V1_2	Altivar31 CANopen Slave DSP402 (TEATV3112E eds)																																						
ATV31T_V1_3	Altivar31 CANopen Slave DSP402 (TEATV31T13E eds)																																						
ATV61_V1_1	ATV61 (TEATV6111E eds)																																						
ATV71_V1_1	ATV71 (TEATV7111E eds)																																						
icIA_IFA	icIA-FA CANopen (icIA-FA eds)																																						
icIA_IFE	icIA-FE CANopen (icIA-FE eds)																																						
icIA_IFS	icIA-FS CANopen (icIA-FS eds)																																						
icIA_NO65	icIAN065 based on profiles DS301V401 and DSP402_V20 (BUC...																																						
Lexium05	DCX170 CANopen (TEDCX107_0100E eds)																																						
Lexium05_MFB	LXM05A PLCopen (LEXLXM05_MFB EDS)																																						
Lexium15LP_V1_4	EDS for Lexium 15LP servodrive (TELEXM15LP_0142 eds)																																						
Lexium15MH_V6_6	EDS for Lexium 15MHP servodrive (TELEXM15MH_0661E eds)																																						
Oscoder	Oscoder - absolute rotary multium encoders (TEXCCB_0100E eds)																																						
-	Other																																						

Step	Action
3	Set 6 in Topological Address. For the slave device choose IclA_IFS.
4	Click on OK to confirm the choice. <b>Result:</b> The CANopen window appears with the new device selected:  <p>The screenshot shows a window titled 'CANopen'. At the top, it displays 'Bus: 3', 'CANopen comm head 01.00', and 'Connections configured: 1'. The main area contains a network diagram with a central device labeled '6' and 'IclA_IFS' highlighted. The device is represented by a 3D model of a motor controller. It is connected to a network topology consisting of a vertical line with a circle at the top and a square at the bottom, and a horizontal line connecting the central device to the vertical line.</p>
5	Select <b>Edit</b> → <b>Open module</b> . If MFB has not already been selected, choose it in the Function area.
6	You will be asked to validate your modifications when closing the Device and CANopen windows.

## 13.3 Configuring the IclA


### Configuring the IclA with DIP Switches

#### Overview

The address and baud rate are set with DIP switches on the **IclA IFX** drive.

#### DIP Switches

The following graphic presents the DIP switches inside the drive:



#### Basic Settings

The baud rate is set with the S4 switch on position 5 for a baud rate of 500.

The CANopen address is set with the S1 and S2 switches. Set S2.3 and S2.2 **ON** for the drive to have address 6. By default, as shown in the graphic above, all the switches on S1 and S2 are set **ON** except the first switch on S1, which gives address 127.

Set S3.2 **ON** to activate the terminating resistor.

## 13.4 Tuning the lclA

---

### Aim of this Section

This section gives an example of tuning the **lclA** with lclA Easy.

### What's in this Section?

This section contains the following topics:

Topic	Page
Configuring the lclA in lclA Easy	157
Tuning the lclA with lclA Easy	160

## Configuring the IcIA in IcIA Easy

### Overview

With IcIA Easy, users can define installed device bases, and describe their associated configurations and communication settings.


IcIA Easy then gives access to a group of actions for editing or transferring the configurations and for connecting to the devices.


IcIA Easy's navigation principle associates a configuration interface with each device type, making it possible to control, tune and monitor them.

**NOTE:** The required signals, i.e LIMN, LIMP, REF must be wired or deactivated by the tuning software.

### Connecting to the IcIA


This table describes the procedure for connecting to the **IcIA**:

Step	Action
1	Connect your PC, on which IcIA Easy is installed, to the Dongle PCAN PS/2 connector on the servodrive to be configured.
2	<p>Start IcIA Easy for <b>IcIA</b>.  <b>Result:</b> the following start-up screen is displayed:</p> 

Step	Action
3	<p>Choose the command <b>Connection</b> →<b>CAN Connection</b>. <b>Result:</b> a text box is displayed.</p> 
4	<p>The <b>Baudrate</b> must be set to 500 Kbaud. The <b>CAN address</b> must be set to 6. The <b>Hardware</b> must be set to LPT1 (Dongle PCAN PS/2). <b>Result:</b> a data transfer from the servodrive to the connected work station is begun.</p>

## Basic IcIA Configuration

An example is given to illustrate modification of the acceleration value. This table describes the procedure for entering this setting:

Step	Action
1	Following a connection and transfer of the device's configurations, IcIA Easy displays a screen that gives access to device control, tuning and monitoring functions.
2	<p>Choose the <b>Motion</b> parameter in the <b>Parameter Groups</b>.  <b>Result:</b> the <b>Parameter</b> window is displayed.</p> 
3	In the <b>acc</b> line, the acceleration can be set to 1000.
4	<p>Save the CANopen settings to EEPROM with the command <b>Parameter →Send parameter group to drive</b>.  <b>Note:</b> it is possible to adjust the servodrive's settings with the same procedure.</p>
5	Once the settings have been adjusted, use the command <b>File →Close</b> to disconnect.

## Tuning the IcIA with IcIA Easy

### In Advance

We recommend tuning the axis kinematic before the program automatically starts it.


### Tuning Example

The following table gives an example of kinematic tuning:

Step	Action
1	Connect (see page 157) to the IcIA.
2	The following figure shows part of the new window. This lower window provides access to IcIA command functions: <div data-bbox="477 570 1174 667" data-label="Image"> </div>
3	Click the <b>Reset</b> button to clear any problems.
4	Place the <b>Enable</b> zone cursor on <b>ON</b> .
5	Choose the command <b>Functions</b> → <b>Operating modes</b> . <b>Result:</b> Operating modes windows is displayed.
6	Choose the <b>Speed mode</b> tab Enter the value 200 in the <b>Setpoint value</b> zone. <b>Result:</b> the motor runs and the sub-window is animated: <div data-bbox="477 914 1067 1382" data-label="Image"> </div>
7	Place the <b>Enable</b> zone cursor on <b>OFF</b> once tuning has been finalized.

---

# Index



## C

configuring the application

ATV 31, *117*

ATV 71, *131*

IclA, *147*

Lexium 05, *21*

Lexium 15LP/MP/HP, *99*

Lexium 32, *85*

configuring the axis, *35*

configuring the CANopen bus, *29*

configuring the servodrives

ATV 31, *124*

ATV 71, *139*

IclA, *155*

Lexium 05, *44*

Lexium 15LP/MP/HP, *106*

Lexium 32, *92*

## D

debugging the application, *63*

## M

motion function blocks, *13*

ATV 31, *117*

ATV 71, *131*

IclA, *147*

Lexium 05, *21*

Lexium 15LP/MP/HP, *99*

Lexium 32, *85*

methodology, *19*

quick start, *13*

## O

oscilloscope, *97*

## P

programming the application, *51*

## **R**

recipes, *71*

replacing servodrives, *76*

## **T**

tuning the servodrives

ATV 31, *130*

ATV 71, *145*

IclA, *156*

Lexium 05, *64*

Lexium 15LP/MP/HP, *114*

Lexium 32, *95*