

StruxureWare™ Power Monitoring Expert 8.2

Software Modules – Configuration Guide

7EN42-0148-00

03/2017



Legal Information

The Schneider Electric brand and any registered trademarks of Schneider Electric Industries SAS referred to in this guide are the sole property of Schneider Electric SA and its subsidiaries. They may not be used for any purpose without the owner's permission, given in writing. This guide and its content are protected, within the meaning of the French intellectual property code (Code de la propriété intellectuelle français, referred to hereafter as "the Code"), under the laws of copyright covering texts, drawings and models, as well as by trademark law. You agree not to reproduce, other than for your own personal, noncommercial use as defined in the Code, all or part of this guide on any medium whatsoever without Schneider Electric's permission, given in writing. You also agree not to establish any hypertext links to this guide or its content. Schneider Electric does not grant any right or license for the personal and noncommercial use of the guide or its content, except for a non-exclusive license to consult it on an "as is" basis, at your own risk. All other rights are reserved.

Electrical equipment should be installed, operated, serviced and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

As standards, specifications and designs change from time to time, please ask for confirmation of the information given in this publication.

Safety Information

Important Information

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service or maintain it. The following special messages may appear throughout this bulletin or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a "Danger" or "Warning" safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

Please Note

Electrical equipment should be installed, operated, serviced and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

Contents

Legal Information	2
Safety Information	3
Safety precautions	9
Software Modules	11
Breaker Performance	12
Breaker Aging Configuration Tool	12
Supported devices	12
Setting up the system	13
Adding Circuit Breaker devices	13
Starting the ION software Modbus Gateway service	13
Adding new calculation service provider	13
Adding a new site for the calculation service	15
Adding new device for the calculation service	16
Configuring breaker devices	17
Configuring switchboards	19
Configuring groups	21
Pasting the Circuit Breaker Aging Framework in VIP	23
Opening Vista Diagrams and Linking the Status	24
Circuit Breaker Aging Report	25
Energy Analysis	27
Energy Regression Analysis Report	27
Configure and generate the Energy Regression Analysis Report	27
Energy Billing	31
IT Billing	32
Energy by IT Customer Report	32
Energy by IT Customer Report Example	32
Emergency Power Supply System (EPSS)	34
EPSS configuration overview	35
About Emergency Power Supply System (EPSS)	35
EPSS test sequence of events	35
Generator Performance Configuration Tool with EPSS Test Module	36
Starting the Generator Performance Configuration Utility with EPSS	37
Define EPSS generators	38
Define EPSS transfer switches	47
Define EPSS Equipment	52
Define EPSS groups	53
View EPSS run history	56
Generate EPSS Vista Diagrams	58

EPSS Test Report	63
EPSS Test Report prerequisites	63
EPSS Test Report example	64
Generator Performance	72
Generator Performance Configuration Tool	72
Starting the Generator Performance Configuration Tool	73
Define generators	73
Define equipment	76
Define groups	77
Run History	80
Generator Activity Report	83
Generator Activity Report prerequisites	83
Configuring the Generator Activity Report	84
Generator Activity Report example	85
Generator Battery Health	86
Configure the Battery Health Framework	88
Example Framework	89
Data Acquisition – Data Acqn 1	90
Digital Input – G1 Crank Relay	90
Convert	91
One-Shot Timer	91
First Waveform Recorder – G1 Battery 1	91
Battery Health Waveform Capture results	93
Generator Battery Health Report	93
Prerequisites	94
Generator Battery Health Export	97
Generator Capacity Report	100
Generator Capacity Report prerequisites	101
Configuring the Generator Capacity Report	102
Generator Capacity Report example	102
Generator Load Summary Report	104
Generator Load Summary Report prerequisites	104
Configuring the Generator Load Summary Report	105
Generator Load Summary Report example	106
Generator Test Report	107
Report Prerequisites	107
Power Capacity	109
Branch Circuit Power Report	109
Branch Circuit Power Report example	109
Generator Power Configuration Utility	110
Generator Power configuration restrictions	110

Starting the Generator Power Configuration Utility	111
Defining generator systems	111
Defining generator groups	114
Defining generators	116
Defining generator loads	116
Defining utilities	117
Generator Power Report	118
Generator Power Capacity Report measurements	118
UPS Power Configuration Utility	119
UPS Power configuration restrictions	119
Starting the UPS Power Configuration Utility	120
Defining UPS systems	120
Defining UPS groups	123
Defining UPS modules	124
Defining UPS loads	125
UPS Power Report	126
UPS Power Report Capacity measurements	126
Power Efficiency	128
Power Losses Configuration Utility	128
Power Losses configuration restrictions	129
Define the Power Losses components	129
Defining transformers for Power Losses	130
Defining UPS modules for Power Losses	131
Power Losses Report	132
Power Losses Report measurements	132
Power Usage Effectiveness (PUE) Summary Report	133
Power Quality Advisor	137
Monitoring devices configuration	137
Enable power quality event detection	138
Enable power quality disturbance logging	139
Enabling time synchronization	140
Global parameters configuration	142
Changing the nominal frequency	142
PQ Advisor Diagrams configuration	143
Power Quality Indicator Diagrams configuration	143
Standardized Equipment Diagrams configuration	146
Optional - Creating a PQ Advisor tab in the Web Applications	167
Power Quality Impact Gadgets and Report configuration	168
Acquire process impact signals	168
Setting up process impact alarms	169
Set up Power Quality Groups	171

Power Factor Impact Gadgets configuration	176
Setting up the Power Factor Impact rate file	177
Setting up the incomer meters in the hierarchy	177
Power Quality Analysis Report configuration	179
PQ Advisor dashboards and reports	180
PQ Advisor dashboards	180
Power Quality Advisor Reports	182
Fine-tune PQ Advisor	182
Changing device inclusion and exclusion for the analysis	182
Changing Power Quality Indicator thresholds	185
Changing Power Quality Indicator weight factors	188
Disable unused Power Quality Indicators	189
Disable Flicker, Frequency, Harmonics or Unbalance Indicators	189
Disable Sag, Swell, Interruptions, Transient, or Unbalance Indicators	191
Uninterruptible Power Supply (UPS) Performance	195
Uninterruptible Power Supply (UPS) Auto Test	195
Adding UPS devices to Management Console	195
Configuring UPS groups	195
Generating a Vista diagram	197
Pasting UPS framework in VIP	198
Setting up Vista Diagram status	200
Running a report	200
Uninterruptible Power Supply (UPS) Auto Test Report	200
Uninterruptible Power Supply (UPS) Battery Health Report	201
Configuring the UPS Battery Health Framework	202
Example Framework	203
Data Acquisition – Data Acqn 1	203
One-Shot Timer	203
First Waveform Recorder – G1 Battery 1	203
Configure and generate the UPS Battery Health Report	204
UPS Battery Health Report example	204
Telvent Weather Data Import Service	206
Configuring the data import service	206
Verifying the service is active	210
AccuSine® Power Correction System (PCS) device	212
Configuring the AccuSine PCS device	212
Verifying the device is active	213
Reference	215
ION power meter configuration	215
Supported ION power meters	215
Maintenance and backups	216

Prerequisites	216
Adding ION devices	218
ATS frameworks for EPSS deployment	218
Generator frameworks deployment	228
Non-ION power meter configuration	235
Supported non-ION power meters	235
Prerequisites	235
PM800 series meter configuration	236
CM3000 and CM4000 series meter configuration	254
Configuring Auto-Enable data logs for CM4000 and PM800 series	268
Configuring SER-2408/SER-3200	270
Adding the SER-2408/SER-3200 to Management Console	272
Verify Device Communications in Vista	274
Assign Measurements for Generators or ATS Equipment	275
Interpreting the Energy Regression Analysis Report results	276
Reading the report	277
Interpreting the report	281
Generator system redundancy types	282
UPS system redundancy types	286
UPS Battery Health Report calculations	292
Power Factor Rate File Calculation	293
PQ Advisor - Supported meters	294
PQ Advisor - Supported measurements	296

Safety precautions

During installation or use of this software, pay attention to all safety messages that occur in the software and that are included in the documentation. The following safety messages apply to this software in its entirety.

DANGER

ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices. In the USA, see NFPA 70E.
- Only qualified electrical workers should install this equipment. Read the entire set of instructions before performing this work.
- NEVER work alone.
- Disconnect all sources of electric power before performing visual inspections, tests, or maintenance on this equipment. Assume that all circuits are live until they have been completely de-energized, tested, and tagged. Pay particular attention to the design of the power system.
- Consider all sources of power, including the possibility of backfeeding.
- Turn off all power supplying the power meter and the equipment in which it is installed before working on it.
- Always use a properly rated voltage sensing device to confirm that all power is off.
- Carefully inspect the work area for tools and objects that may have been left inside the equipment before closing all covers and doors.
- Use caution while removing or installing panels so that they do not extend into the energized bus; avoid handling the panels, which could cause personal injury.
- NEVER bypass external fusing.
- Install the power meter in a suitable electrical enclosure.

Failure to follow these instructions will result in death or serious injury.

WARNING

UNINTENDED EQUIPMENT OPERATION

- Only personnel with a thorough understanding of ION architecture and the system in which the meters and software are installed can configure ION modules and registers.
- Do not use meters or the software for critical control or protection applications where human or equipment safety relies on the operation of the control circuit.
- Do not use an ION meter's digital output for any safety critical application.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

WARNING

INACCURATE REPORT RESULTS

- Do not incorrectly configure the devices and software.
- Do not rely solely on reports to determine if the system is functioning correctly or meeting all applicable standards and requirements.
- Use reports as a supplement to proper workplace practices or equipment maintenance, not as a substitute.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

WARNING

INACCURATE DATA RESULTS

Do not install incorrect drivers for the circuit breakers in your system.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

WARNING

POTENTIAL COMPROMISE OF SYSTEM AVAILABILITY, INTEGRITY, AND CONFIDENTIALITY

- Change default passwords to help prevent unauthorized access to device settings and information.
- Disable unused ports and default accounts to help minimize pathways for malicious attackers.
- Place networked devices behind multiple layers of cyber defenses (such as firewalls, network segmentation, and network intrusion detection and protection.)
- Use industry-accepted Information Technology and Operational Technology cyber security practices to help prevent loss or exposure of data, modification or deletion of logs and data, and interruption of services.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

NOTICE

LOSS OF SYSTEM CONFIDENTIALITY / INTEGRITY / AVAILABILITY


Do not store the username and password in a file.

Failure to follow these instructions can result in unauthorized access to, modification of, and unavailability of the system.

Software Modules

In addition to the foundational solution, a set of software modules is available to use with Power Monitoring Expert, and the Data Center and Healthcare Editions (hereafter collectively referred to as Power Monitoring Expert). Depending on your system, these modules enhance the capabilities of Power Monitoring Expert by helping to better manage system equipment, increase power efficiency and capacity, monitor and log data to capture electrical events, and bill tenants.

The following diagram illustrates the software modules that can be used with Power Monitoring Expert:



This guide includes detailed information on how to configure the Power Monitoring Expert software modules.

NOTE: Each software module requires a license to be used. Contact your Schneider Electric representative for more information.

Breaker Performance

The Breaker Performance module lets you manage and report on breaker performance and wear.

The Breaker Performance module includes the following configuration tool and report:

- ["Breaker Aging Configuration Tool" on page 12](#)
- ["Circuit Breaker Aging Report" on page 25](#)

Breaker Aging Configuration Tool

The Breaker Aging Configuration Tool supplies circuit breaker aging and wear data for devices in your system to Power Monitoring Expert. Using this feature, you can monitor and report on the status of circuit breaker aging and wear in your electrical system.

⚠ WARNING
INACCURATE DATA RESULTS Do not install incorrect drivers for the circuit breakers in your system. Failure to follow these instructions can result in death, serious injury, or equipment damage.

Supported devices

The Breaker Aging Configuration Tool in Power Monitoring Expert supports the following devices:

Standard / Country	Circuit Breaker Range	Control Unit Range
IEC	• Masterpact NT • Masterpact NW • Compact NS630b-3200	• Micrologic 2 A/E • Micrologic 5 A/E/P/H • Micrologic 6 A/E/P/H • Micrologic 7 A/P/H
	Micrologic 5.2/6.2/5.3/6.3 A/E	• Micrologic 5 A/E • Micrologic 6 A/E/E-M
China	Compact NS630b-1600	• Micrologic 2 A • Micrologic 5 A • Micrologic 6 A
	Masterpact MT	• Micrologic 2 A • Micrologic 5 A/E/D/P/H • Micrologic 6 A/E/D/P/H • Micrologic 7 A/P/H
	PowerPact H-, J-, and D-Frame	Same as above

Standard / Country	Circuit Breaker Range	Control Unit Range
USA	- Masterpact NT for IEC, UL, and ANSI standards - Masterpact NW for IEC, UL, and ANSI standards - Compact NS630b-3200 - PowerPact H-, J-, and L-Frame	- Micrologic 2 A - Micrologic 3 A - Micrologic 5 A/P/H - Micrologic 6 A/P/H
	PowerPact H-, J-, and D-Frame	Same as above

Setting up the system

Adding Circuit Breaker devices

Add all necessary Circuit Breaker devices to your Power Monitoring Expert system using the Management Console.

For instructions on how to add Circuit Breaker devices to Management Console, see ["Adding the SER-2408/SER-3200 to Management Console" on page 272.](#)


Starting the ION software Modbus Gateway service

1. Open the Windows Services panel by clicking **Start > Administrative Tools > Services**.
2. Make sure that **ION software Modbus Gateway Service** is both enabled and started/running. If the service is not enabled, then start and enable the service.

Description: Enables software data services via Modbus TCP/IP.	ION Site Service	Manages in...	Running	Automatic	Local Syste...
	ION Software Alarm Service	Performs al...	Running	Automatic	Local Syste...
	ION Software Modbus Gate...	Enables soft...	Running	Automatic	Local Syste...
	ION Virtual Processor Service	Provides ag...	Running	Automatic	Local Syste...
	ION Virtual Processor Servic...	Provides ag...	Running	Automatic	Local Syste...

Adding new calculation service provider


1. In Windows Explorer navigate to ... \[Install path] \system\bin and double-click `ModbusServiceConfigurationTool.exe` to run it. The configuration dialog appears.
2. Click **Add**. The **Add Service Window** dialog appears.



3. From **Available Services** select **Breaker Aging Calculation Service**.
4. In **Unit ID** enter a value of 1 if this is the first service provider you are adding. Otherwise, enter the next logical value for Unit ID.

NOTE: If you have already setup the ["Telvent Weather Data Import Service" on page 206](#) and used UNIT ID = 1, then you must enter a unit ID other than 1, (for example, 2).

5. Click **Configure**. The **Breaker Aging Service Configuration** dialog appears. Leave these values as the default.



Real Time Request Polling Interval (in sec): This is the frequency (in seconds) that is used to request real-time meter data for calculations.


Real Time Request Priority Level: This is the level of priority for real-time meter request. The levels are:

Frequency (in seconds)	Priority
0	Low
250	Medium
500	High
1000	Intermediate
5000	Urgent
10000	Control


NOTE: These settings are for advanced users only and may be modified if certain load conditions in the system require that the polling priority and frequency of real-time meter data be decreased or increased.

NOTE: These settings only apply to real-time data requests. These settings only apply to real-time data requests for breaker aging and wear calculations, and are independent of other types of requests in the system (such as VISTA diagrams, Gadgets, and so forth.)

- Click **OK**. The **Breaker Aging Calculation Service** appears in the list.



A dialog appears informing you about the configuration change.




- Click **Yes** to continue and to restart the Modbus Software Gateway Service.

Adding a new site for the calculation service

Add a new site in Management Console that will communicate with the Circuit Breaker Aging Calculation service.

NOTE: These steps are only necessary if you have not yet set up and configured a site for a service (that uses the Modbus Software Gateway Service), such as the **Telvent Weather Data Import Service**. If you have already set up and configured a site for a service, you can ignore the following steps.

- Open **Management Console**. The **Management Console** dialog appears.
- In the left pane, click **Site**.
- Right-click the dialog and choose **New > Ethernet Gateway Site**.
The **Ethernet Gateway Site Configuration** dialog appears. Complete the fields.



The dialog box is titled "Ethernet Gateway Site Configuration". It contains a table with the following fields and values:

Name	BreakerAgingWearSite
TCP/IP Address	STANDALONE
TCP/IP Port	ModbusTCP Device 502
Computer	STANDALONE
Time Synch ION Enabled	No
Time Synch 3XXX Enabled	No
Time Synch 3720 Enabled	No
Enabled	Yes
Description	


Below the table is a text area for "Name" with the instruction "Enter a name to identify the site." At the bottom right are "OK" and "Cancel" buttons.

4. **Name:** Enter **BreakerAgingWearSite**.
5. **TCP/IP Address:** Enter *<your local PME server IP address>*.
6. **TCP/IP Port:** Enter **ModbusTCP Device|502**.
7. **Computer:** Enter *<your local PME server IP address>*.
8. Click **OK**. The new site is created.

Adding new device for the calculation service

Add a new device in Management Console to the new BreakerAgingWearSite that will communicate with the Circuit Breaker Aging Calculation service.

1. Open **Management Console**. The **Management Console** dialog appears.
2. In the left pane, click **Device**.
3. Right-click on the dialog and choose **New > Serial Device on Ethernet Gateway Site**. The **Serial Device Configuration** dialog appears. Complete the fields. Items in red are mandatory.



Items in red are mandatory

Group	BREAKERS
Name	BreakerAgingWearProvider
Device Type	Breaker Aging And Wear Provider
Unit ID	1
Site	BreakerAgingWearSite
Enabled	Yes
Description	

Site
Select the site used to communicate with the device.

OK Cancel


4. **Group:** Enter **BREAKERS**.
5. **Name:** Enter **BreakerAgingWearProvider**.
6. **Device Type:** Enter **Breaker Aging And Wear Provider**.
7. **Unit ID:** Enter the same Unit ID you configured in the Modbus Gateway Service configuration tool.
8. **Site:** Enter the same site name you entered in the configuration tool. Ideally, the site name you enter can be shared for both Breaker Aging and Telvent.
9. **Enabled:** Enter **Yes**.
10. Click **OK**. The new device appears in the list.

Configuring breaker devices

Use the Breaker Aging Configuration Tool to configure breaker devices.

To configure breaker devices:

1. Navigate to the `... \system\bin` folder and then double-click **Breaker Aging Configuration Tool**. If this is the first time you are configuring data, choose the regional setting for circuit breaker and wear library and then click **OK**.



Initial Configuration

Breaker Aging Engine - Region Setting:

IEC
IEC
US
China

Cancel

The **Breaker Aging Configuration Tool** dialog appears.

Breaker Aging Configuration Tool

Breaker Devices | Switchboards | Groups

Help New Delete Revert

Modified	Name	Source
<not set>		

Name: Source:

Range: Designation: Rating:

Control Unit Designation: Control Unit Rating: Voltage:

☒ Is existing breaker device? Default Harmonics Level:

Existing Device Information

Load Rate (Hour)	Number of Trips	Number of Openings
0 - 49%:	DIN:	$I \leq 0.4 \cdot I_n$:
50 - 79%:	Instantaneous:	$0.4 \cdot I_n < I \leq 0.8 \cdot I_n$:
80 - 89%:	Short Time:	$0.8 \cdot I_n < I$:
90 - 100%:	Long Time:	

Harmonics Level:

OK Cancel Apply

2. Click the **Breaker Device** tab, and then click **New** to add one or more breakers to the system. The configuration dialog appears.
3. For each breaker device enter the following information:
 - **Name:** Enter a unique name to identify this breaker in the generated Vista diagrams and the Circuit Breaker Aging report.
 - **Source:** Associate the device that is to provide data for this breaker (such as load values, total harmonic distortion, and so forth). Note that you can only associate each device in the system with one breaker device.
 - Use the dropdown lists to select values for **Range**, **Designation**, **Rating**, and **Control Unit Rating**.
 - **Voltage:** Enter a value.

- Click **Is existing breaker device?** if the breaker device already exists in the system.

NOTICE

UNINTENDED OPERATION

If you select the check box for **Is existing switchboard?**, go to the [PME Exchange Community web site](#) and search for "Is existing switchboard." Open and read the knowledgebase article, and then follow the instructions.

Failure to follow the instructions in the knowledgebase article will result in this feature not functioning as intended.


- If you select this check box, complete the available fields for each existing breaker device.

After you finish adding and configuring all necessary breaker devices, create any switchboards necessary.

Configuring switchboards

To configure the switchboards:

- In Windows Explorer navigate to the `... \system\bin` folder and double-click **Breaker Aging Configuration Tool**. If this is the first time you are configuring data, choose the regional setting for circuit breaker and wear library and then click **OK**.



The **Breaker Aging Configuration Tool** dialog appears.

- Click the **Switchboard** tab, and then click **New** to add one or more Switchboards to the system. The configuration dialog appears.

The screenshot shows the 'Breaker Aging Configuration Tool' window. It has three tabs: 'Breaker Devices', 'Switchboards', and 'Groups'. The 'Switchboards' tab is selected. The window contains several input fields and sections:

- Name:** A text input field.
- Critical Threshold %:** A text input field.
- Moderate Threshold %:** A text input field.
- Breakers:** A list box with 'Select All' and 'Select None' buttons.
- Environmental Conditions:**
 - Switchboard IP:** A dropdown menu.
 - Corrosive Gas:** A dropdown menu.
 - Salty Atmosphere:** A dropdown menu.
 - Dust Level:** A dropdown menu.
- Sensor Data:**
 - Manual:** Selected by default. Includes dropdowns for Vibration Level, Temperature, and Humidity.
 - Monitored:** An unselected radio button. Includes an 'I/O Module:' dropdown and an 'Inside switchboard?' checkbox.
- Is existing switchboard?:** A checked checkbox.
- Existing Switchboard Information:**
 - Vibration Level:** A dropdown menu.
 - Temperature:** A dropdown menu.
 - Humidity:** A dropdown menu.

Buttons at the top right include 'New', 'Delete', and 'Revert'. Buttons at the bottom right include 'OK', 'Cancel', and 'Apply'.

3. For each switchboard enter the following information:

- **Name:** Enter a unique name to identify this switchboard in the generated Vista diagrams and the Circuit Breaker Aging report
- **Critical Threshold %** and **Moderate Threshold %:** Enter default values (0-100%) to be used for each breaker associated with this switchboard when performing analysis of their electrical aging and electrical wear levels.
- **Environmental Conditions:** Use dropdown lists to select values for **Switchboard IP**, **Salty Atmosphere**, **Corrosive Gas**, and **Dust Level**.
- **Sensor Data:** Select one of two modes, and then use the dropdown lists to select values for the parameters.
 - **Manual:** Define static values for humidity, temperature and vibration levels experience in the switchboard.
 - **Monitored:** Associate the switchboard with an optional IO device in the system that is to provide real-time values for humidity, temperature, and vibration levels measured in the switchboard.

NOTE: If you enter a value of "0" (zero), that level is ignored for the calculations.

- **Breakers:** Select one or more breakers from the list. Note that each breaker can be associated with only one switchboard in the system.

4. Click **Is existing switchboard?** if the switchboard already exists in the system.

NOTICE

UNINTENDED OPERATION

If you select the check box for **Is existing switchboard?**, go to the [PME Exchange Community web site](#) and search for "Is existing switchboard." Open and read the knowledgebase article, and then follow the instructions.

Failure to follow the instructions in the knowledgebase article will result in this feature not functioning as intended.

5. If you select this check box, use the dropdown lists to complete the fields for **Vibration Level**, **Temperature**, and **Humidity** for each existing switchboard.


After you finish configuring all existing switchboards, create any groups as necessary.

Configuring groups

Use the Breaker Aging Configuration Tool to configure groups. You must configure groups in order to generate the Circuit Breaker Aging Report.

To configure groups:

1. Navigate to the `... \system\bin` folder and double-click **Breaker Aging Configuration Tool**. If this is the first time you are configuring data, choose the regional setting for circuit breaker and wear library and then click **OK**.



The **Breaker Aging Configuration Tool** dialog appears.


2. Click the **Groups** tab, and then click **New** to add one or more Switchboards to the system. The configuration dialog appears.

The screenshot shows the 'Breaker Aging Configuration Tool' dialog box with the 'Groups' tab selected. The dialog has a title bar with standard Windows window controls. Below the title bar is a tabbed interface with 'Breaker Devices', 'Switchboards', and 'Groups'. The 'Groups' tab is active. At the top of the 'Groups' tab, there is a 'Help' link, a 'Generate Vista Diagrams' button, and 'New', 'Delete', and 'Revert' buttons. Below this is a table with three columns: 'Modified', 'Name', and 'Switchboards'. The table is currently empty. Below the table, there are two input fields: 'Name:' with a text box, and 'Switchboards:' with a list box. The list box has 'Select All' and 'Select None' buttons above it. At the bottom of the dialog are 'OK', 'Cancel', and 'Apply' buttons.

3. For each group enter the following information:
 - **Name:** Enter a unique name to identify this group in the generated Vista diagrams and the Circuit Breaker Aging report
 - **Switchboards** Select one or more switchboards from the list. Note that a switchboard can be used in multiple groups, if necessary.

After you have created all breakers, switchboards, and groups, you can generate a set of optional Vista diagrams.

4. Click the **Groups** tab, and then click **Generate Vista Diagrams**. A **Vista Diagram Generation** configuration dialog appears.



NOTE: The **Output Path** shows the location where the Vista diagram .dgm file is saved after clicking **Generate Vista Diagrams**.

5. Click **Include Custom Logo** and then navigate to and select the file in order to include a custom logo in your diagrams. Otherwise, a Schneider Electric logo appears.
6. Under **Options**, drag the indicator to define the width of Vista diagrams you generate.
7. Click **Generate Vista Diagrams** to generate the .dgm files, then click **OK** and **Close**.

Pasting the Circuit Breaker Aging Framework in VIP

⚠ WARNING

UNINTENDED EQUIPMENT OPERATION

- Only personnel with a thorough understanding of ION architecture and the system in which the meters and software are installed can configure ION modules and registers.
- Do not use meters or the software for critical control or protection applications where human or equipment safety relies on the operation of the control circuit.
- Do not use an ION meter's digital output for any safety critical application.


Failure to follow these instructions can result in death, serious injury, or equipment damage.

1. Open the **Designer** tool and open the **VIP.<servername>**. node.
2. Drag a Grouping Object and open it.


3. Go to ... \config\fmwk\BreakerAging\CB Aging Grouping Status Framework.fwn and select **Edit > Paste** to paste the framework. Depending on the number of Circuit Breakers and groups, you may need to set up the framework.
4. Connect the inputs of each AND/OR module (Circuit Breaker) to the critical operation and battery usage status.
5. Repeat this step for each Circuit Breaker in the group and for all of the Circuit Breakers in the other groups.
6. Save the framework after you finish modifying the framework based on your Circuit Breaker system.

Opening Vista Diagrams and Linking the Status

1. Log in to Vista, select Open File and then browse to ... \config\diagrams\ud\BreakerAging\Groups.dgm.
2. Manually link the status object to the framework you pasted in VIP in the previous steps.
For example:



3. Repeat this step for all other groups. Your Circuit Breaker Monitoring system is now setup.
For example:



NOTE: Any Circuit Breakers in the groups that require attention show a red LED indicator.

- Manually link the status object from the framework you pasted in the VIP in previous steps.

After you finish configuring all circuit breakers, you can configure and generate the Circuit Breaker Aging Report.

Circuit Breaker Aging Report

Use Power Monitoring Expert > Web Applications > Reports to configure and generate the Circuit Breaker Aging Report.

⚠ WARNING

INACCURATE REPORT RESULTS

- Do not incorrectly configure the devices and software.
- Do not rely solely on reports to determine if the system is functioning correctly or meeting all applicable standards and requirements.
- Use reports as a supplement to proper workplace practices or equipment maintenance, not as a substitute.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

To configure and generate the Circuit Breaker Aging Report:

- Complete the fields to define the report:
 - Title** - Enter a name for the report. It appears in the header section of the report.
 - Select Group** - Select a group from the dropdown list to be used for determining which switchboards and breakers are used for the analysis.
 - Grouped By** - Select from the dropdown list to determine how the circuit breaker aging and electrical wear analysis results are sorted.

Switchboard Name first and Threshold Level second - The results are sorted first by the names (in alphabetical order) of all the switchboards associated with the selected group, and then by the criticality level in descending order of importance (Critical, Moderate, Minor).

Threshold Level first and Switchboard Name second - The results are sorted first by criticality level in descending order of importance (Critical, Moderate, Minor), and then by the names (in alphabetical order) of all the switchboards associated with the selected group

- **Include Breakers with Minor Aging and Wear** - Select Yes or No. Selecting Yes allows all of the breakers to appear in the report regardless of the current electrical aging and electrical wear levels. Selecting No allows only breakers with moderate or critical electrical aging and electrical wear to appear.
- **Include Data Warnings** - Select Yes or No.

2. Click **Generate Report** to produce the report.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.

Energy Analysis

The Energy Analysis module lets you understand energy usage patterns to find energy waste, analyze transformer and circuit capacity as configurations change, determine what factors contribute most to energy usage, and assess energy usage by process area or by product output.

The Energy Analysis module consists of the following reports:

- ["Energy Regression Analysis Report" on page 27](#)
- Duration Curve Report ¹
- Energy Usage per State Report ^{1,2}
- Multi Equipment Operation Reports ^{1,2}
- Power Usage per State Report ^{1,2}
- Single Equipment Operation Reports ^{1,2}

¹ For more information on how to use the Energy Analysis reports, see Power Monitoring Expert Web Applications help.

² For more information on how to configure the equipment state reports, see *How to Configure the Energy Analysis Module* on the [PME Exchange Community](#).

Energy Regression Analysis Report

The **Energy Regression Analysis** report lets you analyze building energy systems, monitor energy consumption, and monitor for anomalies or changes in system behavior. Based on the report results, you can perform energy efficiency upgrades or fixes as needed, or model energy data one independent variable at a time with a wide range of desired independent variables.

Configure and generate the Energy Regression Analysis Report

Use the Reports module in Web Applications to configure and generate the Energy Regression Analysis Report.

1. Complete the fields to define the report:
 - **Title** - Enter a name for the report. It appears in the header section of the report.
 - **Driver Data Source** - Select a grouping and single source for the report.
 - **Driver Data Quantity** - Select a grouping and a corresponding single quantity that is used to calculate the values for the X-axis of the Regression Analysis Chart. For example, you can use a weather data source and quantity as the driver for the model you intend to generate.
 - **Model Data Source** - Select a grouping and single source for the report.
 - **Model Data Quantity** - Select a grouping and a corresponding single quantity that is used to calculate the values for the X-axis of the Regression Analysis Chart. For example, you can use a building electrical consumption data source and quantity as the input data for the model you intend to generate.

- **Reporting Period** - Select from the list to specify a period of time for the report that is used to query data from the database for driver and model data. Select the server time from the next dropdown list.
- **Regression Type** - Select Single Line or Broken Line as the type of line to be used in the report.
- **X-Axis Calculation Method** - Select how data is grouped for the X-axis values from these calculation method options: Cooling Degree Days (CDD), Heating Degree Days (HDD), Average (AVG), Sum, and Delta.

Driver quantity data is retrieved differently depending on which calculation method you select:

- **Cooling Degree Days:** All data points within the selected reporting period that are above the Degree Days Pivot Point temperature are retrieved from the database. Any data point at or below the Degree Days Pivot Point temperature is set to 0.
- **Heating Degree Days:** All data points within the selected reporting period that are below the Degree Days Pivot Point temperature are retrieved from the database. Any data point at or above the Degree Days Pivot Point temperature is set to 0.
- **Average:** All data points within the selected reporting period are retrieved from the database.
- **Sum:** All data points within the selected reporting period are retrieved from the database, and values are summed with previous points as they are inserted into the X data table.
- **Delta:** All data points within the selected reporting period are retrieved from the database, and values are calculated by subtracting previous points before inserting them into the X data table.

NOTE: This parameter depends on selecting the Driver Data Quantity parameter. You can select either "Cooling Degree Days" or "Heating Degree Days" only if the driver data is weather temperature data in Celsius or Fahrenheit degrees.

- **Degree Days Pivot Point** - Enter a value in degrees Celsius to define what the base temperature in the heating degree days and cooling degree days calculations. By default, this value is set to 18, which represents 18 degrees Celsius.

NOTE: This parameter depends on selecting the Driver Data Quantity parameter. The units for this value must match the units for the Driver Data Quantity value.

- **Y-Axis Calculation Method** - Select how data is grouped for the Y-axis values from these calculation method options: Average, Sum, and Delta.

Model quantity data is retrieved differently depending on which calculation method you select:

- **Average:** All data points within the selected reporting period are retrieved from the database.
- **Sum:** All data points within the selected reporting period are retrieved from the database, and values are summed with previous points as they are inserted into the Y data table.

- **Delta:** All data points within the selected reporting period are retrieved from the database, and values are calculated by subtracting previous points before inserting them into the Y data table.

NOTE: This parameter depends on selecting the Model Data Quantity parameter. Select **Sum** only if the model data is interval data. Select **Delta** only if the model data is cumulative data.

- **Aggregation Interval** - Select how driver and model data will be combined to be processed from these two options:
 - **Day** - For daily aggregation, the data collected over the designated reporting period is grouped into days, and an average value is taken for each day.
 - **Week** - For weekly aggregation, the data collected over the designated reporting period is grouped into weeks, and an average value is taken for each week.

- **Exclude Incomplete Weeks** - Determines whether or not incomplete sets of data from the report calculations are removed.

When you select **Yes**, any week that does not have a value very close to the start (within the first hour of the first day of the week) and a value very close to the end (within the last hour of the last day of the week) is considered incomplete, and any data for that week will be disregarded.

This parameter depends on the Aggregation Period parameter. This check is only used when you select "Week" for the aggregation period.

- **Exclude Incomplete Days** - Determines whether or not incomplete sets of data from the report calculations are removed.

When you select **Yes**, then any day that does not have at least 80% of the calculated average number of values collected per day is considered incomplete, and any data for that day will be disregarded.

This parameter depends on the X- and Y- Axis Calculation Method parameters. This check is used on both axes when you select "CDD," "HDD," "AVG," or "Sum."

- **Exclude Days with Rollover** - Determines whether or not an incorrect set of data from the report calculations is removed due to a meter register rollover.

When you select **Yes**, then if the absolute value of the data point at the end of the day is greater than the absolute value of the data point at the beginning of the day, rollover has occurred, and any data for that day will be disregarded.

This parameter depends on the Y- Axis Calculation Method parameter. This check is only used on the Y-axis when you select "Delta."

- **Deviation Type** - Allows you to select "Percent" or "Absolute Value" deviation type from the list to specify how the report determines when data exceptions appear in the report charts and tables. These deviations refer to discrepancies in the Y-axis between the ideal regression line and real data points.

There are two deviation types:

- **Percent** - Select "Percent" to specify that the maximum authorized deviation value has percentage units. Exceptions are displayed on the charts and logged in the Exceptions Table for any data points whose Y value falls outside of the designated percent range above or below the ideal regression line. This range will grow as one shifts rightwards along the regression line and Y values become larger.
- **Absolute Value** - Select "Absolute Value" to specify the maximum authorized deviation value has the same units as the Y-axis measurement. Exceptions are displayed on the charts and logged in the Exceptions Table for any data points whose Y value falls outside of the designated value range above or below the ideal regression line. This range will stay constant as one shifts rightwards along the regression line.
- **Max Authorized Deviation** - Enter a value in the field. This parameter depends on what you select for Deviation Type. If you select "Percent," the units for Max Authorized Deviation will be percent. If you select "Absolute Value," the units for Max Authorized Deviation will correspond to the units for the Model Data Quantity.
- **Include Data Warnings** - Select "Yes" to include informational messages related to the report, or "No" to exclude these messages.
- **Include Report Parameters Summary** - Select "Yes" to include a summary of the input parameters at the beginning of the generated report, or select "No" to exclude them.

2. Click **Generate Report** to produce the report.

See ["Interpreting the Energy Regression Analysis Report results" on page 276](#) for information on reading and interpreting the report.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.

Energy Billing

The Energy Billing Module is a fully functional energy-based billing reporting system that consists of the following reports:

- Billing Report
- Billing Summary Report
- Multiple Billing Report
- Multiple Billing Export Report

For more information on how to use the Billing module, see the [Billing Module Toolkit](#) on the PME Exchange Community.

IT Billing

The IT Billing Module provides information on energy usage for use within a data center facility for billing purposes.

The IT Billing Module includes the ["Energy by IT Customer Report" on page 32](#).

NOTE: The IT Billing Module also includes the ["Energy Billing" on page 31](#).

Energy by IT Customer Report

The Energy by IT Customer Report is used by data center operators to generate a report that provides information regarding energy usage for customers within the data center facility.

NOTE: This report requires a license to be used. Contact your Schneider Electric representative for more information.

Use the Energy by IT Customer Report to:

- Troubleshoot your billing system
- Export your billing system (for CSV export)
- Examine customer specific energy usage.

NOTE: For the Energy by IT Customer Report to provide accurate information, devices must be installed, configured, and communicating correctly, the hierarchy must be set up and configured correctly, and the Managed Circuits feature run each time a device configuration change is made. If any of these tasks are not performed correctly, your reports will provide inaccurate information.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.

NOTE: Report output will vary depending on which hierarchy you are using.

Energy by IT Customer Report Example

The Energy by IT Customer Report data depends on the selections you make while configuring the report and the contents of the Power Monitoring Expert or Data Center database.

Peak Demand Timestamp: Calculated by Customer

7/31/2015 12:00:00 AM - 8/7/2015 12:00:00 AM (Server Local)

Customer Summary

Data Warnings
No data warnings.

Customer	Time Range	Energy (kWh)	Peak Demand (kW)	Peak Current (A)	Peak Timestamp
Customer 1	7/31/2015 - 8/7/2015	4,233.6*	25.2	210.0	7/31/2015 12:15:00 AM**

* Value estimated

** Value based on incomplete data

*** Expected value missing

Emergency Power Supply System (EPSS)

The Emergency Supply System (EPSS) Module is a licensable module you can add to Power Monitoring Expert solutions.

Power Monitoring Expert provides data monitoring and logging to capture electrical events and readings. The EPSS module provides the specific tools and reports to help staff at medical facilities manage the power data specifically for EPSS tests or during loss of power from a main utility.

Schneider Electric or Schneider Electric System Integrators generate reports that government and organizational inspectors may view as an aid to help determine if an EPSS is in an adequate state to generate electrical power during a utility outage.

NOTE: A Power Monitoring Expert system supports both Open Transition Transfer (OTT) and Closed Transition Transfer (CTT). By default, the Power Monitoring Expert system is set for OTT. However, if your customer needs to run a CTT test, navigate to the [Power Monitoring Expert Exchange Community](#) web site, in the Install and Maintain section, and then download and run the necessary SQL script.

In addition to the features provided by the base system, the EPSS provides these capabilities:

- **Vista diagrams** – Generates the system Vista diagrams based on the transfer switch and backup generator configuration.
- **Real-time data in Vista** – Diagrams show electrical data, generator status, transfer switch status and electrical data, and fuel management data.
- **EPSS Test Report** – A comprehensive report of load supporting capabilities for the transfer switches, generators, and equipment. You can use this report to evaluate the overall condition of the EPSS.
- **Run history viewer** – Displays Test, Load Shedding, and Power Outage run activities stored in the system history.

WARNING

INACCURATE REPORT RESULTS

- Do not incorrectly configure the EPSS system, this can lead to inaccurate reports and/or data results.
- Do not rely solely on EPSS reports to determine if the EPSS system is functioning correctly or meeting all applicable standards and requirements.
- Use EPSS reports as a supplement to proper workplace practices or equipment maintenance, not as a substitute.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

EPSS configuration overview

To configure Power Monitoring Expert with the EPSS Test module, follow these general steps:

1. Obtain and install a license for the EPSS Test module.
2. Set up the installed ION meters, including ATS and generator frameworks. See ["ION power meter configuration" on page 215](#) for details.
3. Set up the installed non-ION meters, including digital and analog outputs. See ["Non-ION power meter configuration" on page 235](#) for details.
4. Generate and configure Vista diagrams of EPSS equipment. See ["Generating the EPSS Vista diagrams" on page 59](#).
5. Set up reporting entities in the configuration tool. See ["Generator Performance Configuration Tool with EPSS Test Module" on page 36](#).
6. Configure and run the EPSS Test Report. See ["EPSS Test Report" on page 63](#).

Before you start the configuration process, review the following sections to learn more about the EPSS Test module.

About Emergency Power Supply System (EPSS)

An Emergency Power Supply System (EPSS) provides emergency electrical power to any facilities requiring continuous power, 24 hours a day, 7 days a week. Among these facilities are hospitals and medical centers.

In many jurisdictions, hospitals and medical centers need to test their emergency power supply systems on a periodic basis and keep records of such tests. Hospitals and medical centers in the USA, for example, must meet the standards specified by the Joint Commission on Accreditation of Hospital Organizations (JCAHO) to operate their facilities. These standards include the testing of generator systems. These JCAHO standards are derived from both National Fire Protection Association (NFPA) and National Electrical Code (NEC) requirements.

Power Monitoring Expert uses the Generator Performance Configuration Tool with EPSS Test Module to generate reports that government and organizational inspectors may view as an aid to help determine if an EPSS is in an adequate state to generate electrical power during a utility outage. These reports demonstrate compliance not only with the JCAHO standards, but also with the standards mandated by many other geographies, such as:

- National Electric Code Article 220.87 for the United States of America.
- HTM 0601 for the United Kingdom.
- AS/NZS 3009 for Australia and New Zealand.
- 60364-7-710 for Europe.
- CSA Z32 for Canada.

EPSS test sequence of events

The following diagram represents what happens in a backup power system when the power supply system is tested.


The diagram depicts:

- The ATS events Normal, Test, and Emergency along the top.
- The corresponding GEN (generator) events Stop, Start, and Running along the bottom.

These ATS and GEN events are required by the Test Report to execute its logic.

You can use this diagram to identify which events in the power system correspond to the ATS and GEN events represented in the diagram, and to help ensure that the correct signals are wired to the meter's digital inputs.

The diagram also identifies which events are used to control logging of Analog and Load Profile data, shown beginning at GEN Start in the diagram.



Generator Performance Configuration Tool with EPSS Test Module

NOTE: If your installation does not include the EPSS, see ["Generator Performance Configuration Tool" on page 72](#).

Use the Generator Performance Configuration Tool with EPSS Test Module to configure the transfer switches, generators and other equipment to report the data and status of the power system, including EPSS components.

In the configuration tool, you can also generate the Vista diagrams for the configured devices. This feature of the tool produces the diagrams faster than building the diagrams manually. Generated diagrams may still need some adjustment—you can use Vista to finalize the diagrams

After your system is configured using the Generator Performance Configuration Tool with EPSS Test Module, you can use the following generator-related reports:

- Generator Activity Report
- Generator Battery Health Report

- Generator Capacity Report (available for Power Monitoring Expert 8.2 – Healthcare Edition only)
- Equipment Capacity Report (available for Power Monitoring Expert 8.2 – Healthcare Edition only)
- EPSS Test Report (requires a license for the EPSS Module)


Prerequisites

- Before opening the configuration tool, make sure the sources—which represent metering devices—are added in Management Console and they are communicating.

Starting the Generator Performance Configuration Utility with EPSS

To start the Generator Performance Configuration Tool with EPSS Test Module, open the Power Monitoring Expert folder on the desktop and double-click the Generator Performance Configuration Tool shortcut.

The Generator Performance Configuration Tool with EPSS Test Module window contains these tabs: **Groups**, **Generators**, **Transfer Switches**, **Equipment**, and **Run History**. On these tabs, you create the entities and groups for equipment in the system. You also create Vista diagrams and view data for prior test run results. Use the tabs to define new entities or update existing entities.



When you first use the configuration utility, define generators, transfer switches, and other equipment on the applicable tabs. After you do this, define the device groups on the **Groups** tab. The device groups are necessary for reporting and Vista diagrams.

Use the following tabs to configure the tool:

- **Groups** tab - ["Define EPSS groups" on page 53](#)
- **Generators** tab - ["Define EPSS generators" on page 38](#)
- **Transfer Switches** tab - ["Define EPSS transfer switches" on page 47](#)
- **Equipment** tab - ["Define EPSS Equipment" on page 52](#)
- **Run History** tab - ["View EPSS run history" on page 56](#)

Use the following common controls for the tabs:

- **Help** - Click this to view online help for the tab.
- **New** - Creates a new entry in the grid.
- **Delete** - Deletes the selected entry from the grid.
- **Revert** - Returns a modified record to its original values, if **OK** or **Apply** have not been clicked.
- **OK** - Saves all changes and exits the configuration tool.
- **Cancel** - Exits the tool without saving changes.
- **Apply** - Saves all changes and leaves the tool open.

The **Modified** column in the grid area shows the status of the row data:

+ (plus) - a new entry.

* (asterisk) - a modified entry.

! (exclamation mark) - entry needs more information before it can be saved.

Define EPSS generators

Use the **Generators** tab to create or update entities representing the generators in the emergency power supply system. Configure this tab to successfully generate reports for generator data. After you configure the generators, you can generate the Generator Test, Generator Load Summary, Generator Capacity, and the Generator Battery Health reports from this information.

Generator Performance Configuration Tool with EPSS Test Module - Power Monitoring Expert for Healthcare

Groups Generators Transfer Switches Equipment Run History

Help Edit Engine Data New Clone Delete Revert

Modified	Name	Description	Source	Nameplate Rating	Nameplate Unit	Evaluation Method
	Pavillion Gen	Test Auto	PAV.GEN	750	kW	Load
*	Prairie Heart Gen	Test Auto	PHI.GEN	500	kW	Load
	Test Generator	Test Auto	Warp.7650	1	kVA	Load
	Warp Generator	Test Auto	Warp.GeneratorOne	1200	kW	Load

Edit Generator: Prairie Heart Gen

Name:

Description:

Electrical Data

Source:

Prime Nameplate Rating: Unit:

☐ Engine Temperature Data

Source: Unit:

Measurement:

☐ Exhaust Gas Temperature Data

Source: Unit:

☒ Single Exhaust ☐ Dual Exhaust

Measurement:

Evaluation Method

Edit Evaluation Method Load

Engine Data Measurements

Assign Engine Data

Status Measurements

Source:

☐ Starting: Active Value

☐ Running: Active Value

☐ Stopped: Active Value

☐ Monitor for EPS Available? Active Value Req. Time (Seconds)

☐ Battery Waveforms

Source: Measurement:

OK Cancel Apply

You can perform the following actions on this tab:

- Click **New** to define the properties of the generators in the system. See ["Creating EPSS generators" on page 39](#).
- Click **Clone** to define a new generator that is similar to an existing generator. The system copies many details of the existing device into the new entry. You can then enter the unique details of the new device. If you need to define several devices that are similar, this feature can help you define them quickly. See ["Cloning EPSS generators" on page 43](#).
- Click **Delete** to remove records from the system.
- Click **Revert** (before you click **Apply** or **OK**) if you make changes to a record and want to revert to your initial settings.

Creating EPSS generators

The **Edit Generator** area on the tab is used to create a generator entry and to define specific values for it.

To create an EPSS generator:

1. On the **Generator** tab, click **New**.
2. Complete the following fields to define a generator.
 - **Name** - Enter a unique name to identify the generator.
 - **Description** - (Optional) You can add specific information about the generator, such as make and model.

- **Electrical Data**
 - **Source** - Select a source name from the dropdown list. The source represents the device that records the electrical data from the generator.
 - **Prime Nameplate Rating** - Enter the maximum power load for the generator. Refer to the generator's nameplate for this value.
 - **Unit** - Select the unit of measurement for the power load.
- **Engine Temperature Data** - (Optional) To capture engine temperature data, check the box and complete these fields:
 - **Source** - Select a source name. The source represents the device that records the engine temperature of the generator.
 - **Measurement** - Select the engine temperature measurement.
 - **Unit** - Select either F (for Fahrenheit) or C (for Celsius) for the temperature unit of measurement.

NOTE: The Evaluation Method does not convert units from one type to another. Set the Unit type for Engine Temperature Data on the **Generators** tab to the same Unit type in the Evaluation Method.

- Click **Edit Evaluation Method** to open the **Evaluation Method** editor. The **Evaluation Method** editor is used to select the evaluation method and the respective pass/fail criteria that you want to use when evaluating a generator. See ["Editing the EPSS generator evaluation method" on page 44](#).
- Click **Assign Engine Data** to open the **Engine Data Measurements** editor. The **Engine Data Measurements** editor is used to define engine data values and other custom data values for generators. Defining engine data measurements is optional. See ["Editing engine data" on page 45](#).
- Click **Assign Engine Data** to open the **Assign Engine Data Measurement** editor. The **Engine Data Measurement** editor is used to associate engine data values with specific generator measurements. For information about this activity, see ["Assigning engine data" on page 47](#).
- **Exhaust Gas Temperature Data** - (Optional) If exhaust gas data is not being captured, you do not need to select and complete these values. To capture exhaust data, check the box and complete these fields:
 - **Source** - Select a source name. The source represents the device that records the exhaust gas temperature of the generator.
 - **Single Exhaust or Dual Exhaust** - Select one of these options to indicate whether the exhaust gas temperature is measured for a single exhaust or a dual exhaust generator.
 - **Measurement** - Select the exhaust gas temperature measurement.
 - **Unit** - Select either F (for Fahrenheit) or C (for Celsius) for the temperature unit of measurement.

- Click **Edit Evaluation Method** to open the **Evaluation Method** editor. The **Evaluation Method** editor is used to select the evaluation method and the respective pass/fail criteria that you want to use when evaluating a generator. See ["Editing the EPSS generator evaluation method" on page 44](#).
- Click **Assign Engine Data** to open the **Engine Data Measurements** editor. The **Engine Data Measurements** editor is used to define engine data values and other custom data values for generators. Defining engine data measurements is optional. See ["Editing engine data" on page 45](#).
- Click **Assign Engine Data** to open the **Assign Engine Data Measurement** editor. The **Engine Data Measurement** editor is used to associate engine data values with specific generator measurements. For information about this activity, see ["Assigning engine data" on page 47](#).
- **Status Measurements** - Use this area to configure the states used to record the status of a generator. A generator can be in one of three states: **Starting**, **Running**, and **Stopped**. When a generator is in one of the states, the active value is stored in the measurement. The states appear in the **Events Summary** section of the EPSS Test Report.
 - **Source** - Select a source name. The source represents the ION device that records the status of a generator.
 - **Starting** - (Optional) This state indicates that the generator is starting. Select the check box, select the measurement that provides the starting state input, and enter the active value for the measurement. If this setting does not apply to your installation, do not select the check box.
 - **Running** - This state indicates that the generator is running. Select a measurement that provides the running state input, and enter the active value for the measurement.
 - **Stopped** - This state indicates that the generator has stopped. Select a measurement that provides the stopped state input, and enter the active value for the measurement.

NOTE: Two stop signals could be sent from the generator controller – the initial stop signal, which is followed by 3-5 minute cooling period, and the final stop signal after the cooling period is complete. If the generator has two stop signals, be sure to use the measurement for the first stop signal before the generator goes into the cooling mode. Do not use the stop signal after the cooling period.

The active value for the measurements can be any value you choose.

For example, assume that the system has been configured with measurements of `GENStarting`, `GENRunning`, and `GENStopped`. You assign these measurements to the **Starting**, **Running**, and **Stopped** states respectively and enter 1 as the Active Value for each.

- When the generator starts, the active value for `GENStarting` becomes 1, and **Starting** is the state for the generator.
- When the generator is running, the active value for `GENRunning` becomes 1, and **Running** is the state for the generator.

- When the generator stops, the active value for `GENStopped` becomes 1, and **Stopped** is the state for the generator.

When EPSS Test Report is generated, the states for the generator, and the time when they occurred, are included in the **Events Summary** section of the report. See Power Monitoring Expert Web help for information about this report.

Additional notes about the Status Measurements:

If there is only one measurement to indicate that the generator is either running or stopped, then you select that measurement for both the **Running** and **Stopped** states, and assign a different active value for each. For example, if the measurement used to indicate whether a generator is running or not is `GenRunningStopped`, define the states like this:

For the **Running** state:

- a. Select `GenRunningStopped` as the measurement.
- b. Set the Active Value to 1.

When the generator is running, the active value for `GenRunningStopped` is 1, and **Running** is the state for the generator.

For the **Stopped** state:

- a. Select `GenRunningStopped` as the status measurement.
- b. Set the Active Value to 0.

When the generator is stopped, the active value for `GenRunningStopped` is 0, and **Stopped** is the state for the generator.

- **Monitor for EPS Available** - (Optional) This state indicates that the emergency backup source is available.

Select the check box, select the measurement that provides the available state input, and then enter the active value for the measurement. If this setting does not apply to your installation, do not select the check box.

Recommended state is 0 or 1.

- **Required Time (Seconds)** - Enter a value in seconds. The Required Time value specifies the amount of time required to be considered a pass.

NOTE: If you click **Apply** at this point, you can run the EPSS Test Report for date ranges, but not for a run history.

- **Battery Waveforms** - (Optional) Use this area to if you want to configure and generate the Generator Battery Health Report. To enable the report, check the box and complete these fields:
 - **Source** - Select a source name that is performing the waveform capture. This option is only available for ION7550 and ION7650 meters.
 - **Measurement** - Select the measurement recording the battery waveform. For a typical configuration, this is the V4 waveform.

3. Click **Apply** to save the changes and remain on the tab.
4. Repeat these steps to define other generators.
5. If you are defining several similar generators, use the **Clone** button. See ["Cloning EPSS generators" on page 43](#).

Cloning EPSS generators

You can quickly define several similar EPSS generators by cloning the properties of an existing EPSS generator entity and then using those properties as the baseline for multiple EPSS generators.

To clone an EPSS generator:

1. On the **Generators** tab, select the generator you want to use as the baseline for another generator.
 2. Click **Clone** to create a new generator based on a selected entity. Many fields are copied from the selected generator. The fields which are not copied have an information icon to indicate where you need to enter data, as follows:
 - **Name** - Enter a unique name to identify the generator.
 - **Electrical Data - Source** - Select a source name from the dropdown list. The source represents the device that records the electrical data from the generator.
 - **Status Measurements - Source** - Select a source name. The source represents the metering device that records the status of a generator.
- See ["Creating EPSS generators" on page 39](#) for information on generator properties.
3. Click Assign Engine Data to define other engine details for the generator. See ["Assigning engine data" on page 47](#) for details.
 4. Click **Apply** to save the new generator entity.

Editing the EPSS generator evaluation method

The **Evaluation Method** editor is used to select the evaluation method and the respective pass/fail criteria that you want to use when evaluating a generator.

1. Click **Edit Evaluation Method** to open the **Edit Evaluation Method** editor.

Edit Evaluation Method for Main Gen 1

Evaluation Method: Load Bank ✓ Number of Stages: 3

Stage One Criteria
 Suggested Load %: 25 Run Duration (Minutes): 30

Stage Two Criteria
 Suggested Load %: 50 Run Duration (Minutes): 30

Stage Three Criteria
 Suggested Load %: 75 Run Duration (Minutes): 60

Stage One:
 Electrical Load must be at least 25% of the Nameplate Rating for at least 30 minutes.

Stage Two:
 Electrical Load must be at least 50% of the Nameplate Rating for at least 30 minutes.

Stage Three:
 Electrical Load must be at least 75% of the Nameplate Rating for at least 60 minutes.

OK Cancel

2. Complete the following to set up evaluation criteria for a generator:
 - **Evaluation Method** - Select an evaluation method. For **Load Bank**, you can select from one to three stages to include in the evaluation. If you select **Load Bank**, the **Generator Load Summary** section of the EPSS Test Report shows the details of the selected stages of the load bank test. The stages are represented on the graph. The table below describes the evaluation methods.
 - **Number of Stages** - Select the number of stages for the evaluation if you selected **Load Bank**.
 - **Suggested Load %** or **Minimum Exhaust Gas Temperature** - Depending on the evaluation method that you selected, enter a numerical value for the percentage or for the temperature.
 - **Run Duration (Minutes)** - Enter the minimum number of minutes that the test needs to run for evaluation purposes.
3. Click **OK** to save the evaluation criteria and return to the **Generators** tab.

The evaluation methods and their respective pass/fail criteria are listed in the following table. **Load** is the default evaluation method.

Evaluation Method	Pass/Fail Criteria
Load	The generator must run at an electrical load % that is equal to or greater than the manufacturer's suggested electrical load % for the run duration.
Engine Temperature	The generator must run at an engine temperature that is less than or equal to the engine temperature for the duration.
Exhaust Gas Temperature	The generator must run at an exhaust gas temperature that is equal to or greater than the manufacturer's suggested exhaust gas temperature for the run duration.
Load Bank	The generator must pass the stages selected for the electrical load bank test. If more than one stage is selected, the generator must pass each stage consecutively.
Load OR Engine Temperature	The generator must pass either the electrical load or the engine temperature test.
Load OR Exhaust Gas Temperature	The generator must pass either the electrical load or the exhaust gas test.
Load AND Exhaust Gas Temperature	The generator must pass both the electrical load and the exhaust gas test.
Load AND Engine Temperature	The generator must pass both the electrical load and the engine temperature test.
Load OR Engine Temperature OR Exhaust Gas Temperature	The generator must pass either the electrical load or the exhaust gas test or the exhaust gas test.
Load OR Engine Temperature AND Exhaust Gas Temperature	The generator must pass either the electrical load or the engine temperature test and the exhaust gas temperature test.
Load AND Engine Temperature OR Exhaust Gas Temperature	The generator must pass both the electrical load and the engine temperature test OR the exhaust gas temperature test.
Load AND Engine Temperature AND Exhaust Gas Temperature	The generator must pass both the electrical load and the engine temperature test and the exhaust gas temperature test.

You can edit the test criteria for a test method by selecting the test name and then updating its criteria. The following table shows the default test criteria for each evaluation method. Confirm that these values meet the regulations mandated by local jurisdictions, or meet the minimum values recommended by the manufacturer, and update them if necessary.

Test Name	Stage	Minimum	Run Duration
Load	1	30 %	30 minutes
Engine Temperature	1	140 F	30 minutes
Exhaust Gas Temperature	1	900 F	30 minutes
Load Bank	1	25 %	30 minutes
Load Bank	2	50 %	30 minutes
Load Bank	3	75 %	60 minutes

Editing engine data

The **Engine Data Measurements** editor is used to define engine data values and other custom data values for generators. The items being measured, typically analog data, can differ from generator to generator. Battery voltage and coolant temperature are two common measurements.

If you want to use the Trend Report, Tabular Report, EPSS Test Report, and dashboard gadgets, add the engine data values you need.

To add engine data values and other custom data values:

1. Click **Edit Engine Data** to open the **Edit Engine Data Measurements** editor.

Modified	Name	Unit
	Coolant temperature	F
+	Battery voltage	V

Name: Units:

2. Click **New** to enable the input fields.
3. Complete the following to define new data values:
 - **Name** - Enter a name for the data value.
 - **Units** - Enter a unit of measure for the data value.
4. Click **OK** to save the new data value and return to the **Generators** tab.

Next, assign these data values to generator measurements. See ["Assigning engine data" on page 47](#) for instructions.

Assigning engine data

The **Engine Data Measurement** editor is used to associate engine data values with specific generator measurements. See ["Editing engine data" on page 45](#) for instructions to define custom engine data values.

To assign engine data:

1. Click **Assign Engine Data** to open the **Assign Engine Data Measurement** editor.

The screenshot shows the 'Assign Engine Data Measurements for Generator One' dialog box. It contains a table with the following data:

Modified	Engine Data Measurement	Source	Measurement
+	Coolant temperature	EPSS.GEN1	Coolant Temperature
!	Battery voltage	EPSS.GEN1	

Below the table, there are three input fields:

- Engine Data Measurement:** A dropdown menu with 'Battery voltage' selected.
- Source:** A dropdown menu with 'EPSS.GEN1_PM' selected.
- Measurement:** A text field with 'Unassigned' and a red circular icon with an exclamation mark.

There is a checkbox labeled 'Data Collector' which is checked. At the bottom right, there are 'OK' and 'Cancel' buttons.

2. Click **New**.
3. Complete these fields to associate a data value with a specific measurement:
 - **Engine Data Measurement** - Select the data value. The dropdown list contains all of the data values that were configured on the Edit Engine Data Measurements screen.
 - **Source** - Select the device name that records the generator data.
 - **Measurement** - Select the measurement for the data value.
4. Click **OK** to save your changes and return to the **Generators** tab.

Define EPSS transfer switches

Use the **Transfer Switches** tab to configure the automatic transfer switch entities in the system. Complete this tab when you are configuring the EPSS Test Report.

The screenshot shows the 'Generator Performance Configuration Tool with EPSS Test Module - Power Monitoring Expert for Healthcare' window. The 'Transfer Switches' tab is active, displaying a table of transfer switches. Below the table, the 'Edit Transfer Switch: Main TS 1' dialog box is open, showing fields for Name, Description, Priority Level, Required Transfer Time, Status Measurements, and Load Data.

Modified	Name	Description	Source	Priority Level	Required Transfer Time
	Main TS 1	Test Auto Transfer Switch	MAIN.TS_1	Critical	10
	Main TS 10	Test Auto Transfer Switch	MAIN.TS_10	Critical	10
	Main TS 10A	Test Auto Transfer Switch	MAIN.TS_10A	Critical	10
	Main TS 10B	Test Auto Transfer Switch	MAIN.TS_10B	Critical	10
	Main TS 11	Test Auto Transfer Switch	MAIN.TS_11	Critical	10
	Main TS 11A	Test Auto Transfer Switch	MAIN.TS_11A	Critical	10
	Main TS 12	Test Auto Transfer Switch	MAIN.TS_12	Critical	10
	Main TS 12A	Test Auto Transfer Switch	MAIN.TS_12A	Critical	10
	Main TS 12B	Test Auto Transfer Switch	MAIN.TS_12B	Critical	10

Edit Transfer Switch: Main TS 1

Name: Main TS 1

Description: Test Auto Transfer Switch

Priority Level: Critical

Required Transfer Time: 10 seconds

Status Measurements

Source: MAIN.TS_1

Normal: A-S2 Status

Emergency: A-S1 Status

Test: A-S4 Status

Monitor for Power Outage? No Measurement selected.

Load Data

Source: Unassigned

Measurement: Unassigned

Rating: Unit:

You can perform the following actions on this tab:

- Click **New** to create a transfer switch entry and to define specific values for it. See ["Creating EPSS transfer switches" on page 49](#) for instructions.
- Click **Clone** to define a new transfer switch that is similar to an existing entry. The system copies many details of the existing device into the new entry. You can then enter the unique details of the new device. If you need to define several devices that are similar, this feature can help you define them quickly. For more information, see ["Cloning EPSS transfer switches" on page 50](#).
- Click **Delete** to remove records from the system.
- Click **Revert** (before you click **Apply** or **OK**) if you make changes to a record and want to revert to your initial settings.
- Click **Edit Priority Levels** to open the **Priority Levels** editor. The **Edit Priority Levels** editor is used to select at least one priority level that you want to apply to your transfer switches. See ["Editing EPSS transfer switch priority levels" on page 51](#) for instructions.

Creating EPSS transfer switches

The **Edit Transfer Switch** area on the tab is used to create a transfer switch entry and to define specific values for it.

1. Click **New** to create a transfer switch entity.
2. Complete the following to define a transfer switch.
 - **Name** - Enter a unique name to identify the transfer switch.
 - **Description** - optional. Enter other information that you want to use to identify the transfer switch.
 - **Load Data** - Check this box if you want to generate the Equipment Capacity Management Report for the ATS.
 - **Source** - Select a meter source that is recording electrical data from the ATS.
 - **Measurement** - Select the electrical measurement item you want to track when the report is generated, such as Current Phase Average.
 - **Rating** - Enter the rating value for the measurement, such as 400.
 - **Unit** - Enter the unit of measurement, such as A.
 - **Priority Level** - Select a priority level from the dropdown list. You need to assign a priority level to each transfer switch. After you assign a priority level, the required transfer time for it appears under the dropdown list.
 - **Status Measurements** - Configure the states used to record the status of the ATS. When a transfer switch is in one of the states, the active value is stored in the measurement. The states appear in the **Events Summary** section of the EPSS Test Report.
 - **Source** - Select a source name. The source represents the device that records the status of a transfer switch.
 - **Normal** - The ATS is in the Normal position and power is supplied to the load from the utility. Select the measurement that provides the input indicating that the ATS is in the **Normal** state, and then enter the active value for the measurement.
 - **Test** - The ATS is in the Test mode. Select the measurement that provides the input indicating that the ATS is in the **Test** state, and then enter the active value for the measurement.
 - **Emergency** - The ATS is in the Emergency position and power is supplied to the load from the generator. Select the measurement that provides the input indicating that the ATS is in the **Emergency** state, and then enter the active value for the measurement.
 - **Monitor for Power Outage** - If you are monitoring utility power, select this option. Select the measurement that indicates a power outage occurred and enter the **Active Value** for the measurement.

The active value for the measurements can be any value you choose.

For example, assume that the system has measurements called `EPSS_Norm`, `EPSS_Test`, `EPSS_Emerg`, and `EPSS_Util`. You assign these measurements to the **Normal**, **Test**, **Emergency**, and **Power Outage** states and enter 1 as the active value for each.

When the ATS is in the Normal position, the active value for `EPSS_Norm` is 1, and **Normal** is the state for the ATS. When the ATS is set to the Test mode, the active value for `EPSS_Test` is 1, and **Test** is the state for the ATS. When the ATS is in the Emergency position, the active value for `EPSS_Emerg` is 1, and **Emergency** is the state for the ATS. If a power outage occurs, the active value for `EPSS_Util` is 1, and **Power Outage** is the state for the ATS.

In the EPSS Test Report, the states for the ATS and the time when they occurred are included in the Events Summary section.

In the Automatic Transfer Switch Summary section of the report, the states are used to derive the Transfer Time and In Emergency time:

- **Transfer Time** - The duration (in seconds) to switch to the **Emergency** state. For Test mode, the Transfer Time is the time to switch from the **Normal** state to the **Emergency** state once the test signal has been received. When an actual power outage occurs, the Transfer Time is the time to switch from the **Normal** state to the **Emergency** state once the power outage signal has been received.
- **In Emergency** - The duration (in hours, minutes, and seconds) the ATS receives power from the generators. This is the time between the **Emergency** state and the **Normal** state.

3. Click **Apply** to save the changes and remain on the tab.
4. Repeat these steps to define other transfer switches.
5. If you are defining several similar transfer switches, use the **Clone** button. See ["Cloning EPSS transfer switches" on page 50](#).

Cloning EPSS transfer switches

You can define several similar EPSS transfer switches by cloning the properties of an existing EPSS transfer switches entity and then using those properties as the baseline for multiple EPSS transfer switches.

To clone an EPSS transfer switch:

1. On the **Transfer Switches** tab, select the transfer switch you want to use as the baseline for another transfer switch.
2. Click **Clone** to create a new transfer switch based on a selected entity. Many fields are copied from the selected transfer switch. The fields which are not copied have an information icon to indicate where you need to enter data, as follows:
 - **Name** - Enter a unique name to identify the generator.
 - **Status Measurements - Source** - Select a source name.
 - Click **Apply** to save the new transfer switch entity.

Editing EPSS transfer switch priority levels

The **Edit Priority Levels** editor is used to select at least one priority level that you want to apply to your transfer switches.

1. Click **Edit Priority Levels** to open the **Edit Priority Levels** editor.

Modified	Name	Required Transfer Time	Power Outage Enabled	Color
	Critical	10	☒	Red
	Equipment	30	☐	Blue
	Life Safety	10	☒	Orange

Name: Required Transfer Time (Seconds):

☒ Evaluate this Priority Level when reporting on Power Outages ■ 255, 0, 0

OK Cancel

2. Click **New** to add a priority level.
3. Complete the following to define priority levels:
 - **Name** - Enter a unique name to identify the priority level.
 - **Required Transfer Time (Seconds)** - Enter the transfer time in seconds. This value indicates the maximum acceptable time for the ATS to switch from the **Test** state to the **Emergency** state.
 - **Evaluate this Priority Level when reporting on Power Outages** - Select this check box to include a priority level in the pass or fail grading. Clear the check box to exclude the priority level from grading. By excluding a priority level, you can exclude non-critical switches from evaluation.

For example, if a transfer switch has a priority level of Life Safety and it must be graded as a result of a power outage, then select this check box. Conversely, if a transfer switch has a priority level of Equipment, this transfer switch may not have to be graded as a result of a power outage. In this case, clear the check box.
 - **Color Picker** - Select the color that the priority level detail will appear in the test report.

Default priority levels are shown in the following table. You can change any of these to a priority level scheme of your choice.

Name	Required Transfer Time	Power Outage Enabled
Life Safety	10	True
Critical	10	True
Equipment	30	False

4. Click **OK** to save the priority level and return to the **Transfer Switch** tab.

Define EPSS Equipment

Use the **Equipment** tab to create a logical device with a source measurement and rating. You can add these logical devices to device groups for reporting. Complete this tab when you are configuring reports.

The screenshot shows the 'Generator Performance Configuration Tool - Power Monitoring Expert for Healthcare' window. The 'Equipment' tab is selected. The table below lists the equipment records:

Modified	Name	Rating	Unit	Description
*	Equip1	100	kW	
	Equip2	1500	kW	Test Auto
	IONE7650_Meter1	2000	kW	Test Auto
	IONE7650_Meter2	2600	kW	Test Auto
	laurel_North.S1	1000	kW	Test Auto

Below the table is the 'Edit Equipment: Equip1' dialog box. It contains the following fields:

- Name: Equip1
- Description: (empty text area)
- Load Data:
 - Source: EPSS.G1 (selected from dropdown)
 - Measurement: Active Energy Delivered Phase A (selected from dropdown)
 - Rating: 100
 - Unit: kW

Buttons at the bottom of the dialog: OK, Cancel, Apply.

You can perform the following actions on this tab:

- Click **New** to enter new record for a device. See ["Creating EPSS equipment sources" on page 52](#) for instructions to define the devices.
- Click **Clone** to copy an existing record and make minor changes. The system copies many details of the existing device into the new entry. You can then enter the unique details of the new device. If you need to define several devices that are similar, this feature can help you define them quickly.
- Click **Delete** to remove records from the system.
- Click **Revert** (before you click **Apply** or **OK**) if you make changes to a record and want to revert to your initial settings.

Creating EPSS equipment sources

The **Equipment** tab displays the equipment load sources and measurements defined in the system. To create new EPSS equipment sources:

1. Click **New** to create a record.
2. Complete these fields:
 - **Name** - Enter a unique name to identify the record.
 - **Description** - Enter additional information about the device. Optional.
 - **Source** - Select the load source for the device.

- **Measurement** - Select the measurement for the device.
 - **Rating** - Enter the maximum rated load for the device.
 - **Unit** - Enter the unit of the measurement.
3. Click **Apply** to save the record and remain on the tab.
 4. Repeat these steps to enter additional devices.

Define EPSS groups

A performance group is a combination of generators, transfer switches, and other equipment for reporting and generating Vista diagrams. Complete the **Groups** tab when you are configuring reports.

Generator Performance Configuration Tool with EPSS Test Module - Power Monitoring Expert for Healthcare

Groups | Generators | Transfer Switches | Equipment | Run History

Help | Generate Vista Diagrams | New | Delete | Revert

Modified	Group	Test Frequency (Da...	Generators	Transfer Switches	Equipment
	ATS-A Initiated G1,G2,G4,G5	30	G1, G2, G4, G5, G6	TransferSwitch1, TransferSwitch2	Equip1, IONE7650_Meter1, laur...
	ATS-B Initiated G1,G2,G4,G5	30	G2, G4, G5	TransferSwitch2	
	Group1	30	G6		Equip1, Equip2
	Group 12345678901234567...	30	G5, G6, G7	TransferSwitch1	Equip1, Equip2, IONE7650_Meter1, ...
	Grp 2	30	G8, G9		Equip1, Equip2, IONE7650_Meter1, ...
	Grp3	30	G1, G2		Equip1, Equip2, IONE7650_Meter1, ...
	St Johns Prairie Heart	30	Prairie Heart Gen	Prairie Heart TS CC, Prairie Heart TS...	
	St Johns Pavillion	30	Pavillion Gen	Pavillion TS 1, Pavillion TS 2, Pavillion...	

Edit Group: ATS-A Initiated G1,G2,G4,G5

Name: ATS-A Initiated G1,G2,G4,G5

Test Frequency (Days): 30

Load Sources: Blusson.Blusson_incoming_12KV_from_Energy_centre, Blusson.generator, Chiller_1800.600V_main, LAUREL_NORTH.BUS_DUCT_1_2_3_N, LAUREL_NORTH.BUS_DUCT_1_2_3_V, LAUREL_NORTH.BUS_DUCT_4_5_6_N, LAUREL_NORTH.Chiller_1, LAUREL_NORTH.S1, Test:IONE7650_Meter1

Edit Load Sources

Generators: [Select All](#) [Select None](#)

Transfer Switches: [Select All](#) [Select None](#)

Equipment: [Select All](#) [Select None](#)

☒ G1 ☒ G2 ☒ G4 ☒ G5 ☒ G6 ☐ G7 ☐ G8 ☐ G9 ☐ Main Gen 1 ☐ Main Gen 2 ☐ Main Gen 3 ☐ Pavillion Gen ☐ Prairie Heart Gen ☐ Test Generator

☐ Main TS 1 ☐ Main TS 10 ☐ Main TS 10A ☐ Main TS 10B ☐ Main TS 11 ☐ Main TS 11A ☐ Main TS 12 ☐ Main TS 12A ☐ Main TS 12B ☐ Main TS 12C ☐ Main TS 13 ☐ Main TS 14 ☐ Main TS 15 ☐ Main TS 16

☒ Equip1 ☐ Equip2 ☒ IONE7650_Meter1 ☒ IONE7650_Meter2 ☒ laur_North.S1

OK Cancel Apply

You can perform the following actions on this tab:

- Click **New** to create a new group for generating reports and Vista diagrams. A group can contain any device that has been configured on the other tabs. See ["Creating EPSS groups" on page 54](#) for instructions to define the groups.
- Click **Delete** to remove records from the system.
- Click **Revert** (before you click **Apply** or **OK**) if you make changes to a record and want to revert to your initial settings.
- Click the **Edit Load Sources** to associate a group with the electrical loads that the group of generators must carry in a power outage. See ["Editing EPSS group load sources" on page 55](#) for instructions.

- Click **Generate Vista Diagrams** to generate the frameworks for the EPSS groups. You can select which groups to include in the diagrams. See ["Generate EPSS Vista Diagrams" on page 58](#) for instructions.

Creating EPSS groups

The **Groups** tab displays the device groups defined in the system. The generators, and transfer switches, and other equipment must be defined on their respective tabs before you can add them to a group.

To create an EPSS group:

1. Click **New** to create a group.
2. Complete the following to define the values for a group:
 - **Name** - Enter a unique name to identify the group.
 - **Test Frequency** - Select the frequency, in days, that the group should be tested. Refer to local regulations for an appropriate value.
 - **Generators** - Select the generators to include in the group.
 - **Equipment** - Select the equipment to include in the group.
 - **Transfer Switches** - Select transfer switches to include in the group.
The **Select All** and **Select None** options let you work easily with large numbers of sources by selecting all check boxes or clearing all check boxes at the same time.
3. Click **Apply** to save the group and remain on the tab.
4. Repeat these steps to create other groups.

Editing EPSS group priority levels

The following reports use priority levels:

- Generator Capacity Report – Priority level values are required to accurately display the colors indicated in the priority levels.
- EPSS Test Report – Priority level values are required for the ATSS in the system to PASS or FAIL an ATS based on the required transfer time of the priority level.

Default priority levels are setup as default.

The **Edit Priority Levels** editor is used to select at least one priority level that you want to apply to the equipment groups. The default priority level names and transfer times are:

- Critical - 10 sec
- Equipment - 30 sec
- Life Safety - 10 sec

You can change any of these names and transfer times and add new priority levels as necessary.

To edit EPSS group priority levels:

1. Click **Edit Priority Levels**. The **Priority Levels** screen appears.

Modified	Name	Required Transfer Time	Color
	Critical	10	Red
	Equipment	30	Blue
	Life Safety	10	Orange

Name: Required Transfer Time (Seconds):

Color: 255, 0, 0

OK Cancel

2. Click **New** to add a priority level.
3. Complete the following to define priority levels:
 - **Name** - Enter a unique name to identify the priority level.
 - **Required Transfer Time (Seconds)** - Enter the transfer time in seconds. This time indicates the maximum acceptable time it takes the equipment to move from the **Test** state to the **Emergency** state.
 - **Color** - Click the color box to select a color for the priority level. This color appears on the Generator Capacity Report summary page, where the generator loads are compared. See ["Generator Capacity Report example" on page 102](#) for an illustration.
4. Click **OK** to save the priority level and return to the **Groups** tab.

Editing EPSS group load sources

On the **Select Load Sources** screen, you can associate a group with the various electrical loads that the group of generators must carry during a power outage.

Before configuring load sources define the priority levels for the system. See ["Editing EPSS transfer switch priority levels" on page 51](#) for details.

To edit EPSS group load sources:

1. Click **Edit Load Sources**. The **Edit Load Sources** screen appears.

Modified	Source	Measurement	Priority Level
	LAUREL_NORTH.BUS_DUCT_1_2_3_N	Active Power	Critical
	LAUREL_NORTH.BUS_DUCT_1_2_3_V	Active Power	Life Safety
	LAUREL_NORTH.BUS_DUCT_4_5_6_N	100ms Current A	Life Safety
	LAUREL_NORTH.Chiller 1	Active Power	Equipment

Source: LAUREL_NORTH.BUS_DUCT_1_2_3_N

Measurement: Active Power

Priority Level: Critical


2. Click **New** to add a load source.
3. Complete these fields:
 - **Source** - Select the measurement source.
 - **Measurement** - Select the measurement to monitor.
 - **Priority Level** - Select the priority level to assign to the load source.
4. Click **OK** to save the new load source and return to the **Groups** tab.

NOTE: You can use the **Clone** button to associate a group with several sources where the load is logged against the same measurement. The cloned group contains the same measurement and priority level as the original.

View EPSS run history

Use the **Run History** tab to view or modify run activities that represent the Test, Load Shedding, and Power Outage activities that have occurred in the system. The history indicates when components of the EPSS have become active, such as when a generator was running or when a transfer switch entered test or emergency status. The runs stored in history can be used as input for reports and dashboards in Power Monitoring Expert.

Because the system stores the history of these activities, you can generate useful reports about the equipment operation. The reports can identify when the system was active, why the system was active, and what devices were active.



The first time the history records are generated on the **Run History** tab, the system may take a long time depending on the amount of history present in the system. When changes occur in the EPSS configuration, the run history must be generated again.

For example if you remove a generator from a group, the run history for that group needs to be rebuilt because that generator may have been the reason for the detection of a run. Now that the generator is not part of the group, the system needs to build the run history again to have accurate data.

You can perform the following actions on this tab:

- Click **Detection Options** to modify the criteria of a run event that will cause it to appear on this tab. See ["Modifying EPSS run detection options" on page 57](#).
- Click **Refresh Run History** to update the tab with the latest run events that have occurred in the system.
- Click **Delete Run History** to remove all run event records from the tab.
- Modify the name and run reason for a run event. See ["Modifying EPSS run history details" on page 58](#).

Modifying EPSS run detection options


Run detection options can be defined to help guard against bad data in the system. To record actual run activities, you can set the parameters so the system only records runs that fall within the criteria.

The minimum run length value is present to prevent false positives, which may occur during commissioning when the states of the generators and transfers switches are changing quickly and seemingly at random. This may be due to signals being recorded that really do not reflect actual generator or transfer switch activity.

You can set the maximum run length to eliminate "hanging" runs. A hanging run occurs when the stop signal for a generator is not recorded properly. As a result, every time during the test it records a running signal but there is no way for the system to know when it stops. If the system does not see a stop signal, it sets the end of the run to be the start of the run plus the maximum run duration. Therefore you cannot determine how long the generator was actually running.

To define the run criteria for the system to store runs in history:

1. Click **Detection Options**. The **Run Detection Options** screen appears.

A screenshot of the 'Run Detection Options' dialog box. The dialog has a title bar with the text 'Run Detection Options' and a close button (X). Inside the dialog, there are two input fields. The first is labeled 'Minimum Run Length (Minutes):' and contains the value '15'. The second is labeled 'Maximum Run Length (Hours):' and contains the value '48'. At the bottom of the dialog, there are two buttons: 'OK' and 'Cancel'.

2. Change the values in the minimum and maximum fields.
3. Click **OK** to save the changes and return to the **Runs** tab.
4. Click **Refresh** to update the tab with the run events that match the new detection criteria.

Modifying EPSS run history details

The system defines run data, such as name, start time, end time, reason, and active sources automatically. You can change the name of the run event and the reason for the run.

- The default run name is the start date of the run, such as `June 12 2011`. If a group has multiple runs on the same date, the subsequent runs have the same date with the run number appended, such as `June 12 2011 Run 2` and `June 12 2011 Run 3`.
- The system automatically detects the reason for the run. If the detected reason is incorrect, you can change the reason. For example, the reason appears as `Test`, but the run is actually `Load Shedding`.

Other details about the run event cannot be modified directly. If the sources for a run are not correct, you can exclude or include specific sources when generating a report based on this run.

To modify EPSS run history details:

1. Click the run record you want to modify. The run details appear below the grid.
2. In the **Name** field, change the suggested run name as necessary.
3. In the **Reason** list, select the correct reason for the run.
4. Click **OK** to save the changes for the run.

Generate EPSS Vista Diagrams

After the generators, transfer switches, and device groups are configured, you can generate the Vista diagrams for the configured devices. The same information can be built manually in Vista, but the Generator Performance Configuration Tool with EPSS Test Module provides a way to build these diagrams automatically. Vista diagrams help provide you with real time insight into the system.

After the diagrams are generated, you can open them in Vista or Designer and optimize the designs. See ["EPSS Vista diagram examples" on page 61](#) for descriptions and examples of the generated diagrams.

EPSS Vista diagrams are useful to the customer so they can see real-time information about the status of the generators, transfer switches, and other components of the system. The diagrams can include the customer logo and a map of the customer's facility. The customer can view the diagrams in the Diagrams module of Power Monitoring Expert after the diagrams have been linked to the Diagrams module.

The system includes a template that you can use to set up certain parts of the diagrams before you generate them.

Setting up the EPSS template diagram

The template diagram allows you to produce a consistent structure for the generated diagrams. The template file is used as a basis for the dynamically generated EPSS diagrams. The template is a normal diagram file that the system uses to apply common elements to the generated diagrams.

With the template, you can apply linked-button elements to the generated diagrams, which will help you reduce the amount of time to configure the diagrams.

To set up the EPSS template diagram:

1. Open the Vista Diagrams application.
2. Open `...\config\diagrams\ud\EPSS\templates\Epss_Template.dgm`.
3. To the left side of the diagram, add the buttons with the appropriate links.
4. Do not link the EPSS button to any diagram, because you will already be on the EPSS pages when they are generated.
5. Save and close the template diagram.

When the configuration tool generates diagrams, the template is read and any objects on the diagram are added to every diagram created by the tool.

NOTE: On the generated diagrams, the background image is dynamically created. The background does not come from the EPSS template diagram.

Generating the EPSS Vista diagrams

Before you generate the EPSS Vista diagrams, make sure all devices and groups are configured correctly. Save the changes you have made to the EPSS configuration.

To generate the Vista diagrams:

1. Click the **Groups** tab.
2. Click **Generate Vista Diagrams**. The Vista Diagram Generation screen appears.

3. In the **Output Path** field, enter or select the folder where you want to store the diagrams.
4. (Optional) In the **Included EPSS Groups** box, select the device groups that you want to generate diagrams for. Uncheck any groups you do not want to generate.
5. (Optional) In the **Transfer Switch Options** box, select the colors you want to use for normal and emergency status.
6. (Optional) Check the **Include Test Button on Transfer Switches** option if you want to add a control object for each ATS on the diagrams. This object allows you to manually test the ATS from the diagram. The control must be manually linked using Vista once the diagrams have been created.
7. (Optional) Check the **Include Links to EPSS Groups...** option if you want the device diagrams to have a link to the EPSS Group diagram.
8. In the **Diagram Width** field, select the horizontal width in pixels of the diagrams.
9. Select **Facility Logo** and enter the image file if you want the diagrams to include the customer logo at the top-left of every diagram.
10. Select **Generate Facility Map** if you want to include a map with the diagrams. If you do this, you will be able to add the generator and transfer switch device locations to the map.
 - a. Enter the **Facility Name** to appear on the map.
 - b. Select the image file for the map.
11. Click **Generate Vista Diagrams** to generate and store the diagrams in the selected output folder.

Several diagrams will be created: the homepage that lists all EPSS groups, summary pages that list all generators and transfer switches, and the detail pages for each EPSS Group, Generator and ATS in the system.


You can open the diagrams in Vista and optimize the designs if necessary. Refer to *ION Reference* for information about configuring the modules in the diagram.

EPSS Vista diagram examples

When you generate the Vista diagrams, the following diagrams are produced:


Home Page Diagram

One Home Page diagram is generated. This diagram contains a navigation bar that has links for the facility map, device group diagrams, and device diagrams.




EPSS Group Diagram

For each group selected on the configuration screen, one group diagram is produced. This diagram contains an object for each generator or transfer switch in the group. A Oneline diagram for each device group is also generated and linked to the diagrams. You will need to manually configure the generated Oneline diagrams. Several default objects are included for assistance.




Device detail Diagram

For each generator and transfer switch in a group, a diagram is generated. The device diagram includes status information for the device, including run status, test parameters, and real-time electrical data.



Facility Map

This diagram is generated if the option was selected on the configuration screen. This diagram includes a moveable icon for each generator and transfer switch in all the selected device groups. On the map diagram, you can drag and drop the device icons to the map to represent the physical locations of those devices.



EPSS Test Report

The EPSS Test Report shows the run details and overall status for generators and transfer switches in the group. For example, the report shows the transfer time of the lead ATS and indicates whether the transfer time passes or does not pass the test requirements.

Use the Reports module in Web Applications to configure and generate the EPSS Test Report.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.

EPSS Test Report prerequisites

In the Generator Performance Configuration Tool with EPSS Test Module, define the following tabs and fields in order to generate the report.

Generators Tab

- **Name** - Enter a name for the generator entity.
- **Electrical Data** - Enter the measurement source, nameplate rating, and unit of measurement.
- **Status Measurements** - Enter the source of the status measurement and the start, run, and stop values. Configure the meters that provide these measurements.
- **Evaluation Method** - "Load" is default, but you can change this to accommodate customer requirements.

See ["Define EPSS generators" on page 38](#) for instructions on the above settings.

Transfer Switches Tab

- **Name** - Enter a name for the ATS entity.
- **Status Measurements** - Select the source of the status measurement and the start, run, and stop values. Configure the meters that provide these measurements.
- **Priority Levels** - Default levels are provided, however you can change these levels to accommodate customer requirements.

See ["Define EPSS transfer switches" on page 47](#) for instructions on the above settings.

Groups Tab

- **Name** - Enter a name for the group entity.
 - Select at least one entity from the **Generators**, **Transfer Switches**, or **Equipment** lists. The group can contain entities from each list combined.
- See ["Define EPSS groups" on page 53](#) for instructions.

After these required items are defined, the report can be configured and generated.

EPSS Test Report example

The following images are examples of various sections of an EPSS Test Report in the order in which they occur.

Title Page

The title page of the test report shows the title, company name, group, the name of the person preparing the report, and the test period.



For
Park Royal Hospital

EPSS Main East

Prepared By
John Hancock

Test Period
5/3/2010 1:00:00 AM - 5/3/2010 3:00:00 AM (Server Local)

Generated on: 8/5/2010 1:02:33 PM

Page 1 of 2

Sources

The **Sources** section shows the devices in the selected group.

Sources in Report Group: EPSS Main East

Source	Type	Description
ATS 01	Transfer Switch	This is a Life Safety Load ATS Device. Refer to EPSS operating procedure before testing this device.
ATS 02	Transfer Switch	This is a Critical Load ATS Device
ATS 03	Transfer Switch	This is a Non-Essential Load ATS Device
Gen 01	Generator	Cummins generator.

Events Summary

The **Events Summary** section shows the status of the generators and transfer switches in the group.

ATS and Generator Events Summary

Timestamp	Source Name	Status
5/3/2010 1:00:54.24 AM	ATS 01	Test
5/3/2010 1:00:54.54 AM	Gen 01	Start
5/3/2010 1:01:03.04 AM	Prairie Heart Gen	Emergency Power Source Available
5/3/2010 1:01:03.34 AM	ATS 01	Emergency
5/3/2010 1:01:24.24 AM	ATS 02	Test
5/3/2010 1:01:24.54 AM	ATS 02	Emergency
5/3/2010 1:01:46.31 AM	ATS 03	Test
5/3/2010 1:01:46.58 AM	ATS 03	Emergency
5/3/2010 1:59:18.90 AM	ATS 01	Normal
5/3/2010 1:59:19.90 AM	ATS 02	Normal
5/3/2010 1:59:29.89 AM	ATS 03	Normal
5/3/2010 2:06:21.63 AM	Gen 01	Stopped

Automatic Transfer Switch Summary

The **Automatic Transfer Switch Summary** section includes sections for the **Lead ATS**, the **Time to Emergency Power Source Available**, and **All Automatic Transfer Switches** in the group.

Automatic Transfer Switch Summary

Lead ATS

Lead ATS	Transfer Time	Required Transfer Time	Test Status
ATS 01	9.10 s	10 s	PASS

All Automatic Transfer Switches

Transfer Switch	Priority Level	Transfer Time	In Emergency (hh:mm:ss)
ATS 01	Life Safety	9.10 s	00:58:15
ATS 02	Critical	0.30 s	00:57:55
ATS 03	Non-Essential Equipment	0.27 s	00:57:43

Generator Summary

The **Generator Summary** section shows the evaluation method is being used to determine the status of the generator being tested.


Generator Summary		
Generator: Gen 01		Nameplate: 1000 kW
Start Time: 5/3/2010 1:01:03 AM		Stop Time: 5/3/2010 2:06:21 AM
Evaluation Method		Overall Test Status
Load and Exhaust Gas Temperature		PASS
Test	Stage	Test Status
Load	One	PASS
Exhaust Gas Temperature	One	PASS

This example shows the Load Bank evaluation method was used on the generator.


Generator Summary		
Generator: Gen 01		Nameplate: 1000 kW
Start Time: 5/3/2010 1:01:03 AM		Stop Time: 5/3/2010 2:06:21 AM
Evaluation Method		Overall Test Status
Load Bank		FAIL
Test	Stage	Test Status
Load Bank	One	PASS
Load Bank	Two	PASS
Load Bank	Three	FAIL

Generator Load Summary

The **Generator Load Summary** section shows a chart of the electrical load data for the generator being tested.



This is an example showing the Load Bank evaluation method was used.



Longest Continuous Load

This section includes a table summarizing the minimum, average, and maximum electrical readings for the longest continuous load by load bank stages. The following images show data for each stage of the load bank test.

Min, Avg, Max Readings for the Longest Continuous Load				
Generator: Gen 01		Nameplate: 1000 kW		
Start Time: 5/3/2010 1:01:03 AM		Stop Time: 5/3/2010 2:06:21 AM		
Stage One		1:17:00 AM - 1:27:00 AM		
Measurement	Min	Avg	Max	Units
Active Power	355.00	438.90	526.00	kW
Apparent Power	363.00	447.90	537.00	kVA
Current Phase A	449.00	559.60	674.00	A
Current Phase B	421.00	519.70	624.00	A
Current Phase C	434.00	531.20	632.00	A
Voltage Phases AB	482.00	482.00	482.00	V
Voltage Phases AN	278.00	278.00	278.00	V
Stage Two		1:27:00 AM - 1:59:00 AM		
Measurement	Min	Avg	Max	Units
Active Power	514.00	535.33	558.00	kW
Apparent Power	525.00	547.85	578.00	kVA
Current Phase A	659.00	688.82	729.00	A
Current Phase B	608.00	633.79	666.00	A
Current Phase C	619.00	646.12	679.00	A
Voltage Phases AB	482.00	482.00	482.00	V
Voltage Phases AN	278.00	278.06	279.00	V
Voltage Phases BC	482.00	482.03	483.00	V
Voltage Phases BN	278.00	278.03	279.00	V
Voltage Phases CA	482.00	482.03	483.00	V
Voltage Phases CN	278.00	278.03	279.00	V
Stage Three		No Load Found		


Generator Engine Temperature Summary

This example shows the Load AND Engine Temperature AND Exhaust Gas Temperature evaluation method used on the generator.

Generator Summary		
Generator: G1		Nameplate: 100 kW
Start Time: 3/17/2015 7:00:50 AM		Stop Time: 3/17/2015 8:10:45 AM
Evaluation Method		Overall Test Status
Load AND Engine Temperature AND Exhaust Gas Temperature		PASS
Test	Stage	Test Status
Load	One	PASS
Engine Temperature	One	PASS
Exhaust Gas Temperature	One	PASS


Generated on: 3/20/2015 12:35:35 PM Page 5 of 10

This section also includes a chart of the engine temperature readings for the longest continuous load and a table summarizing the minimum, average, and maximum engine temperature readings for the longest continuous load.




Generator Engine Temperature Details

This section shows summarized engine temperature details by time intervals.



Generator Exhaust Gas Summary

This section shows a chart of the exhaust gas temperature data.



Min, Avg, Max Readings for the Longest Continuous EGT

Measurement	Min	Avg	Max	Units
Exhaust Gas Temperature Left	811.03	844.38	888.80	F
Exhaust Gas Temperature Right	803.00	836.02	880.00	F

Generator Exhaust Gas Details

This section shows summarized exhaust gas temperature details by time intervals.

Generator Exhaust Gas Details

Generator: Gen 01

Nameplate: 1000 kW

Start Time: 5/3/2010 1:01:03 AM

Stop Time: 5/3/2010 2:06:21 AM

Timestamp	Exhaust Gas Temperature Left °F	Exhaust Gas Temperature Right °F
5/3/2010 1:02:00 AM	578.73	573.00
5/3/2010 1:03:00 AM	698.92	692.00
5/3/2010 1:04:00 AM	746.39	739.00
5/3/2010 1:05:00 AM	774.67	767.00
5/3/2010 1:06:00 AM	791.84	784.00
5/3/2010 1:07:00 AM	811.03	803.00
5/3/2010 1:08:00 AM	817.09	809.00
5/3/2010 1:09:00 AM	824.16	816.00

Generator Electrical Details

This section shows summarized electrical details by time intervals.

Generator Electrical Details

Generator: Gen 01

Nameplate: 1000 kW

Start Time: 5/3/2010 1:01:03 AM

Stop Time: 5/3/2010 2:06:21 AM

Timestamp	KW	KVA	Load %	VLLAvg	VLNAvg	Frequency
5/3/2010 1:02:00 AM	241.00	266.00	24.10	482.00	278.00	60.07
5/3/2010 1:03:00 AM	276.00	321.00	27.60	481.00	278.00	60.03
5/3/2010 1:04:00 AM	300.00	336.00	30.00	482.00	278.00	60.08
5/3/2010 1:05:00 AM	288.00	315.00	28.80	482.00	278.00	60.06
5/3/2010 1:06:00 AM	286.00	311.00	28.60	482.00	278.00	60.07
5/3/2010 1:07:00 AM	291.00	321.00	29.10	482.00	278.00	60.07
5/3/2010 1:08:00 AM	283.00	315.00	28.30	482.00	278.00	60.08
5/3/2010 1:09:00 AM	289.00	316.00	28.90	482.00	278.00	60.07
5/3/2010 1:10:00 AM	293.00	319.00	29.30	482.00	278.00	60.07
5/3/2010 1:11:00 AM	290.00	316.00	29.00	482.00	278.00	60.08

Generator Engine Details

This section shows engine parameter details, such as battery voltage and oil pressure readings.

Generator Engine Details

Generator: Gen 01

Nameplate: 1000 kW

Start Time: 5/3/2010 1:01:03 AM

Stop Time: 5/3/2010 2:06:21 AM

Measurement	Timestamp	Reading
Battery Voltage (V)	5/3/2010 1:02:00 AM	28.02
	5/3/2010 1:03:00 AM	28.02
	5/3/2010 1:04:00 AM	28.03
	5/3/2010 1:05:00 AM	28.00
	5/3/2010 1:06:00 AM	27.98
	5/3/2010 1:07:00 AM	27.98

Oil Pressure (PSI)		
	5/3/2010 1:02:00 AM	84.91
	5/3/2010 1:03:00 AM	66.36
	5/3/2010 1:04:00 AM	65.05
	5/3/2010 1:05:00 AM	65.05
	5/3/2010 1:06:00 AM	66.43
	5/3/2010 1:07:00 AM	72.86
	5/3/2010 1:08:00 AM	65.76
	5/3/2010 1:09:00 AM	65.03
	5/3/2010 1:10:00 AM	64.93

Generator Performance

To configure Generator Performance:

1. Obtain and install a license for the Generator Performance module.
2. Set up the installed ION meters, including ATS and generator frameworks. See ["ION power meter configuration" on page 215](#) for details.

NOTE: Transfer Switches and Automatic Transfer Switches (ATS) does not apply to data centers. Even though ATS appears in the configuration tool and reports, you can ignore all references to ATS when configuring a data center facility.
3. Set up the installed non-ION meters, including digital and analog outputs. See ["Non-ION power meter configuration" on page 235](#) for details.
4. Set up reporting entities in the configuration tool. See ["Generator Performance Configuration Tool" on page 72](#). If your system includes the ["Emergency Power Supply System \(EPSS\)" on page 34](#), see ["Generator Performance Configuration Tool with EPSS Test Module" on page 36](#).
5. Configure and run the Generator Performance reports.

Generator Performance Configuration Tool

NOTE: If your installation includes the Emergency Power Supply System (EPSS), see ["Generator Performance Configuration Tool with EPSS Test Module" on page 36](#).

Use the Generator Performance Configuration Tool to configure the generators and other equipment to report the data and status of the power system.

After your system is configured using the Generator Performance Configuration Tool, you can use the following generator-related reports:

- Generator Activity Report
- Generator Battery Health Report
- Generator Capacity Report (available for Power Monitoring Expert 8.2 – Healthcare Edition only)
- Equipment Capacity Report (available for Power Monitoring Expert 8.2 – Healthcare Edition only)
- EPSS Test Report (requires a license for the EPSS Module)

Prerequisites

- Before opening the configuration tool, make sure the sources—which represent metering devices—are added in Management Console and they are communicating. See ["ION power meter configuration" on page 215](#) and ["Non-ION power meter configuration" on page 235](#) for details.

Starting the Generator Performance Configuration Tool

To start the Generator Performance Configuration Tool, open the Power Monitoring Expert folder on the desktop and double-click the Generator Performance Configuration Tool shortcut.

The Generator Performance Configuration Tool window contains these tabs: **Groups**, **Generators**, **Transfer Switches**, **Equipment**, and **Run History**. On these tabs, you create the entities and groups for equipment in the system. You also view data for prior test runs. The tabs contain a grid area and an editor area, as shown next. The grid area is initially empty but it will be populated with entries that you create through the editor area. Use the editor area to define the settings for new items, or to update the settings for an item that you select in the grid area.

When you first use the configuration tool, you need to define generators and equipment on the applicable tabs. After you do this, define the device groups on the **Groups** tab.

NOTE: In order to use the reports, you must define the device groups on the **Groups** tab.

Use the following tabs to configure the tool:

- **Groups** tab - ["Define groups" on page 77](#)
- **Generators** tab - ["Define generators" on page 73](#)
- **Transfer Switches** tab - Define, describe and configure the transfer switches.
- **Equipment** tab - ["Define equipment" on page 76](#)
- **Run History** tab - ["Run History" on page 80](#)

Use the following common controls for the tabs:

- **Help** - Click this to view online help for the tab.
- **New** - Creates a new entry in the grid.
- **Delete** - Deletes the selected entry from the grid.
- **Revert** - Returns a modified record to its original values, if **OK** or **Apply** have not been clicked.
- **OK** - Saves all changes and exits the configuration tool.
- **Cancel** - Exits the tool without saving changes.
- **Apply** - Saves all changes and leaves the tool open.

The **Modified** column in the grid area shows the status of the row data:

+ (plus) - a new entry.

* (asterisk) - a modified entry.

! (exclamation mark) - entry needs more information before it can be saved.

Define generators

Use the **Generators** tab to create or update entities representing the generators in the power supply system. Complete this tab if you need to produce reports for generators.

Modified	Name	Description	Source	Nameplate Rating	Nameplate Unit	Evaluation Method
	G1	Test Auto	EPSS.G1	100	kW	Load
	G2	Test Auto	EPSS.G2_ATSA	1600	kW	Load
	G4	Test Auto	EPSS.G4	100	kW	Load
	G5	Test Auto	EPSS.G5_ATSB	1600	kW	Load

Edit Generator: G1

Name:

Description:

Electrical Data

Source:

Prime Nameplate Rating: Unit:

☐ **Engine Temperature Data**

Source: Unit:

Measurement:

☐ **Exhaust Gas Temperature Data**

Source: Unit:

☒ Single Exhaust ☐ Dual Exhaust

Measurement:

Evaluation Method

Engine Data Measurements

Status Measurements

Source:

☐ Starting: Active Value:

☐ Running: Active Value:

☐ Stopped: Active Value:

☐ Monitor for EPS Available? Active Value: Req. Time (Seconds):

☒ **Battery Waveforms**

Source: Measurement:

You can perform the following actions on this tab:

- Click **New** to define the properties of the generators in the system. See ["Creating generator properties" on page 74.](#)
- Click **Clone** to define a new generator that is similar to an existing generator. The system copies many details of the existing device into the new entry. You can then enter the unique details of the new device. If you need to define several devices that are similar, this feature can help you define them quickly. See ["Cloning generator properties" on page 75.](#)
- Click **Delete** to remove records from the system.
- Click **Revert** (before you click **Apply** or **OK**) if you make changes to a record and want to revert to your initial settings.

Creating generator properties

The **Edit Generator** area on the tab is used to create a generator entry and to define specific values for it.

1. On the **Generator** tab, click **New**.
2. Complete the following fields to define a generator.
 - **Name** - Enter a unique name to identify the generator.
 - **Description** (Optional) - You can add specific information about the generator, such as make and model.
 - **Electrical Data**
 - **Source** - Select a source name. The source represents the device that records the electrical data from the generator.

- **Prime Nameplate Rating** - Enter the maximum power load for the generator. Refer to the generator's nameplate for this value.
- **Unit** - Select the unit of measurement for the power load.
- **Battery Waveform** (Optional) - Use this area to if you want to configure and generate the Battery Health Report. To enable the report, check the box and complete these fields:
 - **Source** - Select a source name that is performing the waveform capture. This option is available for ION 7550 and ION 7650 meters.
 - **Measurement** - Select the measurement recording the battery waveform. For a typical configuration, this is the V4 waveform.

NOTE: Specific frameworks for the battery voltage waveform must also be configured. See ["Generator Battery Health" on page 86](#) for details.

- **Status Measurements** - These fields are not required.
3. Click **Apply** to save the changes and remain on the tab.
 4. Repeat these steps to define other generators.
 5. If you are defining several similar generators, use the **Clone** button. See ["Cloning generator properties" on page 75](#).

Cloning generator properties

You can define several similar generators by cloning the properties of an existing generator entity and then using those properties as the baseline for multiple generators.

To clone a generator:

1. On the **Generators** tab, select the generator you want to use as the baseline for another generator.
2. Click **Clone** to create a new generator based on a selected entity. Many fields are copied from the selected generator. The fields which are not copied have an information icon to indicate where you need to enter data, as follows:
 - **Name** - Enter a unique name to identify the generator.
 - **Electrical Data - Source** - Select a source name from the dropdown list. The source represents the device that records the electrical data from the generator.
 - **Status Measurements - Source** - Select a source name. The source represents the metering device that records the status of a generator.

For information about other generator properties, see ["Creating generator properties" on page 74](#).

3. Click **Apply** to save the new generator entity.

Define equipment

Use the **Equipment** tab to create a logical device with a source measurement and rating. You can add these logical devices to device groups for reporting. Complete this tab if you need to produce reports for equipment capacity.

The screenshot shows the 'Generator Performance Configuration Tool with EPSS Test Module - Power Monitoring Expert for Healthcare' window. The 'Equipment' tab is selected. The table below lists the equipment records:

Modified	Name	Rating	Unit	Description
	Equip1	100	kW	Test Auto
	Equip2	1500	kW	Test Auto
	IONE7650_Meter1	2000	kW	Test Auto
	IONE7650_Meter2	2600	kW	Test Auto
	laurel_North.S1	1000	kW	Test Auto

Below the table is the 'Edit Equipment: Equip1' form. It includes fields for Name (Equip1), Description (Test Auto), Load Data Source (EPSS.G1), Measurement (Active Energy Delivered Phase A), Rating (100), and Unit (kW). Buttons for New, Clone, Delete, Revert, OK, Cancel, and Apply are also visible.

You can perform the following actions on this tab:

- Click **New** to enter new record for a device. See ["Creating equipment sources" on page 77](#) for instructions to define the devices.
- Click **Clone** to copy an existing record and make minor changes. The system copies many details of the existing device into the new entry. You can then enter the unique details of the new device. If you need to define several devices that are similar, this feature can help you define them quickly.
- Click **Delete** to remove records from the system.
- Click **Revert** (before you click **Apply** or **OK**) if you make changes to a record and want to revert to your initial settings.

Creating equipment sources

Use the **Equipment** tab to manage the equipment load sources and measurements defined in the system.

1. Click **New** to create a record.
2. Complete these fields:
 - **Name** - Enter a unique name to identify the record.
 - **Description** - Enter additional information about the device. Optional.
 - **Source** - Select the load source for the device.
 - **Measurement** - Select the measurement for the device.
 - **Rating** - Enter the maximum rated load for the device.
 - **Unit** - Enter the unit of the measurement.
3. Click **Apply** to save the record and remain on the tab.
4. Repeat these steps to enter additional equipment.

Define groups

A performance group is a combination of generators and other equipment for reporting. The **Groups** tab must be completed before you can configure and produce any reports.

Generator Performance Configuration Tool with EPSS Test Module - Power Monitoring Expert Data Center Edition

Groups | Generators | Transfer Switches | Equipment | Run History

Help | Generate Vista Diagrams | New | Delete | Revert

Modified	Group	Test Frequency (Days)	Generators	Transfer Switches	Equipment	Time Zone
	ATS-A Initiated G1...	30	G1, G2, G4, G5, G6	TransferSwitch1, TransferSwi...	Equip1, IONE7650_Meter1, laurel_Nor...	(UTC-08:00) Paci...
	ATS-B Initiated G1...	30	G2, G4, G5	TransferSwitch2		(UTC-08:00) Paci...
	Group1	30	G6		Equip1, Equip2	(UTC-08:00) Paci...
	Group 123456789...	30	G5, G6, G7	TransferSwitch1	Equip1, Equip2, IONE7650_Meter1, I...	(UTC-08:00) Paci...
	Grp 2	30	G8, G9		Equip1, Equip2, IONE7650_Meter1, I...	(UTC-08:00) Paci...
	Grp3	30	G1, G2		Equip1, Equip2, IONE7650_Meter1, I...	(UTC-08:00) Paci...
	St Johns Prairie H...	30	Prairie Heart Gen	Prairie Heart TS CC, Prairie H...		(UTC-08:00) Paci...
	St Johns Pavillion	30	Pavillion Gen	Pavillion TS 1, Pavillion TS 2, ...		(UTC-08:00) Paci...

Edit Group: ATS-A Initiated G1,G2,G4,G5

Name: ATS-A Initiated G1,G2,G4,G5

Test Frequency (Days): 30

Time Zone: (UTC-08:00) Pacific Time (...)

Load Sources: Edit Load Sources

Blusson.Blusson_incoming_12KV_from_Energy_centre, Blusson.generator, Chiller_1800.600V_main, LAUREL_NORTH.BUS_DUCT_1_2_3_N, LAUREL_NORTH.BUS_DUCT_1_2_3_V, LAUREL_NORTH.BUS_DUCT_4_5_6_N, LAUREL_NORTH.Chiller_1, LAUREL_NORTH.S1, SteamPlant.500KWGenerator, ...

Generators: [Select All](#) [Select None](#)

Transfer Switches: [Select All](#) [Select None](#)

Equipment: [Select All](#) [Select None](#)

☒ G1
☒ G2
☒ G4
☒ G5
☒ G6
☐ G7
☐ G8
☐ G9
☐ GEN1
☐ Main Gen 1
☐ Main Gen 2
☐ Main Gen 3
☐ Pavillion Gen
☐ Prairie Heart Gen

☐ ATSTwo
☐ Main TS 1
☐ Main TS 10
☐ Main TS 10A
☐ Main TS 10B
☐ Main TS 11
☐ Main TS 11A
☐ Main TS 12
☐ Main TS 12A
☐ Main TS 12B
☐ Main TS 12C
☐ Main TS 13
☐ Main TS 14

☒ Equip1
☐ Equip2
☒ IONE7650_Meter1
☐ IONE7650_Meter2
☒ laurel_North.S1

OK Cancel Apply

You can perform the following actions on this tab:

- Click **New** to create a new group for generating reports. A group can contain any device that has been configured on the other tabs. See ["Creating groups" on page 78](#) for instructions to define the groups.
- Click **Delete** to remove records from the system.
- Click **Revert** (before you click **Apply** or **OK**) if you make changes to a record and want to revert to your initial settings.
- Click **Edit Priority Levels** to create or modify response times for devices and equipment. See ["Editing EPSS group priority levels" on page 54](#) for instructions.
- Click the **Edit Load Sources** to associate a group with the electrical loads that the group of generators must carry in a power outage. See ["Configuring group load sources" on page 80](#) for instructions.

Creating groups

The **Groups** tab displays the device groups defined in the system. The generators and other equipment must be defined on their respective tabs before you can add them to a group.

To create a group:

1. Click **New** to create a group.
2. Complete the following to define the values for a group:
 - **Name** - Enter a unique name to identify the group.
 - **Generators** - Select the generators to include in the group.
 - **Equipment** - Select the equipment to include in the group.

The **Select All** and **Select None** options let you work easily with large numbers of sources by selecting all check boxes or clearing all check boxes at the same time.

3. Click **Apply** to save the group and remain on the tab.
4. Repeat these steps to create other groups.

Editing group priority levels

The following reports use priority levels:

- ["Generator Capacity Report" on page 100](#) – Priority level values are required to accurately display the colors indicated in the priority levels.
- ["EPSS Test Report" on page 63](#) – Priority level values are required for the ATSS in the system to PASS or FAIL an ATS based on the required transfer time of the priority level.

Default priority levels are setup as default.

The **Edit Priority Levels** editor is used to select at least one priority level that you want to apply to the equipment groups. The default priority level names and transfer times are:

- Critical - 10 sec
- Equipment - 30 sec

- Life Safety - 10 sec

You can change any of these names and transfer times and add new priority levels as necessary.

To edit group priority levels:

1. Click **Edit Priority Levels**. The **Priority Levels** screen appears.

Modified	Name	Required Transfer Time	Color
	Critical	10	Red
	Equipment	30	Blue
	Life Safety	10	Yellow

Name: Required Transfer Time (Seconds):

Color: 255, 0, 0

2. Click **New** to add a priority level.
3. Complete the following to define priority levels:
 - **Name** - Enter a unique name to identify the priority level.
 - **Required Transfer Time (Seconds)** - Enter the transfer time in seconds. This time indicates the maximum acceptable time it takes the equipment to move from the **Test** state to the **Emergency** state.
 - **Color** - Click the color box to select a color for the priority level. This color appears on the Generator Capacity Report summary page, where the generator loads are compared. ["Generator Capacity Report example" on page 102](#) for an illustration.
4. Click **OK** to save the priority level and return to the **Groups** tab.

Configuring group load sources

On the **Edit Load Sources** screen, you can associate an equipment group with the various electrical loads that the equipment must supply during a power outage.

Define the priority levels for the system before you configure load sources. See ["Editing group priority levels" on page 78](#) for instructions.

To configure group load sources:

1. Click **Edit Load Sources**. The **Select Load Sources** screen appears.

Modified	Source	Measurement	Priority Level
	LAUREL_NORTH.BUS_DUCT_1_2_3_N	Active Power	Critical
	LAUREL_NORTH.BUS_DUCT_1_2_3_V	Active Power	Life Safety
	LAUREL_NORTH.BUS_DUCT_4_5_6_N	100ms Current A	Life Safety
	LAUREL_NORTH.Chiller 1	Active Power	Equipment

Source: LAUREL_NORTH.BUS_DUCT_1_2_3_N

Measurement: Active Power

Priority Level: Critical



2. Click **New** to add a load source.
3. Complete these fields:
 - **Source** - Select the measurement source.
 - **Measurement** - Select the measurement to monitor.
 - **Priority Level** - Select the priority level to assign to the load source.
4. Click **OK** to save the new load source and return to the **Groups** tab.

NOTE: You can use the **Clone** button to associate an equipment group with several sources where the load is logged against the same measurement. The cloned group contains the same measurement and priority level as the original.

Run History

Use the **Run History** tab to view or modify run activities that represent the Test, Load Shedding, and Power Outage activities that have occurred in the system. The history indicates when components of the power system have become active, such as when a generator was running. The runs stored in history can be used as input for reports and dashboards.

Because the system stores the history of these activities, you can generate useful reports about the equipment operation. The reports can identify when the system was active, why the system was active, and what devices were active.



The first time the history records are generated on the **Run History** tab, the system may take a long time depending on the amount of history present in the system. When changes occur in the equipment configuration, the run history must be generated again.

For example if you remove a generator from a group, the run history for that group needs to be rebuilt because that generator may have been the reason for the detection of a run. Now that the generator is not part of the group, the system needs to build the run history again to have accurate data.

You can perform the following actions on this tab:

- Click **Detection Options** to modify the criteria of a run event that will cause it to appear on this tab. See ["Modifying run detection options" on page 82](#).
- Click **Refresh Run History** to update the tab with the latest run events that have occurred in the system.
- Click **Delete Run History** to remove all run event records from the tab.
- Modify the name and run reason for a run event. See ["Modifying run details" on page 82](#).

Modifying run detection options


The run detection options can be defined to help guard against bad data in the system. To record actual run activities, you can set the parameters so the system only records runs that fall within the criteria.

The minimum run length value is present to prevent false positives, which may occur during commissioning when the states of the generators are changing quickly and seemingly at random. This may be due to signals being recorded that really do not reflect actual generator activity.

You can set the maximum run length to eliminate "hanging" runs. A hanging run occurs when the stop signal for a generator is not recorded properly. As a result, every week during the test it records a running signal but there is no way for the system to know when it stops. If the system does not see a stop signal, it sets the end of the run to be the start of the run plus the maximum run duration. Therefore you cannot determine how long the generator was actually running.

To define the run criteria for the system to store runs in history:

1. Click **Detection Options**. The **Run Detection Options** screen appears.

A screenshot of a dialog box titled "Run Detection Options" with a red close button in the top right corner. The dialog contains two input fields: "Minimum Run Length (Minutes):" with the value "15" and "Maximum Run Length (Hours):" with the value "48". At the bottom are "OK" and "Cancel" buttons.

2. Change the values in the minimum and maximum fields.
3. Click **OK** to save the changes and return to the **Run History** tab.
4. Click **Refresh** to update the tab with the run events that match the new detection criteria.

Modifying run details

The system defines run data, such as name, start time, end time, reason, and active sources automatically. You can change the name of the run event and the reason for the run.

- The default run name is the start date of the run, such as June 12 2015. If a group has multiple runs on the same date, the subsequent runs have the same date with the run number appended, such as June 12 2015 Run 2 and June 12 2015 Run 3.

- The system automatically detects the reason for the run. If the detected reason is incorrect, you can change the reason. For example, the reason appears as Test, but the run is actually Load Shedding.

Other details about the run event cannot be modified directly. If the sources for a run are not correct, you can exclude or include specific sources when generating a report based on this run.

1. Click the run record you want to modify. The run details appear below the grid.
2. In the **Name** field, change the suggested run name as necessary.
3. In the **Reason** list, select the correct reason for the run.
4. Click **OK** to save the changes for the run.

Generator Activity Report

The **Generator Activity Report** shows the test run hours and other test run data for each generator in the selected group.

 WARNING
INACCURATE REPORT RESULTS • Do not incorrectly configure the devices and software. • Do not rely solely on system reports to determine if the system is functioning correctly or meeting all applicable standards and requirements. • Use system reports as a supplement to proper workplace practices or equipment maintenance, not as a substitute. Failure to follow these instructions can result in death, serious injury, or equipment damage.

Generator Activity Report prerequisites

Before you can generate a Generator Activity Report you must define the following tabs and fields in the Generator Performance Configuration Tool (or Generator Performance Configuration Tool with EPSS Test Module):

Generators Tab

- **Name** - The generator entity needs a name.
- **Electrical Data** - Specify the required measurement source, nameplate rating, and unit of measurement.
- **Status Measurements** - The source of the status measurement and the start, run, and stop values must be selected. Configure the meters that provide these measurements.
- **Evaluation Method** - "Load" is default, but this may be changed to accommodate customer requirements.

For instructions on the above settings see either of these sections:

- For Generator Performance Configuration Tool, see ["Define generators" on page 73](#).
- For Generator Performance Configuration Tool with EPSS Test Module, see ["Define EPSS generators" on page 38](#).

Configuring the Generator Activity Report

Use the Reports module in Web Applications to configure and generate the Generator Activity Report.


NOTE: Emergency Power Supply System (EPSS) is a North American term used in the healthcare segment. "EPSS Group" refers to the "Groups" defined in the Generator Performance Configuration Utility.

1. Complete the fields to define the report:
 - **Title** - Enter a name for the report.
 - **EPSS Group** - Select the group for which the report is intended. When you select a group in the list, the field to the right shows the devices included in the group.
 - **Exclude Sources** - Click this to define the sources to exclude from the report.
 - a. In the **Sources Included** area, select sources to exclude and then click **>** to move those sources to the **Sources Excluded** area.
 - b. To move all of the sources into the **Sources Excluded** area, click **>>**.
 - c. Click **OK** to save the sources and return to the report template. The devices in the group will appear in the **Sources** section of the generated report. Excluded devices will appear as grayed-out entries.
 - **Reporting Period** - Select the date range for the data you want to include. This can be a fixed number of prior days, such as Last 7 Days, or a fixed date range. The initial setting is `Last 7 Days`. In the US, select at least 30 days of load data recorded at 15 minute intervals to satisfy regulations. Also select the type of timestamp to use in the report, either `Server Local Time` or `UTC (Universal Time)`.
 - **Threshold (Hours)** - Enter the maximum number of hours the generators should run in non-emergency use. Enter a value that is in compliance with local authority requirements. For example, in the US, the EPA requires that generators can run no more than 100 hours in non-emergency use.
 - **Include Activity Details** - Click **Yes** to include the generator details in the report. Click **No** to exclude this section.
 - **Include Data Warnings** - Click **Yes** to include data warnings in the report. If there are none, the section is not included. Click **No** to exclude this section.
2. Click **Generate Report** to produce the report.

Generator Activity Report example


Summary Page

The first page of the report shows the title, company name, group, a bar graph representing the test run hours on each generator, and a table of test run data for each generator.



Details Page

The details page shows a pie chart of the type of hours for each generator and the total run time table.



Schneider
Electric

Generator Activity Report

9/12/2013 12:00:00 AM - 9/19/2013 12:00:00 AM (Server Local)

Main

Generator	Start Time	Stop Time	Duration (hours)	Run Reason
Main Gen 1	9/12/2013 7:00:50 AM	9/12/2013 8:10:45 AM	7.65	Test
Main Gen 2	9/12/2013 7:00:50 AM	9/12/2013 8:10:46 AM	7.87	Test
Main Gen 3	9/12/2013 7:00:51 AM	9/12/2013 8:10:45 AM	7.67	Test

Generator Battery Health

The Generator Battery Health system contains several components that provide the customer with information about the generator battery bank. Specifically, the monitor shows the customer the starting voltage signature, which indicates the battery bank's voltage drop and recovery during and after starting the generator.

The following tasks must be completed to set up the Generator Battery Health system:

- Install and configure the ION7550 / ION7650 meter to the battery bank to be monitored. Refer to the *PowerLogic ION7550 / ION7650 Installation Guide* and *PowerLogic ION7550 / ION7650 User Guide* for more information. Obtain the latest version of these documents from www.schneider-electric.com.

Note the following:

- Digital signal from the Crank relay connected to the digital input of the ION7550/ ION7650 meter. This is the signal that triggers that triggers the oneshot timer to start recording waveform
- V1 - V3 voltage inputs must have PTs in order to isolate the ground from the system being monitored and the battery.
- Connect V4 to the positive side of the battery. Input impedance of V4 terminal is 5 Mohm (phase - Vref). For the most up to date specification, contact the local representative.
- Connect Vref to battery ground.
- Fusing must be installed according to the meter installation instructions.
- Perform visual inspection of connections to help ensure there is physical separation between the system connected to V1, V2 and V3, and the battery connected to V4.
- For other wiring options with PTs, see the *PowerLogic ION7550 / ION7650 Installation Guide*.

DANGER


EQUIPMENT ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Treat the battery circuit as energized to the category of the installation.

Failure to follow these instructions will result in death or serious injury.

Refer to the following diagram as an example for connections to the meter.

4-Wire Wye, 3-Element, 3 PTs Connection Diagram




- Configure the Battery Health Framework to capture the battery voltage signature or waveform and deploy the framework to the meter. See the next section for instructions.
- In the Generator Performance Configuration Tool, check the Battery Waveforms option for the generator to be included in the customer's Battery Health report. See ["Creating generator properties" on page 74](#) or ["Creating EPSS generators" on page 39](#) for instructions.
- Configure the Generator Battery Health Report to display the graph of the voltage signature. The customer can use the report to help understand the battery bank condition. The report can display multiple generators for the same starting date or a single generator on multiple starting dates. See ["Configuring the Battery Health Report" on page 94](#).

This section provides instructions for configuring the framework to capture the voltage signature.

Configure the Battery Health Framework

The Battery Health Framework is designed to capture and record a generator's battery voltage signature at start up. This voltage signature provides some indication of the health of the generator's battery bank. A typical waveform capture of the voltage drop when starting is shown next:




Note the following items about this example:

- This capture shows about 4 - 5 seconds worth of data, accomplished via 3 waveform recorders in series configured at a resolution of 16x96.
- The voltage does not immediately recover to its original value (~26 v) but it begins to ramp up.
- There is about 0.5 seconds of data before the voltage drops to approximately 20 V.

Two options in the framework are possible to capture the waveform, based on how the crank relay signal is triggered - pulse or KYZ.

Example Framework

The following figure shows the typical modules for the framework.




The types of module used are:

- Data Acquisition
- Digital Input
- Convert
- OneShot Timer
- Waveform Recorder

See the following descriptions for the way each module works in this framework.

Refer to *ION Reference* for details on how each module operates and for setting module parameters.

Data Acquisition – Data Acqn 1



The V4 signal from the meter goes to the Data Acquisition module.

Digital Input – G1 Crank Relay




This module accepts the Cranking Relay signal from the field. When the signal goes high, the logic to record the battery voltage triggers.

The Input mode can be set to Pulse or KYZ, as explained next.

Pulse Input Mode

When the Crank Relay signal goes high, a pulse is generated on the Trigger output register, labeled "G1 Crank Relay." The setup registers for the Digital Input module are shown next.




Note that the **Input Mode** value is Pulse. The Trigger output can now be fed into the first Waveform Recorder along with V4 from the Data Acquisition module.

KYZ Input Mode

If you are using the same Digital Input to handle the Generator Start signal (EPSS_Start) it is probably set to KYZ mode.

Input Mode KYZ means that a pulse is generated on the Trigger output register when the Crank Relay signal goes high AND when it goes low. The Convert module and One Shot Timer module (explained later) prevent triggering the downstream logic twice.


The Crank Relay Module is setup like this:



Note that the Input Mode value is KYZ.

Convert

The signal from the Digital Input module cannot be fed directly into the One Shot Timer. The Convert module converts the digital signal to analog for the One Shot Timer.



One-Shot Timer

To prevent triggering the downstream logic twice, send the state (EPSS_Start) from the Convert module into the One Shot Timer:




Send the output register into the first Waveform Recorder G1 Battery 1.

First Waveform Recorder – G1 Battery 1

The Data Acquisition module and G2 Crank Relay module are the inputs to the first Waveform Recorder, labeled "G1 Battery 1."



These are the setup registers for the module:



ION Module Setup

Setup Registers:		Output Registers:
WR8 Depth	100	WR8 Wform Log
WR8 RecordMode	Circular	WR8 Log State
WR8 Format	16x96	WR8 Records Left
WR8 Record Delay Cycles	95	WR8 Record Complete
		Event

Module Label

☐ Use Default Label

☒ Use Custom Label:

G1 Battery 1


Modify... OK Cancel

Note the following about the setup registers:

- Depth must be non-zero – 100 is a good number.
- Record Mode should be Circular.
- Format should be 16x96. This means 16 samples per cycle and 96 cycles, so at 60 Hz this results in approximately 1.6 seconds worth of data.
- Record Delay Cycles is set to 95 to allow the “window of observation” to move so that only post-event data is captured. Refer to *ION Reference* for more details.

Second and Third Waveform Recorders

The second Waveform Recorder - G1 Battery 2 - is cascaded with the first to capture another 1.6 seconds of the battery voltage signature. Do this by using the Record Complete output register on G1 Battery 1 as a flag to trigger G1 Battery 2 to start recording.




The third Waveform Recorder - G1 Battery 3 - is cascaded with the second recorder to capture the final 1.6 seconds of the battery voltage signature. As above, use the Record Complete output register on G1 Battery 2 as a flag to trigger G1 Battery 3 to start recording.

The Setup Registers should be the same as first waveform recorder with different labels.

Battery Health Waveform Capture results

After the framework is complete, in Vista you should see the voltage signature that looks similar to the following example image:



After you obtain this type of result, you can configure the generator in the Generator Performance Configuration Tool and define the Battery Health Report in the Power Monitoring Expert 8.2 – Healthcare Edition or the Power Monitoring Expert 8.2 – Data Center Edition Web Applications Reports feature. Refer to these sections for instructions on these tasks.

- ["Creating generator properties" on page 74](#) if the system does not include EPSS.
- ["Creating EPSS generators" on page 39](#), if the system includes EPSS.
- ["Configuring the Battery Health Report" on page 94](#).

Generator Battery Health Report

The **Generator Battery Health Report** shows an image of the generator battery voltage when the generator starts.

The waveform image includes a reference waveform that shows the initial voltage signature when the batteries were first installed and tested. The reference waveform helps compare the current battery condition to their initial condition.

Research has indicated that when a battery begins to fatigue, the waveform for the voltage during start-up changes. The voltage waveform can be captured and stored in the system for ongoing analysis.

By capturing the voltage waveform when the batteries are in a known good condition, subsequent waveforms can be compared to it to identify changes. In the Generator Battery Health report, you can compare waveform images to see the changes over time. Adverse changes in the waveform indicate a degradation of battery condition.

WARNING

INACCURATE REPORT RESULTS

- Do not incorrectly configure the devices and software.
- Do not rely solely on system reports to determine if the system is functioning correctly or meeting all applicable standards and requirements.
- Use system reports as a supplement to proper workplace practices or equipment maintenance, not as a substitute.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Prerequisites

In the Generator Performance Configuration Tool (with or without EPSS), define the following tabs and fields in order to generate the report:

Generators Tab

- **Name** - The generator entity needs a name.
- **Electrical Data** - The measurement source, nameplate rating, and unit of measurement are required.
- **Status Measurements** - The source of the status measurement and the start, run, and stop values must be selected. Configure the meters that provide these measurements.
- **Evaluation Method** - "Load" is default, but this may be changed to accommodate customer requirements.
- **Battery Waveforms** - Select the source and the measurement. Configure the meters that provide these measurements. Also, configure the frameworks as described in "[Generator Battery Health](#)" on page 86.

For instructions on completing this tab, see the following:

- "[Creating generator properties](#)" on page 74 if the system does not include EPSS.
- "[Creating EPSS generators](#)" on page 39, if the system includes EPSS.

After these required items are defined, the report can be configured and generated, as described next.


Configuring the Battery Health Report

Use the Reports module in Web Applications to configure and generate the Battery Health Report.


NOTE: Emergency Power Supply System (EPSS) is a North American term used in the healthcare segment. "EPSS Group" refers to the "Groups" defined in the Generator Performance Configuration Utility.

1. Complete the fields to define the report:

- **Title** - Enter a name for the report.
- **Select EPSS (or Generator) Group** - Select the generator group for which the report is intended. The list shows the groups that include generators that can record the battery voltage waveform via ION 7550 / ION 7650 meter. See ["Creating generator properties" on page 74](#) for more details about selecting the battery waveform selection for a generator. When you select a group in the list, the field to the right shows the devices included in the group.
- **Exclude Sources** - Click this to define the sources to exclude from the report.



- In the **Sources Included** area, select sources to exclude and then click **>** to move those sources to the **Sources Excluded** area.
 - To move all of the sources into the **Sources Excluded** area, click **>>**.
 - Click **OK** to save the sources and return to the report template. The devices in the group will appear in the **Sources** section of the generated report. Excluded devices will appear as grayed-out entries.
- **Select Generator Starts** - Select the option to specify the start records. If you click **Select Reference Starts** you can choose the specific start records by generator and date. For example, you can use this option to compare yesterday's Gen 1 start voltage signature to the Gen 1 start voltage signature from six months prior.




- **Include Data Warnings** - Click **Yes** to include the data warnings in the report. If there are no data warnings, the section is not included in the report. Click **No** to exclude this section.
- **Cumulative Degradation Threshold** - Enter the value that represents the maximum total voltage difference between the reference waveform and the evaluated waveforms. For example, if the waveform is off by 1.0 on each point from the reference, the total degradation is 10. If the threshold value is 8, then the degradation exceeds the threshold.

2. Click **Generate Report** to produce the report.

Battery Health Report example

In this example, the starting voltage waveform (blue) is very similar to the reference waveform (red). The drop to 20 VDC is the point at which the generator started. After the start, battery voltage rises to normal state of charge after the start.



Generator Battery Health Export

The **Generator Battery Health Export** report is based on the same data as the graphic-based report. The export version provides the raw data in CSV file format. The export file can be imported by other systems, such as Energy Operation.

Configuring the Generator Battery Health Export

Use the Web Application Reports feature to configure and produce the Generator Battery Health Export file.

1. In the Reports Library, expand either the **Generator Performance** or **Healthcare Reports** folder and click **Generator Battery Health Export**. The report template appears.

Generator Battery Health Export


Title	Generator Battery Health Export
	ATS-B Initiated G1,G2,G4,G5 G2, G4, G5 Exclude Sources
Select an EPSS Group and Generator Starts	Select Reference Starts ☒ Show the most recent starts ☐ Select the generator starts 5 Starts
Cumulative Degredation Threshold	

Generate Report


2. Complete the fields to define the report.

- **Title** - Enter a name for the export file.
- **Select EPSS Group** - Select the generator group for which the report is intended. The list shows the groups that include generators that can record the battery voltage waveform via ION 7650 meter. For more details about selecting the battery waveform selection for a generator, see either:
 - For Generator Performance Configuration Tool, see ["Creating generator properties" on page 74](#).
 - For Generator Performance Configuration Tool with EPSS Test Module, see ["Creating EPSS generators" on page 39](#).
- When you select a group in the list, the field to the right shows the devices included in the group.

- **Exclude Sources** - Click this to define the sources to exclude from the report.



- In the **Sources Included** area, select sources to exclude and then click **>** to move those sources to the **Sources Excluded** area.
 - To move all of the sources into the **Sources Excluded** area, click **>>**.
 - Click **OK** to save the sources and return to the report template. The devices in the group will appear in the **Sources** section of the generated report. Excluded devices will appear as grayed-out entries.
- **Select Generator Starts** - Select the option to specify the start records. If you click **Select Reference Starts** you can choose the specific start records by generator and date. For example, you can use this option to compare yesterday's Gen 1 start voltage signature to the Gen 1 start voltage signature from six months prior.



- **Cumulative Degradation Threshold** - Enter the value that represents the maximum total voltage difference between the reference waveform and the evaluated waveforms. For example, if the waveform is off by 1.0 on each point from the reference, the total degradation is 10. If the threshold value is 8, then the degradation exceeds the threshold.

3. Click **Generate Report** to produce the report.

Battery Health Export example

	A	B	C	D	E	F	G	H	I	J	K	L	M	N
1	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	99.72509766
2	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	199.4501953
3	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	299.175293
4	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	398.9003906
5	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	498.6254883
6	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	598.3505859
7	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	698.0756836
8	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	797.8007813
9	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	897.5258789
10	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	997.2509766
11	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	1096.976074
12	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	1196.701172
13	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	1296.42627
14	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	1396.151367
15	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	1495.876465
16	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	1595.601563
17	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	1695.32666
18	2	G1	2012-02-22T15:06:57	733	2012-02-29T15:11:02	187	0	1000	2839.898804	1256	2939.623901	99.72509766	80	1795.051768

Generator Capacity Report

The **Generator Capacity Report** helps verify the generators can adequately support the loads required during an emergency. The report compares the loads the generators and equipment must carry with the available generator capacity.

WARNING

INACCURATE REPORT RESULTS

- Do not incorrectly configure the devices and software.
- Do not rely solely on system reports to determine if the system is functioning correctly or meeting all applicable standards and requirements.
- Use system reports as a supplement to proper workplace practices or equipment maintenance, not as a substitute.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Generator Capacity Report prerequisites

In the Generator Performance Configuration Tool, define the following tabs and fields in order to generate the report:

Before you can generate a Generator Capacity Report you must define the following tabs and fields in the Generator Performance Configuration Tool (or Generator Performance Configuration Tool with EPSS Test Module):

Generators Tab

- **Name** - The generator entity needs a name.
- **Electrical Data** - Specify the required measurement source, nameplate rating, and unit of measurement.
- **Status Measurements** - The source of the status measurement and the start, run, and stop values must be selected. Configure the meters that provide these measurements.
- **Evaluation Method** - "Load" is default, but this may be changed to accommodate customer requirements.

For instructions on the above settings see either of these sections:

- For Generator Performance Configuration Tool, see ["Define generators" on page 73](#).
- For Generator Performance Configuration Tool with EPSS Test Module, see ["Define EPSS generators" on page 38](#).

Equipment Tab

- Complete all fields on the Equipment tab (except **Description**). Generators can be added in this tab to include them in the report. See either of these sections for instructions on the **Equipment** tab.

For instructions on the above settings see either of these sections:

- For Generator Performance Configuration Tool, see ["Creating equipment sources" on page 77](#).
- For Generator Performance Configuration Tool with EPSS Test Module, see ["Creating EPSS equipment sources" on page 52](#).

Groups Tab

- Add the load sources indicating measurement and priority levels to the EPSS group in the Edit Load Sources screen. If load sources are not added, the report will return empty pages and state "No Data Available." See either of these sections for instructions on the Groups tab.

For instructions on the above settings see either of these sections:

- For Generator Performance Configuration Tool, see ["Creating equipment sources" on page 77](#).
- For Generator Performance Configuration Tool with EPSS Test Module, see ["Creating EPSS equipment sources" on page 52](#).

Configuring the Generator Capacity Report


Use the Reports module in Web Applications to configure and generate the Generator Capacity Report.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.

Generator Capacity Report example

Summary Page

The first page of the report shows a chart of the loads on each generator compared to the total capacity rating. The colors for the bars are defined for the load priority levels. See ["Editing EPSS group priority levels" on page 54](#) for instructions on how to define the priority levels.



Details Page

The following image shows the details for the capacity of the selected generators:

		Generator Capacity Report				
Date	Total Capacity	Total Load	Available Capacity	Life Safety	Critical	Equipment
December, 2011	810.00		810.00			
January, 2012	810.00	875.91	-65.91	197.94	218.97	459.00
February, 2012	810.00	952.06	-142.06	222.99	231.07	498.00
March, 2012	810.00		810.00			
April, 2012	810.00		810.00			
May, 2012	810.00		810.00			
June, 2012	810.00		810.00			
July, 2012	810.00		810.00			
August, 2012	810.00		810.00			
September, 2012	810.00		810.00			
October, 2012	810.00		810.00			
November, 2012	810.00		810.00			

Generated on: 11/19/2012 10:03:02 AM Page 2 of 2

Generator Load Summary Report

The **Generator Load Summary Report** provides a summary graph of electrical data during a generator run. The report includes a load curve, minimum-maximum-average load summary, and other electrical details.

NOTE: This report is only included with the system if EPSS is not installed.

WARNING

INACCURATE REPORT RESULTS

- Do not incorrectly configure the devices and software.
- Do not rely solely on system reports to determine if the system is functioning correctly or meeting all applicable standards and requirements.
- Use system reports as a supplement to proper workplace practices or equipment maintenance, not as a substitute.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Generator Load Summary Report prerequisites

Before you can generate a Generator Load Summary Report you must define the following tabs and fields in the Generator Performance Configuration Tool:

Generators Tab

- **Name** - The generator entity needs a name.
- **Electrical Data** - Specify the required measurement source, nameplate rating, and unit of measurement.

- **Status Measurements** - The source of the status measurement and the start, run, and stop values must be selected. Configure the meters that provide these measurements.
- **Evaluation Method** - "Load" is default, but this may be changed to accommodate customer requirements.

See ["Define generators" on page 73](#) for instructions on the above settings.


Configuring the Generator Load Summary Report

Use the Reports module in Web Applications to configure and generate the Generator Load Summary Report.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.

NOTE: Emergency Power Supply System (EPSS) is a North American term used in the healthcare segment. "EPSS Group" refers to the "Groups" defined in the Generator Performance Configuration Utility.

Generator Load Summary Report example





Generator Load Summary Report

ATS-B Initiated G1,G2,G4,G5

2/27/2013 8:00:00 AM - 8/28/2013 7:00:00 AM

Electrical Details for G2

Nameplate Rating 1600 kW

Running 7/29/2013 7:00:37 AM

Stopped 7/29/2013 8:09:11 AM

Timestamp	kW	kVA	Load %	PFS	I avg	Vll avg	Vln avg	Frequency
7/29/2013 7:01:00 AM	-54.73	56.53	-3.42	-96.82	2.64	12,534.83	7,236.99	59.88
7/29/2013 7:02:00 AM	226.71	240.88	14.17	-94.12	11.49	12,494.25	7,213.56	60.01
7/29/2013 7:03:00 AM	470.29	494.12	29.39	-95.18	23.31	12,445.82	7,185.60	60.01
7/29/2013 7:04:00 AM	474.87	496.57	29.68	-95.63	23.38	12,459.60	7,193.56	60.01
7/29/2013 7:05:00 AM	478.81	506.26	29.93	-94.58	23.88	12,434.85	7,179.26	60.01
7/29/2013 7:06:00 AM	490.59	514.21	30.66	-95.41	24.19	12,449.52	7,187.74	60.01
7/29/2013 7:07:00 AM	484.94	508.25	30.31	-95.41	23.89	12,467.79	7,198.28	60.02
7/29/2013 7:08:00 AM	482.31	508.36	30.14	-94.88	23.90	12,451.94	7,189.13	60.01
7/29/2013 7:51:00 AM	504.39	527.84	31.52	-95.56	24.78	12,473.35	7,201.50	60.01
7/29/2013 7:52:00 AM	506.23	534.55	31.64	-94.70	25.11	12,457.29	7,192.22	60.01
7/29/2013 7:53:00 AM	506.58	530.68	31.66	-95.46	24.88	12,480.67	7,205.72	60.01
7/29/2013 7:54:00 AM	519.32	546.56	32.46	-95.02	25.53	12,497.70	7,215.55	60.01
7/29/2013 7:55:00 AM	515.66	541.11	32.23	-95.30	25.30	12,496.31	7,214.75	60.01
7/29/2013 7:56:00 AM	511.40	535.62	31.96	-95.48	25.10	12,490.05	7,211.13	60.01
7/29/2013 7:57:00 AM	513.06	533.16	32.07	-96.23	24.93	12,509.28	7,222.24	60.01
7/29/2013 7:58:00 AM	527.68	554.73	32.98	-95.12	26.01	12,466.06	7,196.44	60.01
7/29/2013 7:59:00 AM	529.43	555.54	33.09	-95.30	25.93	12,500.62	7,217.24	60.01
7/29/2013 8:00:00 AM	538.86	570.14	33.68	-94.51	26.65	12,466.28	7,197.41	60.01
7/29/2013 8:01:00 AM	524.81	551.78	32.80	-95.11	25.84	12,465.62	7,197.03	60.01
7/29/2013 8:02:00 AM	536.41	560.83	33.53	-95.64	26.28	12,462.86	7,195.44	60.01
7/29/2013 8:03:00 AM	530.49	555.05	33.16	-95.58	25.99	12,474.76	7,202.31	60.01
7/29/2013 8:04:00 AM	525.79	550.30	32.86	-95.55	25.80	12,467.89	7,196.34	60.01
7/29/2013 8:05:00 AM	538.57	568.77	33.66	-94.69	26.28	12,633.24	7,293.81	59.97
7/29/2013 8:06:00 AM	252.21	269.19	15.76	-93.69	12.51	12,531.39	7,235.00	59.95
7/29/2013 8:07:00 AM	-0.58	0.79	-0.04	-73.22	0.05	12,339.68	7,124.32	59.96
7/29/2013 8:08:00 AM	-0.60	0.81	-0.04	-74.03	0.05	12,339.84	7,124.41	59.96
7/29/2013 8:09:00 AM	-0.62	0.83	-0.04	-74.58	0.05	12,339.95	7,124.47	59.96

Generator Test Report

The Generator Test Report shows the run details and overall status for generators and transfer switches in the group. For example, the report shows the transfer time of the lead ATS and indicates whether the transfer time passes or does not pass the test requirements.

Use the Reports module in Web Applications to configure and generate the Generator Test Report.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.

Report Prerequisites

In the Generator Performance Configuration Tool, define the following tabs and fields in order to generate the report.

Generators Tab

- **Name** - Enter a name for the generator entity.
- **Electrical Data** - Enter the measurement source, nameplate rating, and unit of measurement.

- **Status Measurements** - Enter the source of the status measurement and the start, run, and stop values. Configure the meters that provide these measurements.
- **Evaluation Method** - "Load" is default, but you can change this to accommodate customer requirements.

See ["Define generators" on page 73](#) for instructions on the above settings.

Groups Tab

- **Name** - Enter a name for the group entity.
- Select at least one entity from the **Generators**, **Transfer Switches**, or **Equipment** lists. The group can contain entities from each list combined.

See ["Define groups" on page 77](#) for instructions.

After these required items are defined, the report can be configured and generated, as described next.

Power Capacity

Power Capacity let you manage and report on generator and UPS systems, and report on branch circuits within a data center facility.

Power Capacity includes the following configuration tools:

- ["Generator Power Configuration Utility" on page 110](#)
- ["UPS Power Configuration Utility" on page 119](#)

Power Capacity includes the following reports:

- ["Branch Circuit Power Report" on page 109](#)
- ["Generator Power Report" on page 118](#)
- ["UPS Power Report" on page 126](#)

Branch Circuit Power Report

The Branch Circuit Power Report is used by data center facility operators to generate a report that describes the average and maximum loading for branch circuits within the data center facility, as well as the percentage load compared to the breaker size. This section describes the procedures involved in creating a report, how the reports are used, examples of the generated report, and the managing and saving of the report.

NOTE: This report requires a license to be used. Contact your Schneider Electric representative for more information.

The Branch Circuit Power Report is used for:

- Proactive capacity management
- Incident investigation
- Customer expansion planning
- Service Level Agreement (SLA) management

NOTE: For the Branch Circuit Power Report to provide accurate information, devices must be installed, configured, and communicating correctly, you must use and correctly configure the **Circuit > Rack > Customer** hierarchy, and the Managed Circuits feature run each time a device configuration change is made. If any of these tasks are not performed correctly, your reports will provide inaccurate information. See "Switching to the Customer Circuit hierarchy template" section in the *Power Monitoring Expert 8.2 – Data Center Edition Commissioning Guide* for more information.

Branch Circuit Power Report example

The Branch Circuit Power Report data depends on the selections you make while configuring the report and the contents of the Power Monitoring Expert or Data Center database.

- For N, N+1, and N+2 system types:
 - Only one group is allowed.
 - Each generator in the group must have the same nameplate rating (kVA) value.
 - Each generator in the group must have the same derated nameplate rating (kW) value.
- For 2N, 2(N+1) and 2(N+2) system types:
 - Up to three groups are allowed.
 - All groups must have the same number of generators.
 - All generators in the groups must have the same nameplate rating (kVA) value.
 - All generators in the groups must have the same derated nameplate rating (kW) value.
- **Generators**
 - Name must be unique.
 - At least one generator must be present in each group.
 - A maximum of 12 generators is allowed in each group.

Starting the Generator Power Configuration Utility


To start the Generator Power Configuration Utility, either:

- Double-click the **Generator Power Configuration Utility** icon located in the **Power Monitoring Expert DC Ed** folder on the desktop,
- or
- Click **Start > All Programs > Schneider Electric > Power Monitoring Expert DC Ed > Generator Power Configuration Utility**.

Defining generator systems

A generator system is a logical system configuration that is used for reporting power capacity.

The following image is an example of the Generator Power Configuration Utility with a sample generator system selected.




Control	Description
Help	Opens the help for the utility.
New	Creates a new entry in the grid.
Delete	Deletes the selected entry from the grid.
OK	Saves all changes and exits the utility.
Cancel	Exits the utility without saving changes.
Apply	Saves all changes and leaves the utility open.


Grid Area Columns	Description
Modified	Displays a status symbol for the record.
+ (plus)	A new entry.
* (asterisk)	An existing entry has been modified.
! (exclamation mark)	The entry is incorrect.
System	Displays the system name.
Type	Displays the Generator system type (N, 2N, N+2, etc)
Description	Displays a description of the system

To define a generator system:

- 1. Click **New**. The Edit System: New System area appears below the grid.



- 2. Click anywhere in the editor area. The Properties screen appears.



- 3. Complete the details for the generator system:
 - a. **Generator System Name:** Enter a name for the generator system. Each generator system must have a unique name.
 - b. **Description:** Enter a description for the generator system. This field is optional.

- c. **Redundancy Type:** Select the redundancy type for the generator system. The different redundancy types are explained in ["Generator system redundancy types" on page 282](#).
- d. **Groups:** Shows the number of generator groups contained in the generator system. Click **Add** to add groups to the generator system. Click **Remove** to delete groups.
- e. **Generators Per Group:** Shows the number of generators in each generator group in the system. Click **Add** to add generators to the group. Click **Remove** to delete generators.
This property is only available when the system redundancy type is 2N, 2(N+1) or 2(N+2). To define the number of generators for a system with redundancy type N, N+1 or N+2, use the generator group properties. See ["Defining generator groups" on page 114](#) for more information.

- 4. Click **Done** to save the generator system.

Once complete, you can configure the other components of the system:

["Defining generator groups" on page 114](#)

["Defining generators" on page 116](#)

["Defining generator loads" on page 116](#)

["Defining utilities" on page 117](#)

Defining generator groups

A generator group represents a logical grouping of generators. The system contains at least one group and can contain multiple groups. Depending on the system type, the group properties may be different, as shown below. See ["Generator Power configuration restrictions" on page 110](#) for more information.

To define a generator group:

1. Click on the group object border. The Properties screen appears.

The diagram illustrates two scenarios for defining a generator group in the software. In the first scenario, a single generator icon labeled 'G' is connected to a 'Main Load' icon. A 'Properties for: Gen Group' window is open, showing the 'Generator Group Name' field with the value 'Gen Group', an empty 'Description (optional)' field, and 'Generators Per Group' set to 1. In the second scenario, a group of six generator icons labeled 'Gen B1' through 'Gen B6' is connected to a 'Main Load' icon. A 'Properties for: Group B' window is open, showing the 'Generator Group Name' field with the value 'Group B', an empty 'Description (optional)' field, and 'Generators Per Group' set to 1. Both windows include 'Add' and 'Remove' buttons for the 'Generators Per Group' field and a 'Done' button at the bottom.


2. Complete the details for the generator group:
 - a. **Generator Group Name:** Enter a name for the group.
Each generator group must have a unique name.
 - b. **Description:** Enter a description for the group. This field is optional.
 - c. **Generators Per Group:** Click **Add** to increase the number of generators in the group.
Click **Remove** to decrease the number. This property is available only for system redundancy types N, N+1 or N+2.
3. Click **Done** to save the generator group.

Defining generators

A generator represents an actual generator device in the data center. A group contains at least one generator and can contain multiple generators. For some system types, each group must contain the same number of generators. See ["Generator Power configuration restrictions" on page 110](#) for more information.

To define a generator:

1. Click on the generator object border. The selected generator will be highlighted in blue and the Properties screen appears.




2. Complete the details for the generator:
 - a. **Generator Name:** Enter the name for the generator.
This name must be unique for each generator in the system.
 - b. **Description:** Enter a description for the generator. This field is optional.
 - c. **Nameplate Rating (kVA):** Enter the maximum output power (kVA) of the generator. This value must be greater than zero.
 - d. **Derated Nameplate Rating (kW):** Enter the maximum power capacity (kW) that the generator is expected to support. This value must be equal or less than the nameplate rating value, and greater than zero.
3. Click **Done** to save the generator.

Defining generator loads

A generator load represents the logical load attached to a generator group. Each generator system must have only one load.

To define a generator load:

1. Click the generator load element in the system diagram. The Properties screen appears.




2. Complete the details for the generator load:
 - a. **Load Name:** Enter a name for the load.
 - b. **Description:** Enter a description for the load. This field is optional.
 - c. **Data Source:** Select one or more meter sources where load data is logged for this load.
 - d. **Additional Utilities:** Click **Add** to increase the number of utility objects for the load. Click **Remove** to decrease the number of utility objects.
3. Click **Done** to save the generator load.

Defining utilities

A utility represents the logical utility provider that feeds a particular load under normal operation. This logical utility has no functional purpose in the calculations for power redundancy. It is used to provide a more complete diagram representation for the generator system. A system may have one or two utilities represented in the diagram.

To define a utility:

1. Click the utility element in the diagram. The Properties screen appears.



2. Complete the details for the utility:
 - a. **Utility Name:** Enter a name for the utility.
 - b. **Description:** Enter a description for the utility. This field is optional.
3. Click **Done** to save the utility.

Once the configuration of the generators, loads, and utilities are complete, click **Apply** to save, or click **OK** to save the configuration and exit the utility.

Generator Power Report

The Generator Power Report provides information regarding the generator backup power system and its ability to handle a utility power outage while still complying with the intended redundancy design. The report is generated after a representation of your backup generator system is created and configured using the Generator Power Configuration Utility.

NOTE: This report requires a license to be used. Contact your Schneider Electric representative for more information.

The Generator Power Report data depends on the selections you make while configuring the report and the contents of the Power Monitoring Expert database. See ["Generator Power Capacity Report measurements" on page 118](#) for more details on the Generator Power Report data.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.

Generator Power Capacity Report measurements

The Generator Power Report uses a priority table to determine which measurement to use for querying power data for a load.

The table is stored in the Power Monitoring Expert database, and consists of a list of measurement IDs with a priority value for each measurement. When the report is querying for data, it iterates through the measurement list according to the priority and queries the database for load data. Once data is found, it is returned in the report.

By default, the table GEN_CapacityMeasurement holds four known measurements:

Priority	Measurement ID	Measurement Name
1	116	Active Power Sliding Window Demand Delivered
2	107	Active Power Sliding Window Demand Delivered-Received
3	128	Active Power Mean
4	193	Active Power

Measurement ID	Devices Found
116	ION7650
107	ION7650, Modbus devices: BCPM, CM2000, CM3000, CM4000, Micrologic A and E (for CompactNSX breakers), EM5600, Micrologic E, H, P (for Masterpact breakers), PM1200 and PM800
128	ION7650
193	Modbus devices: CM2000, CM3000, CM4000, Micrologic A and E (for CompactNSX breakers), EM5600, Micrologic E, H, P (for Masterpact breakers), PM1200, PM800, Sepam 40 series and Sepam 80 series

UPS Power Configuration Utility

The Uninterruptible Power Supply (UPS) Power Configuration Utility lets you create, edit, and manage one or more UPS systems that will be used for reporting on the power capacity of those systems. The UPS Power Configuration Utility window contains a grid area and an editor area. The grid area is initially empty but is populated with entries you create. The editor area displays the configuration diagrams and allows you to define and modify the configurations.

The UPS system consists of UPS groups, modules, and loads. The configuration utility lets you organize the components of the system graphically and define properties for each component.

For information on UPS redundancy types, see ["UPS system redundancy types" on page 286](#).

UPS Power configuration restrictions

The UPS Power Configuration Utility enforces certain rules when you create UPS systems, groups, and modules:

- **UPS System**
 - Name must be unique.
 - One or more systems are allowed.
- **UPS Groups**
 - Name must be unique.
 - At least one group must be present in each system.
 - A maximum of three groups are allowed in each system.
 - For N, N+1, and N+2 system types:
 - Each group in the system may have a different number of UPS modules.
 - Each UPS module in the group must have the same nameplate rating (kVA) value.
 - Each UPS module in the group must have the same derated nameplate rating (kW) value

- Each group is connected to one load only. No other group can be connected to the same load.

See the ["UPS Power Configuration Utility" on page 119](#) for more information.

- For 2N, 2(N+1) and 2(N+2) system types:
 - All groups must have the same number of UPS modules.
 - All UPS modules in the groups must have the same nameplate rating (kVA) value.
 - All UPS modules in the groups must have the same derated nameplate rating (kW) value.
 - Depending on the number of groups present in the system, a load may be shared by two groups.

See the ["UPS Power Configuration Utility" on page 119](#) for more information.

- **UPS Modules**

- Name must be unique.
- At least one module must be present in each group.
- A maximum of 12 modules is allowed in each group.

Starting the UPS Power Configuration Utility


To start the UPS Power Configuration Utility:

- Double-click the **UPS Power Configuration Utility** icon in the **Power Monitoring Expert DC Ed** folder located on the desktop,
or
- Click **Start > All Programs > Schneider ElectricStruxureWare Power Monitoring Expert DC Ed > UPS Power Configuration Utility**.

Defining UPS systems

A UPS system is a logical system configuration that is used for reporting power capacity.

The following image is an example of the UPS Power Configuration Utility with a sample generator system selected.




Control	Description
Help	Opens the help for the utility.
New	Creates a new entry in the grid.
Delete	Deletes the selected entry from the grid.
OK	Saves all changes and exits the utility.
Cancel	Exits the utility without saving changes.
Apply	Saves all changes and leaves the utility open.


Grid Area Columns	Description
Modified	Displays a status symbol for the record.
+ (plus)	A new entry.
* (asterisk)	An existing entry has been modified.
! (exclamation mark)	The entry is incorrect.
System	Displays the system name.
Type	Displays the UPS system type (N, 2N, N+2, etc)
Description	Displays a description of the system

To define a UPS system:

- 1. Click **New**. The Edit System: New System area appears below the grid.



- 2. Click anywhere in the editor area. The Properties screen appears.



- 3. Complete the details for the UPS system:
 - a. **System Name:** Enter a name for the UPS system. Each UPS system must have a unique name.
 - b. **Description:** Enter a description for the UPS system. This field is optional.

- c. **Redundancy Type:** Select the redundancy type for the UPS system. The different redundancy types are explained in ["UPS system redundancy types" on page 286](#).
- d. **Groups:** Shows the number of UPS groups contained in the UPS system. Click **Add** to add groups to the UPS system. Click **Remove** to delete groups.
- e. **Modules Per Group:** Shows the number of UPS modules in each group in the system. Click **Add** to add UPS modules to the group. Click **Remove** to delete modules.

This property is only available when the system redundancy type is 2N, 2(N+1) or 2(N+2). To define the number of modules for a system with redundancy type N, N+1 or N+2, use the UPS group properties. See ["Defining UPS loads" on page 125](#) for more information.

- 4. Click **Done** to save the UPS system.

Now you can configure the other components of the system:

["Defining UPS groups" on page 123](#)

["Defining UPS modules" on page 124](#)


["Defining UPS loads" on page 125](#)

Defining UPS groups

A UPS group represents a logical grouping of UPS modules. The UPS system contains at least one UPS group and can contain multiple UPS groups. Depending on the UPS system type, the UPS group properties may be different, as shown below. See ["UPS Power configuration restrictions" on page 119](#) for more information.

To define a UPS group:

1. Click on the group object border. The Properties screen appears.




2. Complete the details for the UPS group:
 - a. **Group Name:** Enter a name for the group. Each UPS group must have a unique name.
 - b. **Description:** Enter a description for the group. This field is optional.
 - c. **Modules Per Group:** Click **Add** to increase the number of UPS modules in the group. Click **Remove** to decrease the number. This property is available only for system redundancy types N, N+1 or N+2.
3. Click **Done** to save the UPS group.

Defining UPS modules

A UPS module represents an actual UPS device in the data center. A UPS group contains at least one UPS module and can contain multiple UPS modules. For some UPS system types, each UPS group must contain the same number of UPS modules. See ["UPS Power configuration restrictions" on page 119](#) for more information.

To define a UPS module:

1. Click on the module object border. The selected module will be highlighted in blue and the Properties screen appears.




2. Complete the details for the UPS module:
 - a. **UPS Module Name:** Enter the name for the module. This name must be unique for each UPS module in the system.
 - b. **Description:** Enter a description for the module. This field is optional.
 - c. **Data Source:** Select the meter source in Power Monitoring Expert where load data is logged for the UPS module. The source must be unique for each UPS module.
 - d. **Nameplate Rating (kVA):** Enter the maximum output power (kVA) of the UPS module. This value must be greater than zero.
 - e. **Derated Nameplate Rating (kW):** Enter the maximum power capacity (kW) that the UPS module is expected to support. This value must be equal or less than the nameplate rating value, and greater than zero.
3. Click **Done** to save the UPS module.

Defining UPS loads

A UPS load represents the logical load attached to a UPS group. This logical load has no functional purpose in the calculations for power redundancy. The UPS load is used only to provide a more complete diagram representation for the UPS system.

To define a UPS load:

1. Click the UPS load element in the system diagram. The Properties screen appears.



2. Complete the details for the UPS load:
 - a. **Load Name:** Enter a name for the load.
 - b. **Description:** Enter a description for the load. This field is optional.
3. Click **Done** to save the UPS load.

UPS Power Report

The UPS Power Report data depends on the selections you make while configuring the report and the contents of the Power Monitoring Expert database. See ["UPS Power Report Capacity measurements" on page 126](#) for more details on report data.

NOTE: This report requires a license to be used. Contact your Schneider Electric representative for more information.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.

UPS Power Report Capacity measurements

The UPS Power Report uses a priority table to determine which measurement to use for querying power data for a UPS module.

The table is stored in the Power Monitoring Expert database, and consists of a list of measurement IDs with a priority value for each measurement. When the report is querying for data, it iterates through the measurement list according to the priority and queries the database for load data. Once data is found, it is returned in the report.

By default, the table GEN_CapacityMeasurement holds four known measurements:

Priority	Measurement I D	Measurement Name
1	116	Active Power Sliding Window Demand Delivered
2	107	Active Power Sliding Window Demand Delivered-Received
3	128	Active Power Mean
4	193	Active Power

Measurement I D	Devices Found
116	ION7650
107	ION7650, Modbus devices: BCPM, CM2000, CM3000, CM4000, Micrologic A and E (for CompactNSX breakers), EM5600, Micrologic E, H, P (for Masterpact breakers), PM1200 and PM800
128	ION7650
193	Modbus devices: CM2000, CM3000, CM4000, Micrologic A and E (for CompactNSX breakers), EM5600, Micrologic E, H, P (for Masterpact breakers), PM1200, PM800, Sepam 40 series and Sepam 80 series

Power Efficiency

Power Efficiency helps you manage and report on monitoring devices that make up the power loss system, and report on branch Power Usage Effectiveness (PUE) and average power consumed for the IT equipment running in a data center facility.

Power Efficiency includes the following configuration tool:

- ["Power Losses Configuration Utility" on page 128](#)

Power Efficiency includes the following reports:

- ["Power Losses Report" on page 132](#)
- ["Power Usage Effectiveness \(PUE\) Summary Report" on page 133](#)

Power Losses Configuration Utility

The Power Losses Configuration Utility allows you to create, edit, and manage the different logical sources, such as transformers or UPS modules monitoring devices that make up the power losses system. It is this system that is used for reporting on its losses.

The Power Losses Configuration Utility window consists of two tabbed panes labeled **Transformers** and **UPS Modules**. Each pane contains a grid area and an editor area. The grid area is empty initially but is populated with entries you create using the editor area. Use the editor area to define the settings for new items, or to update the settings for an item that you select in the grid area.

Before you can generate a Power Losses Report, you need to define a power losses system using the Power Losses Configuration Utility.

The following image is an example of the Power Losses Configuration Utility.

Power Losses Configuration Utility

Transformers UPS Modules

Help New Delete

Modified	Name	Description	Input Side Meter	Output Side Meter	Type
----------	------	-------------	------------------	-------------------	------

No Transformer selected

Name:

Input Side Meter Source:

Description:

Output Side Meter Source:

Low Voltage/Medium Voltage:

OK Cancel Apply

Control	Description
Help	Opens the help for the utility.
New	Creates a new entry in the grid.
Delete	Deletes the selected entry from the grid.
OK	Saves all changes and exits the utility.
Cancel	Exits the utility without saving changes.
Apply	Saves all changes and leaves the utility open.

Grid Area Columns	Description
Modified	Displays a status symbol for the record.
+ (plus)	A new entry.
* (asterisk)	An existing entry has been modified.
! (exclamation mark)	The entry is in error.

Power Losses configuration restrictions

The Power Losses Configuration Utility enforces certain rules when you create a power losses system:

- **All Devices**

- Name must be unique.
- A meter source must be assigned only once to a particular device.

- **Transformers**

- Zero, one, or more low voltage transformers may be present in the power losses system.
- Zero, one, or more medium voltage transformers may be present in the power losses system.

- **UPS Modules**

- Zero, one, or more UPS modules may be present in the power losses system.

Define the Power Losses components

To start the Power Losses Configuration Utility, either:

- Double-click the **Power Losses Configuration Utility** icon located in the **Power Monitoring Expert DC Ed** folder,
or
- Click **Start > All Programs > Schneider Electric > StruxurerWare Power Monitoring Expert DC Ed > Power Losses Configuration Utility**.

Select the appropriate tab to define the following power losses components:

["Defining transformers for Power Losses" on page 130](#)

["Defining UPS modules for Power Losses" on page 131](#)

Defining transformers for Power Losses

To define a transformer used in your power losses system:

1. Select the **Transformers** tab.
2. Click **New**. The editable fields are enabled.

The screenshot shows the 'Power Losses Configuration Utility' dialog box with the 'Transformers' tab selected. The 'UPS Modules' tab is also visible. The 'Help' button is on the left, and 'New' and 'Delete' buttons are on the right. Below these buttons is a table with columns: Modified, Name, Description, Input Side Meter, Output Side Meter, and Type. The table is currently empty. Below the table, the text 'No Transformer selected' is displayed. Under this text, there are four input fields: 'Name' (a text box), 'Description' (a text box), 'Input Side Meter Source' (a dropdown menu with 'Unassigned' selected), and 'Output Side Meter Source' (a dropdown menu with 'Unassigned' selected). Below these, there are two more dropdown menus: 'Low Voltage/Medium Voltage' (with 'Low Voltage' selected) and 'Low Voltage' (with 'Low Voltage' selected). At the bottom right of the dialog box are 'OK', 'Cancel', and 'Apply' buttons.

3. Define the transformer:
 - a. **Name:** Enter a unique name for the transformer.
 - b. **Description:** (Optional) Enter a description for the transformer. For example: make, model.
 - c. **Input Side Meter Source:** Select a source name from the drop-down list. The source represents the Power Monitoring Expert device that records the electrical data from the input side of the transformer. ["Power Losses Report measurements" on page 132](#) for more information.
 - d. **Output Side Meter Source:** Select a source name from the dropdown list. The source represents the Power Monitoring Expert device that records the electrical data from the output side of the transformer. ["Power Losses Report measurements" on page 132](#) for more information.
 - e. **Low Voltage/Medium Voltage:** Select Low Voltage or Medium Voltage from the drop-

down list to indicate the transformer voltage rating type.

Power Losses Configuration Utility

Transformers UPS Modules

[Help](#) New Delete

Modified	Name	Description	Input Side Meter	Output Side Meter	Type
+	Transformer Test		MAIN.DP_1	MAIN.DP_7	Low Voltage

Edit: New Transformer

Name: Transformer Test

Description:

Input Side Meter Source: MAIN.DP_1

Output Side Meter Source: MAIN.DP_7

Low Voltage/Medium Voltage: Low Voltage

OK Cancel Apply


4. Click **OK** to save the transformer.

Defining UPS modules for Power Losses

To define a UPS module used in your power losses system:

1. Click the **UPS Modules** tab.
2. Click **New**. The editable fields are enabled.
3. Define the UPS module:
 - a. **Name:** Enter a unique name for the UPS module.
 - b. **Description:** (Optional) Enter a description for the UPS module. For example: make, model.
 - c. **Input Side Meter Source:** Select a source name from the drop-down list. The source represents the Power Monitoring Expert device that records the electrical data from the input side of the UPS module. ["Power Losses Report measurements" on page 132](#) for more information.
 - d. **Output Side Meter Source:** Select a source name from the drop-down list. The source represents the Power Monitoring Expert device that records the electrical data from the output side of the UPS module. ["Power Losses Report measurements" on page 132](#) for more information.

information.



- 4. Click **OK** to save the UPS module.

Power Losses Report

The Power Losses Report provides the breakdown of the cost of various losses throughout a Data Center's power system and to lets you analyze and quantify the cost of inefficiencies due to transformers (MV and LV) and UPS modules.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.

Power Losses Report measurements

The Power Losses Report uses a priority table to determine which measurement to use for querying energy and power data for the different devices defined in the power losses system.

The table is stored in the Power Monitoring Expert database, and consists of a list of measurement IDs with a priority value for each measurement. When the report is querying for data, it iterates through the measurement list according to the priority and queries the database for the specific type of data. Once data is found, it is returned in the report.

The report also looks for different types of logical measurements, cataloged in a separate Measurements table.

By default, the table PSL_PSLMeasurementCategory holds two known measurements:

Category ID	Category Name
1	Power
2	Energy

By default, the table PSL_PSLMeasurementPriorityMapping holds the following information:

Category ID	Physical ID	Priority	(Physical) Measurement Name
1	116	1	Active Power Sliding Window Demand Delivered
1	107	2	Active Power Sliding Window Demand Delivered-Received
1	128	3	Active Power Mean
1	193	4	Active Power
2	129	1	Active Energy Delivered
2	135	2	Active Energy Delivered-Received
3	13	1	Current Phase Average Sliding Window Demand Delivered
3	12	2	Current Phase Average Mean
3	182	3	Current Phase Average

Devices that provide *Power* measurements:

Measurement ID	Devices Found
116	ION7650
107	ION7650, Modbus devices: BCPM, CM2000, CM3000, CM4000, Micrologic A and E (for CompactNSX breakers), EM5600, Micrologic E, H, P (for Masterpact breakers), PM1200 and PM800
128	ION7650
193	Modbus devices: CM2000, CM3000, CM4000, Micrologic A and E (for CompactNSX breakers), EM5600, Micrologic E, H, P (for Masterpact breakers), PM1200, PM800, Sepam 40 series and Sepam 80 series

Devices that provide *Energy* measurements:

Measurement ID	Devices Found
129	ION7650
135	ION7650, Modbus devices: BCPM and Micrologic E (for Masterpact breakers)

Devices that provide *Current Phase Average* measurements:

Measurement ID	Devices Found
13	---
12	ION7650
182	ION7650 Modbus devices: CM2000, CM3000, CM4000, Micrologic A and E (for CompactNSX breakers), DM6200, EM5600, Micrologic E, H, P (for Masterpact breakers), PM1200, PM200, PM700 and PM800

Power Usage Effectiveness (PUE) Summary Report

The Power Usage Effectiveness (PUE) Summary Report displays PUE and average power consumed for a data center facility, along with average power consumed for the IT equipment running in the facility. Additionally, two graphical trends are displayed in a dashboard that corresponds to the facility PUE values and to the energy consumption of the facility.

NOTE: The PUE Report does not require the data center VIP to be configured. See the "VIP" section *Power Monitoring Expert 8.2 – Data Center Edition Commissioning Guide*. However, the framework does provide an example of the aggregation of power for the data center and the IT Load, and the resulting calculation of interval energies that are required for the report to run.

This section provides an overview of the PUE Summary Report and includes:

- Definitions of some of the terms associated with PUE
- PUE Summary Report prerequisites
- Calculations used to generate the PUE Summary Report.

Terms and Definitions

- **PUE** – Power Usage Effectiveness, defined as a ratio between the total power consumed by a data center facility and the power consumed by the IT equipment that runs in the facility. For example, a PUE value of 2.0 indicates that for every watt of IT equipment power consumed, an additional watt is consumed to operate the facility that houses the equipment (e.g. equipment cooling, power distribution to the equipment).
- **Total Data Center Power** – Represents all the power consumed by the data center facility at one point in time. This value should represent an instantaneous power consumption value.
- **Total Data Center Energy** – Represents all the energy used by the data center facility for a given time interval. This value typically represents a 15-minute energy usage value.
- **Total IT Equipment Power** – Represents all the power consumed by the IT equipment used in a data center facility at one point in time. This value should represent an instantaneous power consumption value
- **Total IT Equipment Energy** – Represents all the energy used by the IT equipment in the data center facility for a given time interval. This value typically represents a 15-minute energy usage value.
- **Support** – Represents the overhead amount of energy or power required to operate the data center, which does not account for IT equipment power consumption. This value represents the data center power distribution losses, as well as the power consumed to cool down the data center facility.

Prerequisites


Before a PUE Summary Report can be successfully generated, the following prerequisites must be met:

- Power Monitoring Expert 8.2 – Healthcare Edition is installed and operational.
- The proper licensing is obtained for this module.
- Reporter is installed and functional.
- The Power Monitoring Expert database contains Total Data Center Power and Total Data Center Energy data, as well as Total IT Equipment Power and Total IT Equipment Energy, as defined in the previous section.
- The PUE Summary Report Pack is installed and operational.
- **IT Equipment Power Measurement:** Click **Select Measurement** to choose the measurement for instantaneous power consumption for all the IT equipment used.

NOTE: Confirm that the Data Center source and the IT Equipment source entries are correct before generating a report. If these entries are not correct, the generated report can contain inaccurate information.

PUE Summary Report Example

The sections and content contained in the PUE Summary Report depend on the selections made in the PUE Summary Report template and the contents of the Power Monitoring Expert database. See the following sample report.



PUE Summary Report Calculations

In this sample, all time periods are based on July 25, 2013.

24 Hours	7 Days	30 Days	Last 12 Months
From July 24 12:00AM until July 25 12:00AM	From July 18 12:00AM until July 25 12:00AM	From June 25 12:00AM until July 25 12:00AM	From July 25, 2012 12:00AM until July 25, 2013 12:00AM

The values in the table below are calculated as follows:

Reporting Period	Start Date and Time	End Date and Time	PUE	Average Load	
				Data Center	IT Equipment
24 Hours	7/24/2014 12:00:00 AM	7/25/2014 12:00:00 AM	1.99	70 kW	35 kW
7 Days	7/18/2014 12:00:00 AM	7/25/2014 12:00:00 AM	1.98	70 kW	36 kW
30 Days	6/25/2014 12:00:00 AM	7/25/2014 12:00:00 AM	1.94	72 kW	37 kW
12 Months	7/25/2013 12:00:00 AM	7/25/2014 12:00:00 AM	1.83	57 kW	31 kW

PUE – The ratio between the data center and IT equipment energy measurement values. This value is calculated for each of the required time periods by the following formula:


PUE =	Sum of Data Center Energy
	Sum of IT Equipment Energy

IT Equipment – The average of the IT equipment power measurement values for each of the time periods.


Data Center – The average of the data center power measurement values for each of the time periods.

The values displayed in the charts below are calculated as follows:

PUE Trend - Last 12 Months with Weekly Rollup Values



Energy Trend - Last 12 Months with Weekly Rollup Values



PUE Trend – The weekly PUE values are calculated by the following formula where N represents a week of the year:

PUE week N =	Sum [Data Center Energy] week N
	Sum [IT Equipment Energy] week N



Energy Trend – The weekly energy values for IT equipment and support are calculated by the following formulas where N represents a week of the year:

IT Equipment Energy week N = Sum [IT Equipment Energy] week N

Support Energy week N = Sum [Data Center Energy] week N - Sum [IT Equipment Energy] week N

Power Quality Advisor

Power Quality (PQ) Advisor displays complex power quality information in a simpler form.



See *StruxureWare Power Monitoring Expert Power Quality Advisor – Design Guide* for more information on the PQ Advisor features.

Monitoring devices configuration

The PQ Advisor can perform an analysis only when monitoring devices (power meters, circuit breakers) have been properly configured to capture power quality events and disturbances. This section describes the following:

- "Enable power quality event detection" on page 138.
- "Enable power quality disturbance logging" on page 139.
- "Enabling time synchronization" on page 140.

See *StruxureWare Power Monitoring Expert Power Quality Advisor – Design Guide* for more information on power quality events and disturbances.

Enable power quality event detection

See ["PQ Advisor - Supported meters" on page 294](#) for supported devices.

Enabling power quality event detection on the supported meters involves:

- Enabling Sag/Swell detection
- Enabling Transient detection

Disturbance direction detection (DDD) is enabled by default if supported.

NOTE: DDD, available on select meters, is used to determine if the events are undetermined, internal, or external to the system. Without DDD, all events will show as undetermined in the PQ Advisor features.

You can do this by using meter configuration tools (such as ION Setup), or by configuring the meter directly. Refer to the meter documentation for more information.

In addition, you can configure ION meters (such as, ION7650, PM8000, etc.), in PME Vista.

Victoria_Bertram.DataCenter_Lab Back to Power Quality

Power Quality Setup

Enables	Sag/Swell	Limit Learning
Sag/Swell recording ☒	Click to change value, then press Enter	
Waveform recording ☒	Swell limit 110	Learned Swell limit
Harmonics Logging ☒	Sag limit 90	Learned Sag limit
Transient detection ☒	Change criteria 10	Learn Duration (days) 30
	Nominal voltage 120	* Learn Mode Manual
		Start Learning
	Transient	
	Click to change value, then press Enter	
	Threshold 125	Learned Threshold
		Learn Duration (minutes) 30
		* Learn Mode Manual
		Start Learning

* If Learn Mode is Automatic, learned limits will be applied when learning is complete

Device Time 3/17/2016 01:33:43.093 PM
Device Type 7650

After the power quality events are detected by the meter, they are classified by PME Power Quality Event Classification method and stored in PME database as:

- Interruptions
- Voltage Sag
- Voltage Swell
- Transient Voltage
- Over voltage
- Under voltage

See *StruxureWare Power Monitoring Expert – Design Guide* for more information on PME Power Quality Event Classification.

Enable power quality disturbance logging

PQ Advisor consumes the periodical data logs for:

- Voltage Unbalance
- Current Unbalance
- Voltage Harmonics
- Current Harmonics
- Frequency Variation
- Flicker

The supported meters are listed in ["PQ Advisor - Supported meters" on page 294](#). They are categorized as:

- **Logged by Default** – The supported measurements are logged by the default. For these meters, no additional configuration is required. However, for brownfield installations, care must be taken to see if the configuration has been modified.
- **Not Logged by Default** – The meter measures the value but does not log it. You need to enable logging on these meters.

Choose the measurement to log

The supported measurements and their corresponding register labels are in ["PQ Advisor - Supported measurements" on page 296](#).

For example, for Voltage Unbalance, you may find both of the supported registers Voltage Unbalance L-L Worst and Voltage Unbalance L-N Worst available in a non-ION device. Choose the one which is required by your local standards.

Or, for Voltage Harmonics, you may find all of the 8 supported registers available in a non-ION device. If per-phase analysis is important to the customer on this device, choose the 3 per-phase measurements based on your system and standards. If per-phase analysis is not important (because of the load, design, or other reasons), choose only one measurement; either THD Voltage L-L or THD Voltage L-N, which are the averages of the per-phase values.

NOTE: For each disturbance category, choose only the appropriate/necessary measurements from the supported list to log. Do NOT log all of them; doing so can cause unwanted database growth and performance issues.

Enable device logging

To enable the logging for devices categorized as "Not Logged by Default":

- Supported measurements are logged by default for most ION meters, so configuration is not required. For some models, where the supported measurements are not logged by default, you can configure logging by using PME Designer.
- For non-ION meters, you can use PME Modbus Device Importer to configure logging:

NOTE: For non-ION devices, PQ Advisor only supports the logged instantaneous values. Do NOT log the calculated values (Mean, High, or Low). For Harmonics and Unbalance measurements, the recommended logging Interval is 3600 seconds.

Configure Logging and Calculation

☐ Show downstream device columns

Select rows in the grid below
Use the Editors below the grid to configure the selected rows

Register	Modbus Register	Log	All	Mean	High	Low
Label			Interval	Calculate	Calculate	Calculate
Voltage Unbalance C-A	403042	☐	900	☐	☐	☐
Voltage Unbalance C-N	403050	☐	900	☐	☐	☐
Voltage Unbalance L-L Worst	403044	☐	900	☐	☐	☐
Voltage Unbalance L-N Worst	403052	☒	900	☐	☐	☐
Voltage Unbalance-Ack Status	411079	☐	900	☐	☐	☐
Voltage Unbalance-Alarm Count	413549	☐	900	☐	☐	☐
WAGES External Demand Elapsed Time...	403724	☐	900	☐	☐	☐
WAGES External Demand Elapsed Time...	403725	☐	900	☐	☐	☐
WAGES External Demand Interval	403722	☐	900	☐	☐	☐
WAGES External Demand Sub-Interval	403723	☐	900	☐	☐	☐

Register

☒ Log

All

Log Interval: 900 Seconds

☐ Is Downstream Device

Downstream Device Name:

☐ Include Name of Device Instance

Mean

☐ Calculate

☐ Log

High

☐ Calculate

☐ Log

Low

☐ Calculate

☐ Log

OK Cancel

See *StruxureWare Power Monitoring Expert – User Guide* for more information on using Designer and Modbus Device Importer.

- For the non-ION meters, especially PM800 (except PM810 without PME810LOG), CM3000, and CM4000, configure the on-board logging using meter configuration tools.

NOTE: The PM800 Series devices are supported, except the PM810 without PM810LOG.

Flicker

Flicker is only available when the supported meter has a PQ framework with EN50160 evaluation enabled. Refer to the meter documentation for more information.

Once enabled, the flicker measurements are logged in 10-minute intervals by default. There is no need to change the logging interval.

Enabling time synchronization

Time synchronization is crucial for:

- Event clustering (the same event seen by different devices is only counted once).
- Correctly associating the process impact alarms with power quality events.


The standard synchronization between the Power Monitoring Expert server and devices is adequate for enabling PQ Advisor features.

- For Modbus devices, time synchronization through Modbus is activated by default.
- For all ION protocol devices (e.g. ION7650, PM8000, etc.), the application engineer needs to enable this feature.

NOTE: High accuracy of time synchronization (such as IRIG-B, etc.), can be used to address user requirements, but it is not required for PQ Advisor.


To enable Power Monitoring Expert time synchronization on an ION device:

1. Connect to the device using ION Setup. On the **Timezone** tab for **Clock**, change entry for the **CL1 Time Sync Source** to **ETHERNET - ION**. You can also do this on the meter front panel.




2. In Management Console:

- a. For an Ethernet device, set the **Time Synch Ethernet Enabled** to **Yes** in the **Ethernet Device Configuration**.



- b. For a serial device, set the **Time Synch ION Enabled** to **Yes** in the **Ethernet Gateway**

Site Configuration.


Ethernet Gateway Site Configuration	
Name	TestLabSite
TCP/IP Address	10.168.26.36
TCP/IP Port	EtherGate COM1 7801
Computer	STANDALONE
Time Synch ION Enabled	Yes
Time Synch 3XXX Enabled	No
Time Synch 3720 Enabled	No
Enabled	Yes
Description	

Global parameters configuration


Depending on the requirement of the customer's facility you might need to change the global parameters.

Changing the nominal frequency

The default nominal frequency is 60Hz.

To edit the default nominal frequency:

1. In SQL Server Management Studio, locate the `dbo.vCFG_ConfigItems` view in the `ION_Net-`work database, and right-click to select "Edit Top 200 Rows".



2. Find the **Frequency Nominal** row.
3. Set the Value to the appropriate local nominal frequency. For example:

Module	Category	Item	Value
PQAnalytics	General Settings	Frequency Nominal	60


PQ Advisor Diagrams configuration

The following topics describe how to configure the PQ Advisor diagrams:

- ["Power Quality Indicator Diagrams configuration" on page 143](#)
- ["Standardized Equipment Diagrams configuration" on page 146](#)
- ["Optional - Creating a PQ Advisor tab in the Web Applications" on page 167](#)

Power Quality Indicator Diagrams configuration

The Power Quality (PQ) Indicator Diagrams introduce simple green-yellow-red indicators for the most common power quality problems.



The PQ Indicator Diagrams are pre-configured with default settings. To enable the PQ Indicator Diagrams complete the following steps:

- ["Pasting the PQ Advisor Framework" on page 143](#)
- ["Open the Power Quality Indicator Diagrams" on page 144](#)

Pasting the PQ Advisor Framework

The VIP Frameworks included with the PQ Advisor installation get data from the PQ Advisor Web Service in order to display values and drive the status objects in the PQ Advisor Indicator Vista Diagrams.

NOTE:


- The VIP.PQADVISOR ION Service must be running to proceed with the steps below. (The service is configured to start automatically.)
- Installing the PQ Advisor framework onto an ION VIP Service other than VIP.PQADVISOR is not recommended.
- Installing the PQ Advisor framework onto an ION VIP Service that has existing modules that have been put in by a user is not recommended.

1. Open Power Monitoring Expert Designer.
2. Click **File > Open**.

3. Click the 'VIP.PQADVISOR' node and click **OK**.
4. Select the **Edit > Paste from framework** menu item.
5. Navigate to the folder containing the PQ Advisor Framework file: `{root install folder-}\config\fmwk\PQ_Advisor`
6. Click the file `PQAdvisor_v1.0.0.0.0.fwn` and click **Open**.

NOTE: Use the most current version of the fwn file available.

7. In the Paste Summary dialog:
 - a. Ignore items with a red check mark, as these are core modules that cannot have two instances in the same VIP. The existing modules will work with the new framework being pasted.
 - b. In the **Source** column, select the first list entry with a green check mark, press and hold the **Shift** key, and then click the green check mark icon in the check box on the final entry. This action applies the lock paste selection to all of the entries.



NOTICE

UNINTENDED DEVICE OPERATION

- Do not use the lock paste option to overwrite existing destination modules.
- Only use the lock paste option if you are an advanced user familiar with ION architecture.

Failure to follow these instructions can result in operational differences in required modules.


- c. In a new Power Monitoring Expert installation, no modules should be overwritten. In an existing Power Monitoring Expert installation there may be conflicts and the framework paste may try to overwrite existing module; if this occurs double click the check box again so that it returns to just a check mark, and note the module that created a conflict.
8. Press **OK** when pasting is complete.
The PQ Advisor framework is visible in Designer.
9. Click **Save** to complete the process.

Open the Power Quality Indicator Diagrams

The PQ Indicator Diagrams are located in:

`{root install folder}\config\diagrams\ud\PQ_Advisor`


The diagrams start to function once the framework is pasted in the PQ Advisor VIP. You can link them to the existing Vista diagrams or use them separately.



NOTE: When a Power Quality Indicator has no supported device to feed it the required data, it should be disabled by following the procedures in the section ["Disable unused Power Quality Indicators" on page 189](#).

Alternative symbols can be used to provide a colorblind friendly view. They are located in the folder:

```
{root install folder}\config\diagrams\images\ PQ_
Advisor\Indicators\Alternate\
```



Set the Query Server – Distributed system only

When using distributed PME systems, set the query server node for the following landing page diagrams:

- PQAdvisor_LandingPage_24h_V1.0.0.0.0.dgm
- PQAdvisor_LandingPage_7d_V1.0.0.0.0.dgm

- PQAdvisor_LandingPage_30d_V1.0.0.0.0.dgm
- PQAdvisor_LandingPage_12m_V1.0.0.0.0.dgm

Standardized Equipment Diagrams configuration

The following sections describe how to set up and configure the Standardized Equipment Pages. Skip this section if corrective equipment does not exist in the system.

- Configure the Framework for the Equipment Diagrams
- Configure the Equipment Diagram Detail Pages
- Configure the Equipment Diagram Group Pages
- Configure the Equipment Diagram Landing Pages


Unlike the PQ Advisor Indicator diagrams, the Equipment diagrams are not auto-functional pages, but rather templates that you use during commissioning to provide the user with equipment status displays with the same user experience and focus on simplification as the PQ Advisor Indicator pages.

The equipment diagram elements are:


- Equipment Diagram Landing Pages
- Equipment Diagram Grouping Pages
- Equipment Diagram Detail Pages

Equipment Diagram Landing Pages

The Corrective Equipment Status portion of the Power Quality Advisor page is a landing page.




The Equipment page is also a landing page.




Equipment Diagram Grouping Pages

When you select an element of the Equipment landing page (e.g. Capacitor Banks), the grouping page opens. A summary entry for each device (e.g. Capacitor Bank) in the system could be configured here.



Equipment Diagram Detail Pages

When you select an element on the Equipment Grouping Page, the equipment diagram detail page for that device opens.



The following supported devices currently have template pages available:


- Capacitor Banks: [VarPlus Logic VL6 and VL12](#)
- Active Harmonic Filters (AHF): [Accusine PCS+/PFV+](#)
- Uninterruptible Power Supplies (UPS): [Galaxy 5000 and 5500](#)

All Equipment Diagrams are installed in the following location:

{root install folder}\config\diagrams\ud\Equipment

Configuration Workflow

The order of commissioning is the opposite of user workflow. Set up the Detail Pages first, and then create the buttons for each Detail Page on the Group Pages. The Landing Pages (both Equipment and PQ Advisor Indicator), require no commissioning other than optional customization if required.




Configuring the Framework for the Equipment Diagrams

Configure the Equipment Pages of the VIP framework to display aggregated warning/alarm indicators found on the PQ Advisor Indicator Landing Pages and on the Equipment Landing and Group Pages.


NOTE: The VIP.PQADVISOR service must be set up and running with the Equipment Status Indicator Framework configured in order to commission the Equipment Diagrams.

The PQ Advisor Framework contains some template OR Logic modules and simple instructions on configuring the VIP to work with the Equipment Pages:

1. Open the VIP.PQADVISOR framework in Designer.
2. Open the **Equipment** grouping folder.



The Equipment folder contains the following:



Summary Section:

Equipment Status Aggregation Framework

This framework drives the equipment status indicators on the Power Quality Advisor Landing and Equipment Pages Vista Diagrams. Connect boolean status indicators from equipment within the ION network below using Distributed Boolean, External Boolean Input, etc. ION Modules.

DEVICE COUNTS

+

-

x

÷

Capacitor Bank section:

Capacitor Banks

Copy this template module for each device. Connect desired alarm/fault inputs from the device on the inputs.

Cap Bank Group Item: TEMPLATE

^^^Equipment group page indicators connect to this module.

Equipment Landing and Power Quality Advisor indicators connect to the subsequent module.>>>

Force Cap Bank Landing Red

Cap Bank Landing Page

Active Harmonic Filters section:

Active Harmonic Filters

Copy this template module for each device. Connect desired alarm/fault inputs from the device on the inputs.

AHF Group Item: TEMPLATE

^^^Equipment group page indicators connect to this module.

Equipment Landing and Power Quality Advisor indicators connect to the subsequent module.>>>

Force UPS Red

AHF Alarm Landing Page

The UPS section:

UPS

Copy this template module for each device. Connect desired alarm/fault inputs from the device on the inputs.

UPS Group Item: TEMPLATE

^^^Equipment group page indicators connect to this module.

Equipment Landing and Power Quality Advisor indicators connect to the subsequent module.>>>

Force AHF Red


UPS Landing Page

Page 150 of 300

© 2017 Schneider Electric. All Rights Reserved.

Configuring device count

1. Right-click the module labeled **DEVICE COUNTS** to open the ION Module Setup dialog.
2. Double-click any of the 'Formula' Setup Registers to modify their value. The value entered represents the number of devices of corresponding type listed directly to the right in the Output Registers list.




3. Repeat Step 2 until there is a device count number for each of the listed devices.

Configuring equipment status


1. Start with the set up of the capacitor bank by duplicating the template module labeled **Cap Bank Group Item: TEMPLATE** (or by creating a new AND/OR module).




2. Right-click the new module and make the following modifications:
 - a. Set the mode of operation to OR.
 - b. Enter the name of the capacitor bank device in the **Custom Label** field.



3. Link the input of the new module to a device alarm status output by performing the following steps:
 - a. Click the **ION** button on the toolbar to open the Create Link dialog.
 - b. Click the desired device, **Alarms** under **Managers**, **Low Current Alarm** under **Modules**, and **Low Current Alarm** under **Output Registers**.
 - c. Click **OK**.




- d. The cursor appears with a circle; click the input of the module and select **NEW Source**.



4. Repeat Step 3 until each of the capacitor bank's desired alarm status is connected to the module.

By doing this, the output of the module outputs a '1' (High) state if any of the connected alarm states are activated.

5. Link the output of the new module to the input of the module labeled **Cap Bank Landing Page**.




6. Repeat Steps 1-5 for each capacitor bank in the system.
7. Remove the link between the output of the template module and the input of the Landing Page module:

- a. Right-click the input of the Landing Page module.
 - b. In the resulting window select the appropriate input.
 - c. Click **Unlink**.
8. Repeat Steps 1-7 for the Active Harmonic Filter and UPS device frameworks until each desired corrective equipment device in the system is connected.
 9. **Save** the modified framework.

NOTE: The outputs of the modules configured for the individual devices drive the Equipment Group Page indicators, and the outputs of the Landing Page modules drive the Landing Page Indicators on both the Equipment Pages and PQ Advisor Indicator pages.


Configuring the Equipment Diagram Detail Pages

Each individual piece of equipment in the system can have its own detail page. These diagrams connect directly to the devices and do not have any interaction with the PQ Advisor VIP service.



To set up any of the detail pages using the provided template diagrams:


1. In Windows Explorer, open the folder location that contains the DetailPage template for one of the Equipment (UPS, Capacitor bank or Harmonic filter).




2. Highlight the template that will be used and copy it by pressing **Ctrl+C** and paste it using **Ctrl+V**.
3. When the file is pasted, it is enabled for editing. Choose a new name for the diagram file; preferably one that is easily associated with the particular device of interest.

NOTE: Take care not to overwrite the original template file by ensuring that the new file has a new and distinct file name.

4. Open the PME Vista application and ensure that the toolbox is enabled.
5. Open the new file that was created in step 3 by selecting **File > Open** and navigating to the containing folder in the dialog.
6. When the diagram opens, right-click anywhere on the background and select **Properties** on the menu.




7. In the subsequent dialog, select the **Node** tab.



8. On the **Node** tab, select **Custom** and then click **Select** to open the Select Node dialog.

9. Select the node name of the equipment for which the diagram was created, and click **OK**.




10. Click **OK** on the properties dialog, and click **Save** in Vista.

Provided the correct device was selected as the parent node of the page (that is, that the device mapping is correct), all the fields and indicators on the page should populate and be ready for use.

Verify that the device selected is the correct type for the template being used, and that the device is configured correctly.

Once the page has been linked to the node, there are a few manual steps that should be completed to customize the page:



11. Customize the page as per the graphic above:
- Update the page header to include the unique name of the device.
 - Change the picture of the device from the sample image to a custom image, such as a standard image or an actual picture of the device.
 - Update the device model name to be more specific.
12. As a final step, click the folder icon in the Overview section to view the default diagram of the device. Verify that the correct default diagram appears, and that the values and status shown

match what appears on the detail page.


Click here for more device measurements ->




13. Repeat all steps for other equipment.

Configuring the Equipment Diagram Group Pages

Group Pages display multiple devices of a particular type from a single location.



This is made possible by creating and customizing "Buttons" that consist of grouping, numeric, text, and status objects arranged to represent a clickable overview of a single device.



Group Pages set up and scaling

Before the Group Page for a particular device type can be populated, the logical organization of the device grouping must be reviewed, and multiple Group Pages need to be created if necessary.

If there are less than eight devices of the Group Page type, then proceed to the ["Group Page Buttons set up and Detail Page association" on page 163](#). If there are more than eight, more Group Page diagrams have to be created. These new pages will be linked as tabs from the main device type Group Page.

Device scaling

The first step is to determine how many diagrams will be required by counting the number of devices of the type in question. A single Group Page diagram has eight Button positions, so there will need to be a Group Page diagram for each eight devices and portion thereof. For example, if the system contains ten capacitor banks (each with its own Detail Page diagram), then there will need to be two Group Page diagrams; one page with eight buttons, one page with two.

Alternately, a different organizational scheme can be incorporated by creating a Group Page for each logical grouping of devices. For example, a separate Group Page can be created for each production line in a facility, thus allowing the user to conveniently check the active harmonic filters that are present for a production line that is experiencing problems.

Another option is to create Group Pages for different buildings or areas within a facility.

Ultimately, it is up to the deploying Application Engineer to determine the solution which makes the most sense for the user's application.

Group scaling

Each Group Page has space for six tabs, therefore, if there are more than six Group Pages required for a single device type, they need to be arranged into sub-types on the Landing page level. For example, if there were twelve Group Pages for active harmonic filters, they need to be split into two logical categories and treated separately on the Landing Page level.


For the purpose of this set up guide, assume that there are only six or less Group Pages required in the steps outlined below.

Group Page logical set up

With the number of Group Pages required in mind, complete the following preliminary setup steps:

Set up the Group Page files

1. In Windows Explorer, open the folder location that contains the Group Pages.
2. Highlight the template that will be used. Copy it by pressing **Ctrl+C** and paste it using **Ctrl+V**.
3. When the file is pasted, the file name opens for editing.



Choose a new name for the diagram file; preferably one that reflects how the Group Pages will be organized.

Note that the original file (the one that contains the word "All" or "Pg1" in the filename) will be the main Group Page that is linked to/from the Equipment landing page. For example, if one were creating an active harmonic filter Group Page for each floor of a facility the filenames would be as follows:

- a. Equipment_GroupPage__AHFAll_V1.0.0.0.0.dgm (default filename for the first floor)
- b. Equipment_GroupPage_AHF_Floor2_V1.0.0.0.0.dgm
- c. Equipment_GroupPage__AHF_Floor3_V1.0.0.0.0.dgm


And so on.

NOTE: Use the most current version of the dgm file available.


4. Press **Enter** to save the file name.
5. Repeat steps 2-3 until you create all of the required files.

Set up tabs in the First Group Page

1. Open PME Vista and ensure that the Toolbox is enabled.
2. Open the first logical Group Page file that is to be set up by selecting **File > Open** from the menu bar and navigating to the containing folder in the dialog.
3. Select the tab text (the green text **Default Group** in new installations) and press **Ctrl+C** to copy it.



4. Press **Ctrl+V** to paste up to six text boxes - one for each Group Page.
5. Arrange the text boxes evenly along the tab line in up to five additional "tab" positions.
6. Change the text color for each of the pasted text boxes (but not the original) to black:
 - a. Right-click the text box to open the Text Box Configuration dialog.
 - b. Click the **Text** tab.
 - c. Select **Custom** and click the **Font** button to open the Font dialog.
 - d. Select **Black** from the Color dropdown menu and click **OK**.
 - e. Click **OK** on the configuration dialog to complete the change.



7. Place a new Grouping Object over top of each new text box.




8. Change the shape of each new grouping object by left-clicking the object and dragging the black tabs that appear.


The objects will be what the user will click to navigate to other tabs; they should therefore cover the text underneath, and should not overlap.

9. Make each new grouping object link to the Group Page diagram referenced by the text underneath it.
 - a. Right-click the grouping to open the Grouping Object Configuration dialog.
 - b. Select the **Action** tab.

- c. Select **Open User Diagram** and click the **Browse** button to open the Choose sub-diagram dialog.



10. Make each new grouping object appear transparent to show the text underneath it.
 - a. Right-click the grouping to open the configuration dialog.
 - b. Select the **Display** tab.
 - c. Select **None**.
 - d. Click **OK** in the configuration dialog to complete the change.



11. Hold down the left mouse button and draw a marquee around all of the tab (text box and grouping) objects.
12. Press **Ctrl+C** to copy the objects.
13. Save and close the diagram.


Set up tabs in subsequent Group Pages

1. Open the next Group Page diagram by selecting **File > Open** from the menu bar and navigating to the containing folder in the dialog.
2. Delete any existing text box objects in the tab area by selecting them and pressing **Delete**.
3. Press **Ctrl+V** to paste the tab objects from the previous Group Page diagram.
4. Change the color of the text in the text box that represents the first Group Page to black (see "Setting up Tabs in the First Group Page", Step 6).
5. Add a new grouping object over top of the text that represents the first Group Page, modify it to be transparent, and link it to the first Group Page diagram file (see "Setting up Tabs in the First Group Page", Steps 8-10).
6. Delete the grouping object in the tab area that links to the current Group Page by selecting it and pressing **Delete**.
7. Change the color of the text in the text box that represents the current Group Page to green.
8. Change the background image of the diagram to one that has highlighting on the correct portion of the tab area:
 - a. Right-click any unpopulated space on the diagram area and select **Properties** on the menu.
 - b. Select the **Image** tab in the Configuration dialog.
 - c. Select **Custom Image** and click **Browse**.
 - d. In the resulting, navigate to the following location: `...\configuration\diagrams\images\Equipment_Diagrams\Backgrounds`
">
 - e. Select the correct background image.

Each Equipment diagram background image included in this installation is the same, except for the position of a green highlight in the tab area. The filename of the background image indicates where the green highlight is located. For example, "PQEquip_Lvl1BG_Pos2_V1.0.0.0.0.bmp" has a highlight in the second position from the left, indicated by the "Pos2" text in the filename. Double-click the file to complete the selection.

NOTE: Use the most current version of the bmp file available.

- f. Click **to** complete the change and to close the configuration dialog.




9. Repeat steps 1-8 until all Group Pages have the required tabs.


Group Page Buttons set up and Detail Page association

The following steps outline how to set up a Group page with custom buttons for each device that has an associated Detail Page:


1. Open Vista and ensure the Toolbox is enabled.
2. Open the Group Page file that is to be set up by selecting **File > Open** from the menu bar and navigating to the containing folder in the dialog.
3. Hold down the left mouse button and draw a marquee around the template button in the top left position of the page space, selecting all objects contained within.
4. Press **Ctrl+C** to copy the button items.



5. Press **Ctrl+V** to paste up to seven additional buttons (for a total of eight on the page); one for each device with a Detail Page.




6. Link an indicator (status) object to its corresponding ION module in the PQ Advisor Equipment VIP Framework:
 - a. Right-click the indicator (status) object.
 - b. Navigate to the correct module output by selecting the following in the Create Link dialog:
 - i. Node: VIP.PQADVISOR.
 - ii. Managers: And/OR Modules.
 - iii. Modules: the AND/OR module that was set up for the corresponding device in the [Equipment Status Indicator Framework](#) step.
 - iv. Output registers: (module designator) Result.



7. Repeat step 6 for each indicator object on the page.

8. Link the numeric objects within the button to the corresponding outputs on the device.
 - a. Right-click the numeric object.
 - b. Navigate to the correct module output by selecting the following in the 'Create Link' dialog; start by selecting the device in the 'Node' section and navigating to the desired numeric output.
9. Repeat step 8 for each numeric object on the page.
10. Link the button background to the appropriate Detail Page:
 - a. Right-click the button (grouping object) area where there is no other object (such as numeric or indicator).
 - b. Select the **Action** tab on the configuration dialog.
 - c. Select **Open User Diagram** and click **Browse**.
 - d. In the resulting window, navigate to the Detail diagram file.
 - e. Click **OK** on the configuration dialog to complete the change.



11. Repeat step 10 for each button (Grouping Object) on the page.
12. Repeat this process for each (corrective) device type in the system.
The Group Page should now be configured.
13. Repeat this process for any other Group Page diagrams in the system.

Group Button measurement linking

The measurements displayed on the Group Page buttons are linked to the device measurements by navigating to the appropriate measurement in the numeric object configuration window. To help the deploying Application Engineer, these links are listed in more detail below along with the ION Handle:

See the section called “How to Modify Indicators” in the Appendix called “How to Modify Power Quality Advisor Vista Diagrams” for instructions on how to link to ION Handles.

VarPlus Logic Capacitor Bank Button Measurement Display

Button Label	Measurement Label in Device ION Handle	
Power Factor - Target	Target Cos Phi 01	0x8502E01
Power Factor - Measured Power Factor Total		0x8803701

Accusine PCS+ Active Harmonic Filter Button Measurement Display


Button Label	Measurement Label in Device ION Handle	
Total Load Current - A Load Current A Total		0x8100001
Total Load Current - B Load Current B Total		0x8100002
Total Load Current - C Load Current C Total		0x8100003
Load Harmonic - A Load Harmonics Current A		0x810001B
Load Harmonic - B Load Harmonics Current B		0x810001C
Load Harmonic - C Load Harmonics Current C		0x810001D

Galaxy 5500 UPS Button Measurement Display

Button Label	Manager	Module	Output Register	ION Handle
Time Remaining Diagnostics2	Backup Time	Battery Time Remaining		0xb300002
Battery Voltage	Voltages	Voltage	Battery DC Voltage	0xc000018
Loading	Power Factors	Power Factor Total	Output Percent Load	0xb200001

Configuring the Equipment Diagram Landing Pages

Configuring Landing Pages is the last step in setting up the Equipment Page.



The indicators (Status Objects) on the Landing Pages are linked to the output of the respective Equipment Landing Page ION Module in the Equipment Status Indicator Framework of the VIP.PQADVISOR service.

The Equipment Counts (Numeric Objects) are linked to the 'DEVICE COUNTS' ION Arithmetic Module in the Equipment Status Indicator Framework. The number of devices of each category within the system needs to be entered into the Setup Registers of the module.

Link the button background to the appropriate Group Page:

1. Right-click the button (grouping object) area anywhere that there is no other object (such as numeric or indicator).
2. Select the **Action** tab on the Configuration dialog.
3. Select **Open User Diagram** and click **Browse**.
4. In the resulting window, navigate to the Group diagram file.
5. Click **OK** on the Configuration dialog to complete the change.
6. Save the diagram.

Customization might be needed under the following circumstances:

- There are more than six Group Pages (i.e. more than 48 devices) for a particular device.
- The customer's application demands multiple Landing Pages with custom groups of device types. An example of this is pre-configured on default Landing Page; there is a tab for all devices and a tab for corrective devices only.

When customization is required, follow the steps in this section for adding additional pages/tabs and additional buttons. Note that the background images used for the Group Pages are the same as those used in the Landing Pages.

Optional - Creating a PQ Advisor tab in the Web Applications

An optional step is to create a tab in the Web Applications interface to view the PQ Advisor Vista diagrams:

DASHBOARDS DIAGRAMS TABLES TRENDS ALARMS REPORTS **PQ ADVISOR**

To do this:

1. Navigate to the following file: {root install folder-
}\Applications\ApplicationFramework\Framework.xml
2. Right click the file and select **Edit**.
3. Scroll to the place in the file with the following lines: </Application> </Ap-
plications>
4. Between the two lines shown in step 3 above, copy the following snippet of XML code:

```
<Application id="3a0163ba-c26d-4b79-a846-9e62961ddced" name=
e="Advisor" requiredPrivilege="WebReach.AccessApplication" but-
tonContents="" description="PQAdvisorVistaDiagram_Description"
displayName="PQ ADVISOR" resourcesClassName=
e="UI.ApplicationFramework.Resx.ApplicationFrameworkResources,
ApplicationFramework, Version=1.0.0.0" securityLevel="0">
<ApplicationSpecificPanelButtons>                      </Ap-
plicationSpecificPanelButtons>                      <Libraries>                      <Library
className="LibraryPanelItem3" />                      </Libraries>
```

```

<OptionsButtonControls>          </OptionsButtonControls>
<SetupControls>                  <SetupItem SetupControlId="b29ceb39-4cd8-
4077-9c7c-4c6287ac5b64" />      <SetupItem SetupCon-
trolId="2600efb2-955a-4fef-9895-c8e716325656" />      <SetupItem
SetupControlId="63c71c83-3d88-4d2f-a6eb-db9a1b0f3989" />
</SetupControls>                <Settings>              <Setting name=
e="Url">/ion/default.aspx?dgm=x-pml:/diagrams/ud/PQ_Advisor/PQAd-
visor_LandingPage_7d_V1.0.0.0.0.dgm</Setting>          </Settings>
</Application>

```

NOTE: Use the most current version of the dgm file available.

5. If the Web Application interface is opened, reload the page.
6. Verify the new selection appears and that the PQ Advisor indicator diagrams are loaded when it is selected.

NOTE: The System Technical Note titled *How Can I Modify the StruxureWare Power Monitoring Expert Web User Interface and Add Web Content* (<https://exchangecommunity.schneider-electric.com/message/67646#67646>), contains more details on modifying the Web Applications User Interface.

Power Quality Impact Gadgets and Report configuration

The Power Quality Impact Gadgets and Reports associate PQ events with process impact alarms within a given process / production line, and applies a flat rate cost estimate to the duration of the process impact alarm.

The following sections describe the configuration steps to make the Power Quality Impact Gadgets work:

- ["Acquire process impact signals" on page 168](#)
- ["Setting up process impact alarms" on page 169](#)
- ["Set up Power Quality Groups" on page 171](#)

Acquire process impact signals

A process impact alarm is designed to be created on:

- An electrical value (e.g. current, voltage, power, etc.) from a power device. In this way PME detects the process impact independently (for example, based on a current drop).
- A process impact signal from another system or equipment. The process impact signals can be:
 - Hard wired signals from the process. The signal can be from the process PLC, motor VSD, etc. It can be hard wired to a digital input or an analog input of the meter which monitors the corresponding load (requires AI/DI capability on the meter). The signal can also be hard wired to a dedicated PLC, which can then be connected into PME as a Modbus device.

- OPC tags from the process. Power Monitoring Expert (working as OPC client) acquires the process impact signals from process SCADA system (working as OPC server) via OPC.

NOTE: If signals from multiple processes are connected to a single device (for example, process A and process B signals on a PLC, power meter or OPC connection), then logical devices must be defined to represent each process, in order to be used in the power quality group definition.

To acquire the process impact signals (if Power Monitoring Expert is not detecting the process impact independently), the following tasks may be required to accomplish the work:

- Using meter I/Os
- Using third-party Modbus device in Power Monitoring Expert
- Using Power Monitoring Expert as an OPC client
- Using Power Monitoring Expert Logical Device


See Power Monitoring Expert documentation for more information.

Setting up process impact alarms

Once the process impact signals are connected into the PME system, or PME is set up to detect the process impact independently, process impact alarms need to be set up.

To set up process impact alarms:

1. Launch **Alarm Configuration** from **Management Console**, or from the **Alarm** tab in the web interface.



2. Select **Add Alarm Rule**.
3. In the **User Defined** section. Select **Analog Measurement** if the alarm is based on an analog value. Select **Digital Measurement** if the alarm is based on a digital value.
4. Select the **Measurement** that will be used to determine a process impact event (e.g. **Current Avg** if using the current drops to signify the process impact, or **Equipment State** if the process impact signal is mapped to this measurement for the Logical Device created for the process)
5. In the **Alarm Type** field, enter **Process Impact Alarm**.

NOTE: The string “Process Impact Alarm” is the only flag that the Power Quality Impact report and gadgets looks for.

Add Alarm Rule - Details

Alarm Type

Process Impact Alarm

Alarm ON

When Value is: Over [] []

Pickup Delay [s]: 60

Active Condition: On

☒ Log Extreme Value

Alarm OFF

When Value is: Under [] []

Dropout Delay [s]: 60

Inactive Condition: Off

Advanced

Priority [0-255]: 1 [Event]

Polling Interval: 5 seconds [v]

Cancel Previous Next

6. Configure the thresholds for when the alarm will go ON and when the alarm will go OFF.

7. Configure the **Pickup Delay** and **Dropout Delay**:

The alarm will go ON if the threshold has been exceeded for longer, in seconds, than the “Pickup Delay” value.

The alarm will go OFF if the value is below the threshold for longer, in seconds, than the “Dropout Delay” value.

8. Configure the **Priority**. Use a number less than 64 to prevent the alarm from appearing in the PME Alarm Viewer.

9. Set the **Polling Interval**. The recommendation is **5** seconds.

10. Select the **Source** for the alarm rule. If a Logical Devices is created to represents a process, select the logical device.

11. Give the Alarm rule a name.

Add Alarm Rule - Summary

Alarm Rule Name

Enabled

Alarm Status Measurement Mappings

Input Measurement	Output Alarm Status Measurement
Current A	Process Impact Alarm - Current A Alarm

Cancel


Previous

Finish

12. Click **Finish**.

Set up Power Quality Groups

The Power Quality Groups are defined per process (for example, a production line), so that only the power quality events captured by the meter which relate to the particular process are considered in the impact analysis.



Power Quality Groups must be defined or the Power Quality Impact gadgets and Report will not function.

The incomer meters defined in the Power Quality Groups are also used for the Power Factor section of the Power Quality Analysis Report.

Power Quality Group definition

Power Quality Group are defined in the `PowerQualityGroups.csv` file which is located under the folder:

```
{root install folder}\Applications\PowerQuality\
```

The format of the comma delimited file is as follows:

```
<Power Quality Group Name>,<Incomer Meter>,<Feeder Meter>,<Load  
Meter>,<Rate>
```

Where:

- **Power Quality Group Name** – The name for the group (target process). It is used for selecting the group in Power Quality Impact gadgets and report.
- **Incomer meter** – The meter monitors the incomer. It typically has the PQ event detection capability. The event it captures will be used in the analysis.
- **Feeder Meter** – The meter between the incomer meter and the load meter (could be multiple). The PQ events it captures can potentially impact the process at its downstream. If a feeder meter does not support PQ event detection, then there is no need to include it in the definition. See the examples in next section.
- **Load Meter** – Contains the Process Impact Alarms. The Power Quality Impact Gadgets and Report will not work if the load meters are not defined for the Power Quality Groups. It can be a logical device if the Process Impact Alarm is defined on a logical device. See ["Setting up process impact alarms" on page 169](#) for more information. The load meter typically doesn't have PQ event detection capability.
- **Rate** – The flat hourly rate for the cost impact calculation

NOTE:


- The file structure only allows one incomer meter, one feeder meter, and one load meter per row. If, for a category, more than one meter needs to be included, define them in multiple lines with the same group name.
- The file structure allows one rate per group; define it only in the first row of the group.
- The PQ events captured by the meters in a Power Quality Group will be clustered before associating with the Process Impact Alarms, so that the same event seen by different meters are counted only once.
- Only the PQ events captured by the incomer meter and feeder meter are considered in the analysis. If the load meter supports PQ event detection, and you want to include the events it detects into the analysis, you need to define it as a feeder meter as well. See the examples in next section.
- The incomer meters defined are also used by the Power Factor section of the Power Quality Analysis Report to determine the incomer meters in the system. See the examples in next section.

Editing PowerQualityGroup.csv

NOTE: Before editing the `PowerQualityGroups.csv` file, make sure you understand the relationship between the power metering system and the process of the customer's facility.

To edit the `PowerQualityGroups.csv` file:

1. Identify the **System Name** of a device, go to Management Console, select **System Name** in the Column Selector to add **System Name** to the display:



NOTE: Only the device system names are acceptable.

2. Edit the file in Excel, Notepad or other text editor. For each Power Quality Group:
 - a. In column B, list all related incomer meters that can detect PQ events for the group. Use multiple rows if there is more than one incomer meter.
 - b. In column C, list all related feeder meters that can detect PQ events for the group. Use multiple rows if there is more than one feeder meter.
 - c. In column D, list all related load meters on which the Process Impact Alarms are configured for the group. Use multiple rows if there is more than one load meter.
 - d. Repeat the group name in column A for each row.
 - e. Specify the rate in column E for only the first row for the group.
3. Repeat step 2 for each Power Quality Group.
4. Save the file and keep the format as .csv.

NOTE:

- The list separators for the .csv are “,” for most regions, and “;” for several European countries. The list separators will be detected from the culture settings and used by the import/export exe.
- The rate under culture settings, other than English (en-XX), needs to be enclosed in double quotes. For example, for Spain (es-ES), if the rate 123.456.789,0 is represented, it is input as "123.456.789,0".


Example 1:

Take the metering layout in the image ["Editing PowerQualityGroup.csv" on page 173](#) as an example, the definition contains the following:

	A	B	C	D	E
1	Process A	Incomer.meter	Feeder.meter	Load.meter1	10000
2	Process A			Load.meter2	

Example 2:

In a more complicated example:



The file contains the following:

	A	B	C	D	E
1	Process A	Incomer.meter1	Feeder.meter1	Load.meter1	10000
2	Process A	Incomer.meter2		Load.meter2	
3	Process B	Incomer.meter1	Feeder.meter2	Load.meter3	20000
4	Process B	Incomer.meter2	Feeder.meter21		

Example 3:

As explained in the previous section, in addition to Example 2, if the feeder meters do not have PQ event detection capability, there is no need to define them. (There is no effect if they are defined.)

	A	B	C	D	E
1	Process A	Incomer.meter1		Load.meter1	10000
2	Process A	Incomer.meter2		Load.meter2	
3	Process B	Incomer.meter1		Load.meter3	20000
4	Process B	Incomer.meter2			

Example 4:

As explained in the previous section, in addition to Example 3, if the Process Impact Alarm for the “Process A” is defined only under “Load.meter2”, then “Load.meter2” is the only meter that needs to be defined for the “Process A”. (There is no effect if other load meters are included.)

	A	B	C	D	E
1	Process A	Incomer.meter1		Load.meter2	10000
2	Process A	Incomer.meter2			
3	Process B	Incomer.meter1		Load.meter3	20000
4	Process B	Incomer.meter2			

Example 5:

As explained in the previous section, in addition to Example 4, if the “Load.meter3” can detect sag/swell, and you want the event it captures to be included the analysis, you need to duplicate it as a feeder meter:

	A	B	C	D	E
1	Process A	Incomer.meter1		Load.meter2	10000
2	Process A	Incomer.meter2			
3	Process B	Incomer.meter1	Load.meter3	Load.meter3	20000
4	Process B	Incomer.meter2			

Example 6:

The incomer meters defined in the Power Quality Groups are also used for the Power Factor section of the Power Quality Analysis Report.

If the customer does not require the Power Quality Impact feature, and only wants to enable the Power Factor section of the Power Quality Analysis Report, the file can be created as:

	A	B	C	D	E
1		Incomer.meter1			
2		Incomer.meter2			

Import / Export Power Quality Group Definition

The tool PQGroupConfig.exe is used to import / export the Power Quality Group definition in the PowerQualityGroups.csv file. It is located in {root install folder}\Applications\bin

Importing the Power Group Quality definition

To import the definition, run the command line:

```
PQGroupConfig.exe import "<filepath>\<filename>"
```

```
Administrator: Command Prompt - PQGroupConfig.exe import "C:\Program Fil...
Microsoft Windows [Version 6.3.9600]
(c) 2013 Microsoft Corporation. All rights reserved.

C:\Users\Administrator>cd C:\Program Files (x86)\Schneider Electric\Power Monito
ring Expert\Applications\bin

C:\Program Files (x86)\Schneider Electric\Power Monitoring Expert\Applications\bin>PQGroupConfig.exe import "C:\Program Files (x86)\Schneider Electric\Power Mon
itoring Expert\Applications\PowerQuality\PowerQualityGroups.csv"
Power Quality Groups are already installed in this system. Overwrite? (y/n)
-
```


If you are using the default file name and path, copy the following command line:

```
PQGroupConfig.exe import "C:\Program Files (x86)\Schneider  
Electric\Power Monitoring  
Expert\Applications\PowerQuality\PowerQualityGroups.csv"
```

Exporting the Power Group Quality definition

To export the definition, run the command line:

```
PQGroupConfig.exe export "<filepath>\<filename>"
```



If you are using the default file name and path, copy the following command line:

```
PQGroupConfig.exe export "C:\Program Files (x86)\Schneider  
Electric\Power Monitoring  
Expert\Applications\PowerQuality\PowerQualityGroups.csv"
```

Power Factor Impact Gadgets configuration

The Power Factor Impact Gadgets provide a clear visual indication of the impact of poor power factor on your energy bill.

NOTE:

- The Power Factor Impact Gadgets only work for billing periods that start on the first day of the month. Billing periods that do not start on the 1st (for example, the 20th) are not supported.
- The Viewing Period for the Power Factor Impact Gadget should be set to **This Month or Last Month**. The gadget does not show meaningful information if you set the Viewing Period to another value.
- The Aggregation Period for the Power Factor Impact Trend Gadget should be set to **By Month**. The gadget does not show meaningful information if you set the Aggregation Period to another value.

The calculated surcharge is based on the rate file defined for the PME Rate Engine. Creating or modifying the rate files requires knowledge of the PME Rate Engine. To learn about the PME Rate Engine, refer to [PME Billing Module Toolkit](#).

The following sections describe the Power Factor Impact Gadgets configuration steps:

- ["Setting up the Power Factor Impact rate file" on page 177](#)
- ["Setting up the incomer meters in the hierarchy" on page 177](#)

Setting up the Power Factor Impact rate file

There are four sample rate files based on different calculation methods that are generally used by utilities for power factor rate penalties:

- Power Factor Impact - Active Energy Billing with PF Adjustment Option 1.xml
- Power Factor Impact - Active Energy Billing with PF Adjustment Option 2.xml
- Power Factor Impact - Apparent Energy Billing.xml
- Power Factor Impact - Reactive Energy Billing.xml

The rate file `Power Factor Impact Rate.xml` is active by default. It includes the same calculation as the first sample file. See ["Power Factor Rate File Calculation" on page 293](#) for the calculations of the sample rate files.

The files are located under the folder:

```
{root install folder}\config\reports\billing report\ratelibrary
```

To set up the Power Factor Impact rate file:

1. Consult with the customer to see how the power factor penalties are calculated by the utility provider, including the power factor target under which penalty will be charged.
2. Choose the sample file in which the power factor penalty calculation is the closest to customer's utility contract.
3. Copy the selected rate file to the file name `"Power Factor Impact Rate.xml"`
4. Modify the file to have the same power factor penalty calculation with customer's utility contract. To learn how to modify the rate files, please refer to the *PME Billing Module Toolkit* as mentioned above.
5. Set the target to be shown in the gadgets.
 - a. Find PF target value by searching for `"<Name>PF_target</Name>"`
 - b. Modify the value for the **Formula** accordingly.

```
<VariableFromFormula>
  <Formula>92</Formula>
  <Name>PF_target</Name>
  <NumberFormatForThisVariable>N2</NumberFormatForThisVariable>
```

6. Save the file.

Setting up the incomer meters in the hierarchy

The PME rate engine only works with a hierarchy node. Therefore, you need to add the meters which are subjected to the penalty to a hierarchy. You can do this with the default hierarchy, a custom hierarchy, or virtual meters.

The gadgets only work on a single node. If more than one physical meter needs to be defined (e.g. dual incomer from same utility), add the meters to a single node in the hierarchy, or add meters to a single virtual meter.

For example, to add the dual incomer meters as a virtual meter:

1. Launch **Hierarchy Manager** from **Management Console** or navigate to `http://<Server-Name>/hierarchymanager` in a web browser.
2. Click the **Virtual Meter** tab and click **Add**.

Hierarchy Manager Show Views | Help

Site Buildings Areas **Virtual Meter**

Virtual Meter Add Edit Delete

Name	Device
<Filter>	<Filter>

3. Choose a name for the virtual meter, for example `Main_Incomers`.
4. Click **Add** and select a meter to add to the Virtual Meter. Repeat until all the you add all of the meters that incur PF penalties.

Add Device References ×

	Full Name	Group	Name
	<Filter>	<Filter>	<Filter>
☐	TestAuto.SerialGatewa...	TestAuto	SerialGateway1
☐	TestAuto.TestLogicalD...	TestAuto	TestLogicalDevice1
☐	Victoria_Bertram.coffe...	Victoria_Bertram	coffee_maker
☐	Victoria_Keating.eleva...	Victoria_Keating	elevator
☐	Victoria_Keating.main...	Victoria_Keating	main_7650
☒	Victoria_Keating.Main...	Victoria_Keating	Main_8600
☐	Victoria_Keating.Main...	Victoria_Keating	Main_PM800
☐	Victoria_Keating.PNL_K	Victoria_Keating	PNL_K
☐	Victoria_Keating.RTU_4	Victoria_Keating	RTU_4
☐	VIP.PQADVISOR	VIP	PQADVISOR
☐	VIP.STANDALONE	VIP	STANDALONE
☐	VIP2.TESTAUTO	VIP2	TESTAUTO
☐	VIP3.TESTAUTO	VIP3	TESTAUTO

Percentage


From: **To:**

* start of day

OK Cancel



Once the hierarchy node is defined, it can be selected in the Power Factor Impact Gadgets.



Power Quality Analysis Report configuration

The Power Quality Analysis Report does not need configuration to work, unless you want to include output for the Power Factor section in the report.

The Power Factor section reports the power factor information for the incomer meters in the system. The report retrieves the incomer meter definition from the Power Quality Group definition. See for more information on how to define the incomer meters.

Alternatively, the Power Factor section can be toggled off when generating the report.

PQ Advisor dashboards and reports

This section describes best practices when using PQ Advisor dashboards and reports.


PQ Advisor dashboards

PQ Advisor gadgets are grouped into two groups in Power Monitoring Expert Dashboards:

- Power Quality Overview
 - Power Quality Impact
 - Power Quality Impact Trend
 - Power Factor Impact
 - Power Factor Impact Trend
 - Power Quality Rating
 - Power Quality Rating Trend
- Power Quality Details
 - Power Quality Events Breakdown
 - Power Quality Events Impact
 - Power Quality Events Location

Set up Power Quality Overview dashboards

The following image is an example of a Power Quality Overview dashboard.



Gadget viewing period

When displaying each gadget with its trending gadget, the aggregation period of each bar in the trending gadget should match the viewing period of the non-trending gadget. Otherwise, they are not comparable.

For example, if the non-trending gadget is set to be monthly,

Last Month ▼ ≡

This Month ▼ ≡

the corresponding trending gadget should be set to a time range of **Last 12 Months**, and an aggregation of **By Month**.

Gadget Setup - Viewing Period

Time Range

Last 12 Months ▼

Aggregation


☐ By Day
☐ By Week
☒ By Month

NOTE: Specifically for the Power Factor Impact Gadgets:

- The Viewing Period for the Power Factor Impact Gadget should be set to **This Month or Last Month**. The gadget does not show meaningful information if you set the Viewing Period to another value.
- The Aggregation Period for the Power Factor Impact Trend Gadget should be set to **By Month**. The gadget does not show meaningful information if you set the Aggregation Period to another value.

Set up Power Quality Detail dashboards

The following image is an example of the Power Quality Detail dashboard. (Three regular Trend charts for Power Factor, Harmonics, and Unbalance are combined in this dashboard.)



Power Quality Advisor Reports

The following PQ Advisor Reports are available:

- Power Quality Analysis Report
- Power Quality Impact Report

NOTE: When you generate the Power Quality Advisor reports, a reporting period longer than 12 months is not supported. Use multiple yearly reports instead.

Fine-tune PQ Advisor

Fine-tuning PQ Advisor is very important during commissioning to obtain useful power quality views. It depends heavily on customer requirements, power system design, power meters used in the system, and the power quality condition of the customer's facility.

This section describes the following fine-tuning procedures:

- ["Changing device inclusion and exclusion for the analysis" on page 182](#)
- ["Changing Power Quality Indicator thresholds" on page 185](#)
- ["Disable unused Power Quality Indicators" on page 189](#)

Changing device inclusion and exclusion for the analysis

You can include or exclude certain meters for power quality assessment by PQ Advisor. For example, this capability is useful when you want to include only meters which are critical, or to exclude spare meters, etc. Also, for performance reasons, it is important to exclude unnecessary meters.

You can include or exclude the following Power Quality Event types:

- Interruptions
- Voltage Sags
- Voltage Swells
- Transient Voltage
- Over Voltage
- Under Voltage

And you include or exclude the following Power Quality Disturbance types:

- Voltage Unbalance
- Current Unbalance
- Voltage Harmonics
- Current Harmonics
- Frequency Variation
- Flicker

Each PQ event or disturbance has an inclusion list and an exclusion list, and the following logic applies to both lists:

1. The inclusion list is processed first:
 - a. If the inclusion list is empty, assume that ALL sources in the system are included. This means all sources in the sources table.
 - b. If the inclusion list is not empty, use only sources that exist in the inclusion list. If a source in the inclusion list does not exist in the sources table, do not add it to the list.
2. The exclusion list is processed last:
 - a. From the source list obtained in step 1, remove any source that appears in the exclusion list.

The following features in the PQ Advisor module which are affected by the inclusion and exclusion lists:

- PQ Indicator Diagrams
- PQ Rating Gadget
- PQ Rating Trend Gadget
- Power Quality Events Breakdown Gadget
- Power Quality Events Impact Gadget
- Power Quality Events Location Gadget
- Power Quality Analysis Report – for all sections except the Power Factor section


NOTE: These lists do not define:

- Devices considered by the Power Quality Impact Gadgets and Report.
- Devices considered by the Power Factor Impact Gadgets.
- Devices considered for the Power Factor section of the Power Quality Analysis Report.


See the configuration sections of the above features for details.

To edit the inclusion and exclusion lists:

1. Identify the **System Name** of the target device. Go to Management Console, show **System Name** column using the Column Selector:



- Go to SQL Server Management Studio, locate the dbo.vCFG_ConfigItems view in the ION_Network database, and right-click and select "Edit Top 200 Rows".




The following variables are the inclusion and exclusion lists:


Module	Category	Item	Value	DefaultValue
PQAnalytics	Source Lists	SwellInclusionList		
PQAnalytics	Source Lists	SwellExclusionList		
PQAnalytics	Source Lists	InterruptionInclusionList		
PQAnalytics	Source Lists	InterruptionExclusionList		
PQAnalytics	Source Lists	TransientInclusionList		
PQAnalytics	Source Lists	TransientExclusionList		
PQAnalytics	Source Lists	OvervoltageInclusionList		
PQAnalytics	Source Lists	OvervoltageExclusionList		
PQAnalytics	Source Lists	UndervoltageInclusionList		
PQAnalytics	Source Lists	UndervoltageExclusionList		
PQAnalytics	Source Lists	FrequencyInclusionList		
PQAnalytics	Source Lists	FrequencyExclusionList		
PQAnalytics	Source Lists	HarmonicsVoltageInclusionList		
PQAnalytics	Source Lists	HarmonicsVoltageExclusionList		
PQAnalytics	Source Lists	HarmonicsCurrentInclusionList		
PQAnalytics	Source Lists	HarmonicsCurrentExclusionList		
PQAnalytics	Source Lists	FlickerInclusionList		
PQAnalytics	Source Lists	FlickerExclusionList		
PQAnalytics	Source Lists	UnbalanceVoltageInclusionList		
PQAnalytics	Source Lists	UnbalanceVoltageExclusionList		
PQAnalytics	Source Lists	UnbalanceCurrentInclusionList		
PQAnalytics	Source Lists	UnbalanceCurrentExclusionList		

- In the **Value** fields, enter the comma delimited list of the devices, for example:
PQ.B1, PQ.B2, Main.BackupGenerator

4. To apply the changes immediately in the PQ Indicator Diagrams, go to the PQ Advisor Setup page in Vista:



Click **Initialize/Update Indicators**.




5. To apply the changes immediately in the Power Quality Rating Gadgets, force the gadgets to clear their cache by “editing” the gadget, and clicking **Save** (no changes are required).

To exclude all sources for a given category, put a string in the inclusion and exclusion list. For example: “disabled”.

Module	Category	Item	Value
PQAnalytics	Source Lists	FlickerInclusionList	disabled
PQAnalytics	Source Lists	FlickerExclusionList	disabled

Changing Power Quality Indicator thresholds

The Power Quality Indicator threshold for each indicator is displayed on the information page. (Click the “i” icon.)



Power Quality Advisor - Unbalance			
INDICATOR INFORMATION			✕
Voltage and Current Unbalance for all time periods	Green	Yellow	Red
	V Unbal < : 1 %	V Unbal >= : 1 %	V Unbal > : 5 %
	OR	OR	OR
	I Unbal < : 10 % for >= 95% of the time period	I Unbal >= : 10 % I Unbal <= : 40 % for > 5% of the time period	I Unbal > : 40 % for > 5% of the time period

The thresholds are used to determine the Power Quality Rating by using a color (green, orange, red) for each Power Quality indicator. Also, only the samples which exceed the threshold are shown in the Detail Report of the PQ Indicator diagrams.

The count thresholds specified here are used to determine the colors for a year. They get divided by 365 for **Last 24 Hours**, by 52 for **Last 7 Days**, and so on. The calculation is as follows:

Round Up ((Yearly Service Limit) x (Number of Days / 365))

For example, for 30 days, where the yearly limit for orange is 5 and the yearly limit for red is 15:

Orange limit: $(5 * (30/365)) = 0.41$ which rounds up to 1.

Red limit: $(15 * (30/365)) = 1.23$ which rounds up to 2.

NOTE: The orange limits are >=, but the red limits are

To change the thresholds:

- 1. In SQL Server Management Studio, in the ION_Network database locate the dbo.vCFG_ConfigItems view.
- 2. Right-click the dbo.vCFG_ConfigItems view and select **Edit Top 200 Rows**.

The following items are the indicator thresholds:

Module	Category	Item	Value	DefaultValue
PQAnalytics	General Settings	Transients/Year - Orange	5	5
PQAnalytics	General Settings	Transients/Year - Red	15	15
PQAnalytics	General Settings	Sags/Year - Orange	5	5
PQAnalytics	General Settings	Sags/Year - Red	15	15
PQAnalytics	General Settings	Swells/Year - Orange	5	5
PQAnalytics	General Settings	Swells/Year - Red	15	15
PQAnalytics	General Settings	Interruptions/Year - Orange	2	2
PQAnalytics	General Settings	Interruptions/Year - Red	5	5
PQAnalytics	General Settings	Overvoltages/Year - Orange	5	5
PQAnalytics	General Settings	Overvoltages/Year - Red	15	15
PQAnalytics	General Settings	Undervoltages/Year - Orange	5	5
PQAnalytics	General Settings	Undervoltages/Year - Red	15	15
PQAnalytics	General Settings	THDU - Orange	5	5
PQAnalytics	General Settings	THDU - Red	8	8
PQAnalytics	General Settings	Voltage Unbalance - Orange	1	1
PQAnalytics	General Settings	Voltage Unbalance - Red	5	5
PQAnalytics	General Settings	Current Unbalance - Orange	10	10
PQAnalytics	General Settings	Current Unbalance - Red	40	40
PQAnalytics	General Settings	Frequency Nominal	60	60
PQAnalytics	General Settings	Frequency Deviation - Orange	1	1
PQAnalytics	General Settings	Frequency Deviation - Red	2	2
PQAnalytics	General Settings	Flicker Pst - Orange	0.9	0.9
PQAnalytics	General Settings	Flicker Pst - Red	1	1
PQAnalytics	General Settings	Flicker Plt - Orange	0.7	0.7
PQAnalytics	General Settings	Flicker Plt - Red	0.8	0.8

The count thresholds specified here are used to determine the colors for a year. They get divided by 365 for **Last 24 Hours**, by 52 for **Last 7 Days**, and so on. The calculation is as follows:

Round Up ((Yearly Service Limit) x (Number of Days / 365))


For example, for 30 days, where the yearly limit for orange is 5 and the yearly limit for red is 15:

Orange limit: $(5 * (30/365)) = 0.41$ which rounds up to 1.


Red limit: $(15 * (30/365)) = 1.23$ which rounds up to 2.

NOTE: The orange limits are $\geq$, but the red limits are $>$.

3. Change the threshold item `value` as needed.
4. For the PQ Indicator Diagrams to display the updated limit information, go to the PQ Advisor Setting page in Vista:



Click **Import Indicator Limit Information**.



Changing Power Quality Indicator weight factors

When setting up a baseline for the Power Quality Rating of the system, adjust the Weight Factor to meet customer requirements, or to reflect the actual condition of the system. For example, increase the weight for the indicator that is important to the customer, or decrease the weight for the indicator that is not important.

NOTE: If a certain indicator is not available in the system, for example, no meter in the system can monitor transient, set its weight to 0.

The formula used to calculate the Power Quality Rating is:

$$PQ.Rating = \frac{\sum PQ.Indicators.Value \times Weight Factor}{\sum PQ.Indicators.MaxValue \times Weight Factor} \times 100\%$$

Where:

- **PQ.Indicators.Value** is a number indicating each Power Quality Indicator status, Green = 2 ; Yellow = 1 ; Red = 0
- **PQ.Indicators.MaxValue** = 2 for each individual indicator.
- **Weight Factor** is an adjustable value (default=1) for assigning a different weight to each individual indicator depending on customer requirements.

To change a weight factor:

1. In SQL Server Management Studio, in the ION_Network database locate the dbo.vCFG_ConfigItems view.

2. Right-click the dbo.vCFG_ConfigItems view and select **Edit Top 200 Rows**.

The following items are the weight factors:

Module	Category	Item	Value	DefaultValue
PQAnalytics	General Settings	Interruptions Weight	1	1
PQAnalytics	General Settings	Sags Weight	1	1
PQAnalytics	General Settings	Swell Weight	1	1
PQAnalytics	General Settings	Transient Weight	1	1
PQAnalytics	General Settings	Harmonics Weight	1	1
PQAnalytics	General Settings	Unbalance Weight	1	1
PQAnalytics	General Settings	Flicker Weight	1	1
PQAnalytics	General Settings	FreqVar Weight	1	1
PQAnalytics	General Settings	OverUnder Weight	1	1

3. Change the weight item `value` as needed.
4. To apply the changes immediately in the Power Quality Rating Gadgets, force the gadgets to clear their cache by “editing” the gadget, and then click Save (no changes are required).

Disable unused Power Quality Indicators

When a Power Quality Indicator has no supported device to feed it the required data, disable it by using the procedures in the following sections. See ["PQ Advisor - Supported meters" on page 294](#) for meter support information.

Disable Flicker, Frequency, Harmonics or Unbalance Indicators

Use the following procedure to disable the Flicker, Frequency, Harmonics, and Unbalance indicators. Flicker is used specifically in this example, but the procedure is the same for the other items.

You can also use the following procedure to disable Overvoltage and Undervoltage. However, note that it will disable both of them simultaneously. If only one needs to be disabled, use the procedure in the next section.

1. To prevent PQ Advisor from requesting Flicker values, add a string “disabled” to the FlickerInclusionList & FlickerExclusionList (no double quotes needed). See ["Changing device inclusion and exclusion for the analysis" on page 182](#) for detail steps.

Module	Category	Item	Value
PQAnalytics	Source Lists	FlickerInclusionList	disabled
PQAnalytics	Source Lists	FlickerExclusionList	disabled

2. To prevent the PQ Advisor indicator diagrams from displaying status:
 - a. Edit the PQADVISOR VIP in Designer.
 - b. Open the Flicker folder.




- c. Add a new Ext Bool Module.



- d. Link the switch output register of the new module to the Enable input register on the 4 XML import modules used for Flicker.

- i. Right click on the newly created Ext Bool Module
- ii. Change the Module Label and the switch Output Register Label to “Flicker Enable”



- iii. Select the outputs for the Flicker Enable module and select “Flicker Enable”




- iv. Select the input of the 24hr Flicker Count Import XML module and select “Flicker Enable”



- v. Repeat the previous step for the following:
 - 7d Flicker Count Import XML module
 - 30d Flicker Count Import XML module
 - 1y Flicker Count Import XML module

vi. The result will look like this:



- 3. Save the VIP and close Designer.
Since the Ext Boolean has a default value of “false”, the Flicker Count Import modules are disabled upon saving the VIP.
- 4. Check the PQ Advisor Indicator Diagram.
The Flicker icon should be grey.



The details should be blank:

Power Quality Advisor - Flicker

DETAILS

	Last 24 Hours	Last 7 Days	Last 30 Days	Last 12 Months
Pst Maximum				
Pst Average				
Plt Maximum				
Plt Average				
Detail Report				

Disable Sag, Swell, Interruptions, Transient, or Unbalance Indicators

Use the following procedure to disable the Sag, Swell, Interruptions, and Transient indicators, if the devices being used in the installation do not support them. Transients are used specifically in this example, but the procedure is the same for the other items.

You can also use the following procedure to disable either Overvoltage or Undervoltage, if only one needs to be disabled. If both need to be disabled simultaneously, then use the procedure in the previous section.

1. To PQ Advisor from requesting Transient values, add the string “disabled” (without the quotes) to the TransientInclusionList and TransientExclusionList. See ["Changing device inclusion and exclusion for the analysis" on page 182](#) for detailed steps.
2. To prevent the PQ Advisor indicator diagrams from displaying Transient status:
 - a. Edit the PQADVISOR VIP in Designer.
 - b. Open the Sag, Swell Transient, Interruption folder.



- c. Right click on the 12m Event Ind Extrap module.

 A screenshot of the "ION Module Setup" dialog box. It has a light blue title bar and a white background. The dialog is divided into two main sections: "Setup Registers:" and "Output Registers:". Below these are radio buttons for "Module Label" and a text input field. At the bottom are buttons for "OPC...", "Modify...", "OK", and "Cancel".

Setup Registers:		Output Registers:
ART16 Formula 1	S1 = 1	Interrupt Amber Ind
ART16 Formula 2	S1 = 2	Interrupt Red Ind
ART16 Formula 3	S2 = 1	Sag Amber Ind
ART16 Formula 4	S2 = 2	Sag Red Ind
ART16 Formula 5	S3 = 1	Swell Amber Ind
ART16 Formula 6	S3 = 2	Swell Red Ind
ART16 Formula 7	S4 = 1	Transient Amber Ind
ART16 Formula 8	S4 = 2	Transient Red Ind
ART16 N/A Conversion	None	ART16 Event

Module Label


☐ Use Default Label

☒ Use Custom Label:

12m Event Ind Extrap

OPC... Modify... OK Cancel

- d. Double click on Formula 7 and add “S5 + “ to the beginning of the string. This will cause the output of the equation to be NA because S5 is unassigned and therefore equivalent to NA. If transients need to be added back to the system (e.g. a new meter which supports transients is purchased for the site), then it is easy to remove the string “S5 +” from the setup register string



Modify String Register

String:

S5 + S4 = 1

Register Label


☐ Use Default Label

☒ Use Custom Label

ART16 Formula 7

OK Cancel

- e. Repeat step d for Formula 8
 - f. Repeat steps c, d and e for:
 - 24h Event Ind Extrapol module
 - 7d Event Ind Extrapol module
 - 30d Event Ind Extrapol module
3. Save the VIP and close Designer.
 4. Check the PQ Advisor Indicator Diagram. The Transient Voltage icon should be grey.



The DETAILS page should display zeros:

Power Quality Advisor - Transient Voltage

DETAILS



Number of Events				
	Last 24 Hours	Last 7 Days	Last 30 Days	Last 12 Months
No Impact	0	0	0	0
Likely Impact	0	0	0	0
Internal	0	0	0	0
External	0	0	0	0
Undetermined	0	0	0	0
Detail Report				

Uninterruptible Power Supply (UPS) Performance

The UPS Performance Module is an optional module that helps to reduce the risk of UPS battery failure between maintenance periods and measures UPS remaining time to reinforce patient safety.

Uninterruptible Power Supply (UPS) Auto Test

The Uninterruptible Power Supply (UPS) Auto Test solution provides a Vista diagram to the user in order to monitor the MGE5500 series UPS in Power Monitoring Expert.

NOTE: The UPS Auto Test solution is supported only for the MGE5500 UPS.

Adding UPS devices to Management Console


1. Log in to the Management Console.
2. In Management Console, click **Devices** and add each new UPS device.

Configuring UPS groups


To configure UPS groups using the UPS Configuration Tool:

1. Open the UPS Configuration Tool.
2. In the UPS Configuration Tool, click **New** and add each new UPS that you added in the Management Console.
3. (Optional) Change the value for the **Display Name** that appears in the Vista diagram if you want.

NOTE: This **Display Name** appears only in the Vista diagram and does not impact the name that you use in the Management Console.



4. After adding all new UPS devices, click the **Groups** tab.
5. Click **New** to create new groups for the UPS devices.




6. After you finish adding all UPSs and associated groups, click **Apply**.


Generating a Vista diagram

To generate a Vista diagram:

1. In the UPS Configuration Tool, click **Generate Vista Diagrams**.



The **Vista Diagram Generation** dialog appears.




NOTE: The **Output Path** shows where the Vista diagram .dgm file is saved after clicking **Generate Vista Diagrams**. The file name or location can be modified from the default value if desired.

2. Click **Include Custom Logo** and then navigate to and select the file in order to include a custom logo in your diagrams. Otherwise, a Schneider Electric logo appears.
3. Under **Options**, drag the indicator to define the width and dimensions of Vista diagrams you generate.
4. Click **Generate Vista Diagrams** to generate the .dgm files, then click **Close**.


Pasting UPS framework in VIP

To paste a UPS framework in VIP:


1. Open the Designer tool and open the VIP.<servername>.node.
2. Drag a Grouping Object and open it. Make sure that the toolbox is available (**Options > Show toolbox**).
3. Go to `... \config\fmwk\UPS\` and select **Edit > Paste** to paste the framework. Depending on the number of UPSs and groups, you may need to set up the framework. The default template assumes the user has two groups with five UPSs in each group.



The following example shows an instance where the user has three groups with a different UPS in each group:



4. Connect the inputs of each AND/OR module (UPS) to the critical operation and battery usage status.




5. Repeat this step for each UPS in the group and for all of the UPSs in the other groups.


6. Save the framework after you finish modifying the framework based on your UPS system.

Setting up Vista Diagram status

1. Browse to ... \config\diagrams\ud\UPS\UpsGroups.dgm.



2. Link the status object from the framework that you pasted in VIP in the previous steps.



3. Repeat step 2 for all other groups. Your UPS Monitoring system is now setup.

NOTE: Any UPS in the groups that require attention show a red indicator.

Running a report

After you finish configuring all UPSs, you can run a report by selecting a group.

Uninterruptible Power Supply (UPS) Auto Test Report

The **UPS Auto Test Report** shows the test solution and provides a Vista diagram to the user in order to monitor the MGE5500 series UPS.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.

Uninterruptible Power Supply (UPS) Battery Health Report

The **UPS Battery Health Report** is designed to show information related to the health of the battery for a UPS device. The UPS devices intended for use with this report are UPS devices that do not have an auto-test capability.

Supported Devices

The only devices supported by UPS Battery Health are as follows:

- ION7550 / ION7650

The UPS Battery Health system contains several components that provide the customer with information about the generator battery bank. Specifically, the monitor shows the customer the starting voltage signature when the UPS comes online, which indicates the battery bank's voltage drop and recovery at that time.

The following tasks must be completed to set up the UPS Battery Health system:

- Install and configure the ION 7550 / ION7650 meter to the battery bank to be monitored. Refer to the *PowerLogic ION7550 / ION7650 Installation Guide* and *PowerLogic ION7550 / ION7650 User Guide* for more information. Obtain the latest version of these documents from www.schneider-electric.com.

Note the following:

- V1 - V3 voltage inputs must have PTs in order to isolate the ground from the system being monitored and the battery.
- Connect V4 to the positive side of the battery. Input impedance of V4 terminal is 5 Mohm (phase - Vref). For the most up to date specification, contact the local representative.
- Connect Vref to battery ground.
- Fusing must be installed according to the meter installation instructions.
- Perform visual inspection of connections to ensure there is physical separation between the system connected to V1, V2 and V3, and the battery connected to V4.
- For other wiring options with PTs, see the *PowerLogic ION7650 Installation Guide*.

DANGER

EQUIPMENT ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Treat the battery circuit as energized to the category of the installation.

Failure to follow these instructions will result in death or serious injury.

Refer to the following diagram as an example for connections to the meter.


The diagram illustrates a Wye (Star) wiring configuration for potential transformer (PT) primaries and secondaries. On the left, the 'LINE' consists of four horizontal conductors: A, B, C, and N. The 'LOAD' section on the right shows a series of vertical conductors representing the PT terminals. The primary windings (2A) are connected in a star configuration with their common point grounded to the N line. The secondary windings (3A) are also connected in a star configuration with their common point grounded. The diagram includes labels for various terminals: V1, V2, V3, V4, Vref, I11, I12, I21, I22, I31, I32, I41, I42, I51, I52, G, L/+, and N/-. A note in a box states: 'Fuse for N/- terminal required if its supply source is ungrounded. Connect G terminal to ground for AC power source.' A label 'I4 Optional' points to a specific secondary terminal connection.

- Configure the UPS Battery Health Framework to capture the battery voltage signature or waveform and deploy the framework to the meter. See the next section for instructions.
- Configure the UPS Battery Health Report to display the graph of the voltage signature. The customer can use the report to help understand the battery bank condition.

This section provides instructions for configuring the framework to capture the voltage signature.

Configuring the UPS Battery Health Framework

The UPS Battery Health Framework is designed to capture and record a UPS's battery voltage signature at start up. This voltage signature provides some indication of the health of the UPS's battery bank. A typical waveform capture of the voltage drop when the UPS comes online is shown below:



Note the following items about this example:

- This capture shows about 4 - 5 seconds worth of data, accomplished via one (1) waveform recorder configured at a resolution of 512 x 4.
- The voltage does not immediately recover to its original value but it begins to ramp up.
- There is about 0.5 seconds of data before the voltage drop to approximately 20 V.

Two options in the framework are possible to capture the waveform, based on how the crank relay signal is triggered - pulse or KYZ.

Example Framework

The types of module used are:

- Data Acquisition
- Digital Input
- Convert
- OneShot Timer
- Waveform Recorder

See the following descriptions for the way each module works in this framework.

Refer to *ION Reference* for details on how each module operates and for setting module parameters.


Data Acquisition – Data Acqn 1



The V4 signal from the meter goes to the Data Acquisition module.

One-Shot Timer

To prevent triggering the downstream logic twice, send the state from the Convert module into the One Shot Timer:



Send the output register into the first Waveform Recorder G1 Battery 1.

First Waveform Recorder – G1 Battery 1

The Data Acquisition module is the input to the first Waveform Recorder, labeled "G1 Battery 1."



These are the setup registers for the module:

The ION Module Setup dialog box is divided into three main sections. The top section contains two lists: 'Setup Registers' and 'Output Registers'. The 'Setup Registers' list includes 'WR8 Depth' (100), 'WR8 RecordMode' (Circular), 'WR8 Format' (16x96), and 'WR8 Record Delay Cycles' (95). The 'Output Registers' list includes 'WR8 Wform Log', 'WR8 Log State', 'WR8 Records Left', 'WR8 Record Complete', and '***Event***'. The bottom section is titled 'Module Label' and contains two radio buttons: 'Use Default Label' and 'Use Custom Label'. The 'Use Custom Label' option is selected, and a text box below it contains the label 'G1 Battery 1'. At the bottom right of the dialog are three buttons: 'Modify...', 'OK', and 'Cancel'.

Setup Registers:		Output Registers:
WR8 Depth	100	WR8 Wform Log
WR8 RecordMode	Circular	WR8 Log State
WR8 Format	16x96	WR8 Records Left
WR8 Record Delay Cycles	95	WR8 Record Complete
		Event

Module Label

☐ Use Default Label

☒ Use Custom Label:

G1 Battery 1

Modify... OK Cancel

Note the following about the setup registers:

- Depth must be non-zero – 100 hundred is a good number.
- Record Mode should be Circular.
- Format should be 16x96. This means 16 samples per cycle and 96 cycles, so at 60 Hz this results in approximately 1.6 seconds worth of data.
- Record Delay Cycles is set to 95 to allow the “window of observation” to move so that only post-event data is captured. Refer to *ION Reference* for more details.

Configure and generate the UPS Battery Health Report

Use the Reports module in Web Applications to configure and produce the UPS Battery Health Report.

For more information on generating and managing reports, see the "Reports" section of the Web Applications help file.


UPS Battery Health Report example

In this example, the starting voltage waveform (blue) is similar to the reference waveform (red). The drop to near 51 volts DC is the point at which the generator started. After the start, battery voltage rises to normal state of charge.


The first section shows a summary table of the reference and comparison waveforms. It shows the timestamp for the waveform that corresponds to the recorder timestamp of the waveform, and whether or not the drop or recovery are found.

The next section shows a chart that shows the reference and comparison waveforms in a stacked view. If a voltage drop is found in both waveforms, then those waveforms are *time aligned* based on their **voltage drop minimum** values. If a drop is *not* found in both waveforms, then those waveforms are *time aligned* based on their **absolute minimum** values.

The chart shows a gray band around the Analysis Section that represents the section of the waveform where the voltage drop and recovery voltage samples are found.



This section shows a chart with details of the waveform analysis. Following the analysis table, a chart shows a stacked view of the reference and comparison waveform voltage drops. The chart also shows a red horizontal band that represents the area that is under the voltage threshold.



Telvent Weather Data Import Service

The Telvent Weather Data Import Service allows you to import current weather data from the Telvent weather source you specify into Power Monitoring Expert in order to forecast weather conditions and to correlate weather-related conditions to energy consumption. The Telvent Weather Data Import Service device driver can import real-time and historical data into Power Monitoring Expert.


NOTE: The Telvent Weather Data Import Service requires an active Telvent subscription account.

Configuring the data import service


To use the Telvent Weather Data Import Service, you must first configure it using the Modbus Service Configuration Tool and the Management Console.

Run the Modbus Service Configuration Tool

1. In **Windows > Explorer**, navigate to the **system\bin** folder and then double-click **ModbusServiceConfigurationTool.exe** to run it. The **Modbus Service Configuration Tool** dialog appears.
2. Click **Add**. The **Add Service Window** dialog appears.



3. From the **Available Services** dropdown list, select **Telvent Weather Service**.
4. For **Unit ID**, enter "1" and then click **Configure**. The **Telvent Weather Service Configuration** dialog appears.



Telvent Weather Service Configuration

Telvent User Name: SE2294984 Telvent Password:

☒ GPS Location
 ☐ Station Id
 ☐ Postal Address

Latitude: 48.564212
 Longitude: -123.415818

Distance: Kilometer
 Angle: Radian
 Time: Hours

Degree Day: Degree Day - Corn
 Temperature: Celsius
 Luminance: Nit - Candela per sq m

Depth: Millimeter
 Speed: Kilometres per hour
 Pressure: Atmosphere

Radiation: Joule
 Evapotranspiration: Millimeters per hour


Horizontal Distance: Kilometer
 Vertical Distance: Meter

OK Cancel

5. Complete the fields as follows:

- **Telvent User Name** field: Enter your Telvent subscription user name.
- **Telvent Password** field: Enter your Telvent subscription password.
- For location, choose and complete the fields for one of the following:
- **GPS Location**: Enter values for **Latitude** and **Longitude**.
- **Station ID**: Enter a specific Weather Station ID.
- **Postal Address**: Enter a postal address (ZIP or postal code).
- From the dropdown lists, select the unit measurements you want. For **Degree Day**, enter what the Telvent weather service provides as units.

6. Click **OK**. **Telvent Weather Service** now appears in the list under **Service Name** in the Modbus Service Configuration Tool dialog and begins collecting data immediately.



Modbus Service Configuration Tool

Service Name	Unit Id
Telvent Weather Service	1


Add Edit Delete

Ok Cancel

7. Click **OK**, and then click **Yes** to restart the Modbus Software Gateway Service.

Configure the Management Console

1. From the desktop, navigate to the ...\\Power Monitoring Expert folder and double-click **Management Console**, enter your user name and password, and click **OK**. The **Management Console** dialog appears.
2. In the left pane, click **Sites**.
3. Right-click on the dialog and choose **New > Ethernet Gateway Site**.




The **Ethernet Gateway Site Configuration** dialog appears.

Name	SoftwareGatewayService
TCP/IP Address	10.12.44.101
TCP/IP Port	502
Computer	STANDALONE
Time Synch ION Enabled	No
Time Synch 3XXX Enabled	No
Time Synch 3720 Enabled	No
Enabled	Yes
Description	


TCP/IP Port
Select the TCP/IP port to use for this site.

OK Cancel

4. Complete the fields as follows:
 - **Name** field: Enter a name for the site, such as SoftwareGatewayService.
 - **TCP/IP Address** field: Enter the local IP address or the server name where Power Monitoring Expert is installed.
 - **TCP/IP Port** field: Enter port **502**.
5. Click **OK**.
6. In the left pane, click **Devices**.
7. Right-click on the dialog and choose **New > Serial Device on Ethernet Gateway Site**.



The **Serial Device Configuration** dialog appears.



The image shows a 'Serial Device Configuration' dialog box with a table of fields and a text area below it.

Group	MAIN
Name	Telvent
Device Type	Telvent Weather Service
Unit ID	1
Site	SoftwareGatewayService
Enabled	Yes
Description	

Below the table is a text area with the label 'Name' and the instruction 'Enter a name to identify the device.' At the bottom right are 'OK' and 'Cancel' buttons.

8. Complete the fields as follows:
 - **Group** field: Select a group for the device, such as MAIN.
 - **Name** field: Enter a name for the device, such as Telvent.
 - **Device Type** field: Select Telvent Weather Service.
 - **Unit ID** field: Enter "1" .
 - **Site** field: Select **Software Gateway Service**.
 - **Enabled** field: Choose **Yes**.
 - **Description** field: Enter a description of the device if you want.
9. Click **OK**. The new device now appears in the list of devices. The Telvent Weather Data Import Service is now configured.

Verifying the service is active

After configuring the Telvent Weather Data Import Service, you can verify that the service is active in Vista.

1. Select the site you configured, such as **SoftwareGatewayService**.
2. From the desktop, navigate to the ...\\Power Monitoring Expert folder and double-click **Vista**.
3. Log in with your username and password, and then click **OK**. The **Vista** dialog appears.
4. Choose **File > New** to create a new diagram.
5. Drag a Numeric Object from the toolbar onto the diagram.

6. Right-click on the object and then click the **Link** tab.
7. Select **Custom** and click **Edit Link**.
8. In the **Create Link** dialog, select the device you configured, such **Weather.Telvent**, and click **OK**.
9. Make selections for **Managers**, **Modules**, and **Output Registers**, and then click **OK**.
10. Open the Vista diagram and verify that the service is logging observed measurements.

NOTE: All observed measurements are logged and all observed measurements are read in real time. Hourly observed measurements are logged every half-hour, and all daily observed measurements are logged every 12 hours.

AccuSine® Power Correction System (PCS) device


The AccuSine Power Correction System device is used to help reduce maintenance and wear on an electrical system and to improve Power Quality. Adding a AccuSine Power Correction System device to your Power Monitoring Expert system allows you monitor and correct the harmonics of the power for your buildings.

Configuring the AccuSine PCS device

To use the AccuSine Power Correction System, you must first configure it using the Management Console.

To configure the AccuSine PCS device:

1. Navigate to and double-click **Management Console**. The **Management Console** dialog appears.
2. In the left pane, click **Devices**.
3. Right-click on the dialog and choose **New > Ethernet Device**.



The **Ethernet Device Configuration** dialog appears.

Group	Correction
Name	AccuSine
Device Type	AccuSine_PCS
TCP/IP Address	10.168.88.77
Computer	STANDALONE
Enabled	Yes
Description	

Description
Enter a description for the device.

OK Cancel


4. Complete the fields as follows:
 - **Group** field: Select a group for the device, such as Correction.
 - **Name** field: Enter a name for the device, such as AccuSine.
 - **Device Type** field: Select **AccuSine_PCS**.
 - **TCP/IP Address** field: Enter your server IP Address.
 - **Computer** field: Enter the name of your server.
 - **Enabled** field: Select **Yes**.
 - **Description** field: Enter a description of the device if you want.
5. Click **OK**. The new device now appears in the list of devices. The AccuSine Power Correction System is now configured.

Verifying the device is active

After the AccuSine Power Correction System is configured, verify that the device is active.

1. In **Vista**, generate the network diagram.
2. Open the network diagram.
3. Click on each tab to verify that harmonic measurement data appears in each.

NOTE: Allow a few moments for measurement data to appear and refresh on the tabs.



4. After you verify that the monitoring and correction is active, close the diagram.

Reference

ION power meter configuration

This section describes how to complete the following tasks:

- Add ION power meters to the Power Monitoring Expert 8.2 solution.
- Deploy a custom framework on an ION power meter using the Designer application of Power Monitoring Expert 8.2 solution.
- Configure the framework with site-specific information.

Experience using ION Setup, Designer, and other software is necessary to configure ION power meters. Successful completion of these tasks ensures that:

- The operational states on the Active Transfer Switches (ATS) and generators are associated with the digital inputs on the ION power meters, and that the digital inputs are appropriately labeled and logged in the ION_Data database.

NOTE: ATS do not need to be configured for the Generator Performance software module, only for EPSS.

- The engine data for the generators is associated with the analog inputs on the ION power meters, and that the analog inputs are appropriately labeled and logged in the ION_Data database.
- The electrical details for the generators are logged and saved in the ION_Data database.

WARNING

UNINTENDED OPERATION

- Do not use ION meters for critical control or protection applications where human or equipment safety relies on the operation of the control circuit.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Refer to the *ION Reference* for more information on ION module operation.

Supported ION power meters

All Power Monitoring Expert solutions can use the following ION power meters:

- PM8000, ION7550 and ION7650 for ATSS only, generators only, or for generators and ATSS combined
- ION7550 RTU for ATSS only

Related Information

For information about adding ION power meters to Power Monitoring Expert, see the Management Console online help or the Power Monitoring Expert 8.2 Help.

For details about configuring Analog or Digital Input modules, refer to *ION Reference*.

Maintenance and backups

As a good practice, always save a backup of the final framework that is pasted onto the meter. Use Designer to create a copy of the framework from the meter. Save the framework to a location from where the framework can be pasted back to the meter if necessary.

NOTE: Be sure to save a backup of the meter's framework before deploying and configuring the EPSS frameworks.

If a meter needs to be replaced, use the backup copy of the ION meter framework for the new ION meter. For all other installation and configuration steps, you must follow the original commissioning steps as described in the following sections.

Refer to existing Power Monitoring Expert 8.2 documentation for instructions to backup meter frameworks.

Prerequisites

The following items must be completed before attempting to configure ION power meters to record data from generators, automatic transfer switches (ATS) and other equipment.

- The Power Monitoring Expert solution must be installed and operational.
- All ION power meters must be installed and communicating.
- ION power meters selected to monitor **each ATS device** must have the following available data recorders and inputs:
 - One available data recorder
 - At least three available digital inputs (site specific)
- ION power meters selected to monitor **each generator device** must have the following available data recorders and inputs:
 - Three available digital inputs (site specific)
 - Two available data recorders
- See ["Additional Information about Digital and Analog Inputs" on page 217](#) for more information.
- Each ATS should be physically wired to the appropriate ION power meters so that the following status signals are represented:
 - Normal
 - Emergency
 - Test
 - Power Outage (optional)

- Each generator should be physically wired to the appropriate ION power meters so that the following status signals are represented:
 - Start (optional)
 - Emergency Power Source Available (optional)
 - Run
 - Stop
- The following generator electrical data must be metered and available for each generator:

• VIn a	• VII ab	• I a	• kW tot
• VIn b	• VII bc	• I b	• kVA tot
• VIn c	• VII ca	• I c	• PF sign tot
• VIn avg	• VII avg	• I avg	• Freq

Additional Information about Digital and Analog Inputs

Digital Inputs

Meters used to monitor generators and other equipment must have enough available digital inputs to handle the incoming status signals. The number of required digital inputs depends on how many signals are available and whether they are single state or dual state signals.

Example of single state signals, where signalA represents GEN Running

- When signalA = 1, GEN Running is TRUE
- When signalA = 0, GEN Running is FALSE

Example of dual state signals, where signalA represents GEN Running and GEN Stopped

- When signalA = 1, GEN Running is TRUE
- When signalA = 0, GEN Stopped is TRUE

Analog Inputs

Meters used to monitor generators must have available analog inputs to handle the incoming generator-specific analog data. The number of required analog inputs depends on how many measurements are being recorded. For example, analog data can include the following:

- Exhaust Gas Temperature left and right
- Engine Coolant Temperature in and out.
- Engine Oil Pressure

NOTE: Generator analog signals can be obtained through the analog inputs or via Modbus Master from the engine controller. Refer to the *PowerLogic ION7550/7650 User Guide* for more information.

Adding ION devices

Follow these steps to add ION power meters to your system configuration.

NOTE: Complete these steps to prevent any unwanted database actions when modifying the meter framework.

1. Stop the Log Inserter Service, as follows:
 - a. Open the Windows Services panel by clicking:
Start > Administrative Tools > Services

The path to **Services** may vary depending on the Windows operating system being used.

- b. Right-click **ION Log Inserter Service** and select **Stop**.
2. Open the Management Console.
3. Use the Device window in Management Console to add each ION meter.

The Device window includes **Group** and **Name** fields. **Group** is the name under which you want to associate the device you are adding. **Name** identifies the meter that you are adding. The meter name should include a reference to identify which ATS or generator is connected to the meter.

When a meter has been added it appears in the list of devices in *group.name* format. For example, if you named the group **EPSS**, and identified the meter as **ATS1**, the name in the device list is **EPSS.ATS1**. Similarly, if you used the same group to add a meter identified as **GEN1**, the name in the device list is **EPSS.GEN1**. See the *StruxureWare Power Monitoring Expert 8.2 User Guide* or online help for information about adding a meter.

After the power meter is added, configure the appropriate frameworks as described in ["ATS frameworks for EPSS deployment" on page 218](#) and ["Generator frameworks deployment" on page 228](#).

ATS frameworks for EPSS deployment

Use Designer to copy and paste the ATS framework to your ION meter. Repeat this process for every power meter in your system that records ATS data for EPSS purposes.

Pasting ATS frameworks

Before you deploy ATS frameworks, you need to be aware of the implications of free pasting and lock pasting modules.

Use free pasting to paste a new module with a different name if a module with the same name already exists. This helps to ensure that existing modules and their functionality are not replaced.

Use lock pasting to overwrite an existing module and its functionality with a new module, while retaining the module name. However, you need to understand what the modules are currently being used for before you lock paste the modules. A lock paste replaces the functionality of those modules.

- If a power meter already uses all modules of a certain type that are a necessary part of the framework, then a lock paste operation is required.


- If all of the available digital or analog input modules are in use, a lock paste of the analog or digital input modules is required to help ensure that the parameter settings are updated

Copying the ATS framework to the ION power meter


Use Designer to copy and paste the ATS framework to the power meter. Repeat this process for every power meter in the system that records ATS data for the EPSS.

To copy the ATS framework and paste it to the power meter.


1. In **Management Console** click **Tools > System > Designer**. The Designer login window appears.
2. Enter the login credentials with administrator or supervisor access and click **OK**.
3. Click **File > Open**, select the power meter that has the ATS connected to it, and then click **OK** to open the meter's framework.



4. Navigate to **Advanced Setup** and double-click the **Frameworks** folder to open it.




5. Make sure that the Toolbox is open. Select **Options > Show Toolbox** if it is not open.
6. Select **Edit > Paste from framework**. The **Paste from framework** window appears, from which you paste the framework to the **Frameworks – ION Advanced Configuration** folder.





7. Navigate to `C:\Program Files (x86)\Schneider Electric\Power Monitoring Expert for Healthcare\config\fmwk\EPSS`, select the EPSS ATS framework .fwn file, and click **Open**.

For example, in the following image the EPSS ATS framework file is EPSS ATS.fwn.



8. Press SHIFT and left-click to lock paste all of the Digital Input modules listed in the **Paste Summary** dialog, and free paste all of the remaining modules.

NOTE: The lock paste overwrites a module if it already exists on the meter. For more information, see ["ATS frameworks for EPSS deployment" on page 218](#).




9. Do not select **Maintain external inputs**.
10. Press **OK** to paste the EPSS ATS framework.

Configuring ATS frameworks


After the ATS framework has been pasted, configure the ATS framework with site-specific data.

To configure the ATS frameworks:

1. Double-click the framework folder **EPSS ATS** to open its node diagram.



The nodes of the ATS framework, as shown next, support the three single state status signals: Normal, Emergency, and Test. These status signals are received by their respective digital input modules ATS1 Normal, ATS1 Emergency, and ATS1 Test.



The names of the digital input modules are examples to identify how the label the components in the framework. You can rename them to match the system being deployed. For example, ATS1 could be just ATS. The remaining steps use these label names to illustrate the updates made to the framework.

2. Right-click a Digital Input module to access its registers. The **ION Module Setup** screen appears.

The following image shows the registers for the digital input module ATS1 Normal. The ATS controller hardware that this module interfaces with governs how *Input Mode*, *Polarity*, and *Debounce* should be configured.

The image shows the 'ION Module Setup' dialog box. It has two main sections: 'Setup Registers' and 'Output Registers'. The 'Setup Registers' section contains a list of parameters: DI1 Input Mode (KYZ), DI1 EvLog Mode (Log On), DI1 Event Priority (20), DI1 Polarity (Non-Inverting), DI1 Debounce (0.01), and DI1 Port (Port DI1). The 'Output Registers' section contains a list of labels: EPSS_Norm, ATS1 Norm, and **Event**. Below these sections is a 'Module Label' section with two radio buttons: 'Use Default Label' and 'Use Custom Label'. The 'Use Custom Label' radio button is selected, and the text 'ATS1 Normal' is entered in the adjacent text box. At the bottom of the dialog are four buttons: 'OPC...', 'Modify...', 'OK', and 'Cancel'.

3. To update a register, select the register and click **Modify**. The **Modify Registers** screen appears.
4. Change the values to the site-specific sources and quantities. Click **OK** to return to the node diagram. For example:
5. The Setup Register *Input Mode* is set to KYZ, which forces a pulse output on both leading and trailing edges of the signal. This causes the data recorder to record the state on each transition of the signal.
6. The Output Register label `EPSS_Norm` is the name associated with the signal received by the digital input module ATS1 Normal. The maximum number of characters for the label is 15. Examples of Output Register labels for digital input modules ATS1 Emergency and ATS1 Test are `EPSS_Emerg` and `EPSS_Test`, respectively.

Make sure that Output Register labels are consistently labeled across the entire system. For example, if you plan to represent the ATS Normal state as `EPSS_Norm`, then you need to use the same label for all of the ATSs.

For systems that use a single meter to record EPSS status measurements for multiple EPSS devices, the Output Register naming convention for digital input modules must be modified from *quantity* to *quantity@source*.

For example, change `EPSS_Test` to `EPSS_Test@ATSxx` where `xx` uniquely identifies the ATS device.

The *quantity@source* format allows the data it represents to be uniquely identified.

NOTE: The quantities remain the same (EPSS_Test, EPSS_Emerg, EPSS_Norm) but the source name is now unique (ATSxx). If this change is not made, data for all ATSS or generators recorded on the meter cannot be uniquely identified.

7. Right-click the Data Recorder module to access its setup registers.

The image shows the 'ION Module Setup' dialog box. It has two main sections: 'Setup Registers' and 'Output Registers'. The 'Setup Registers' section contains three entries: 'RE18 Depth' with a value of '3,600', 'RE18 RecordMode' with a value of 'Circular', and 'RE18 Insert Outage Records' with a value of 'No'. The 'Output Registers' section contains five entries: 'RE18 Data Log', 'RE18 Log State', 'RE18 Records Left', 'RE18 Record Complete', and '***Event***'. Below these sections is a 'Module Label' section with two radio buttons: 'Use Default Label' (which is unselected) and 'Use Custom Label:' (which is selected). Below the 'Use Custom Label:' radio button is a text input field containing the text 'ATS1 Data Rec'. At the bottom of the dialog box are three buttons: 'Modify...', 'OK', and 'Cancel'.

8. Set the *Depth* setup register to at least a value of 100 to help ensure that data is recorded.
9. Select **Use Custom Label** and add a label that clearly identifies the data recorder within the framework.
10. When you have completed all of the necessary site-specific modifications, click **File > Send & Save** from the node diagram to write your changes to the ION meter.
Refer to the *ION Reference* for more information about configuring setup registers.
11. Restart the Log Inserter Service after you configure the framework.

You can configure the EPSS ATS framework to remotely switch the ATS into test mode, as described next.

NOTE: (Optional) If you have a power outage signal, feed it into the above module with the EPSS Normal Emergency and Test.

Configuring remote ATS test for ION7550/7650 power meters

Switching an ATS to test mode remotely is done by linking a control object in a Vista diagram to a digital output on the ION7550/7650 meter that is connected to the ATS controller.

Refer to *StruxureWare Power Monitoring Expert 8.2 User Guide* for more instructions on working with Vista diagram control objects.

For details about configuring modules, refer to *ION Reference*.

NOTE: The EPSS or ATS framework must be deployed to the meter and configured before you can set up the framework for ATS remote switching. For instructions, refer to ["ATS frameworks for EPSS deployment" on page 218](#).


Configuring the digital output

To configure the digital output for the ION7550/7650 power meter:


1. Open Designer and login as a supervisor.
2. Connect to the meter.
3. In the meter framework, open the EPSS ATS folder.
4. From the Toolbox drag and drop an External Boolean module into the EPSS folder.
5. Locate the Digital Output folder and drag in a Digital Output module.

You can also use CTRL-SHIFT left click to drag in a shortcut to the Digital Output module.


The folder should look similar to the following example:



6. Configure the External Boolean Setup Registers as shown next:



7. Connect the ATSTestSwitch output to the Source input of the Digital Output module, as shown next.



8. Configure the Digital Output module as shown next:

Note the following details for the module setup:

- **Polarity** - Set this to "Non-Inverting"
- **Pulse Width** - Set this to "0"
- **Port** - Set this to the physical port on the meter that is connected to the ATS. In this case, D01.
- **Use Custom Label** - Enter a name easy to recognize, such as "ATSTestOutput."

9. Click the **Send and Save** icon.

Configure the Vista diagram for the meter, as described next.

Configuring the Vista diagram


Follow these steps for the ION7550/7650 power meter. Make sure Designer is closed before linking any objects in Vista.

1. Login to Vista as a supervisor and open a new diagram.
2. From the Toolbox, drag a Control object onto the diagram.
3. Right-click on the Control object. The Control Object Configuration screen appears.


4. Use a custom label, such as "ATSTestSwitch."



5. Configure the link to the External Boolean module's Switch output register, as shown next.



6. Click **OK**.
7. Right-click the ATSTestSwitch object. The Control Object Configuration screen appears.
8. On the **Action** tab, set the **Level to Operate** field to "Controller" as shown next.



9. Click **OK**.
10. Close the Toolbox.
11. Restart the ION Log Inserter Service after you configure the framework.

Now you can control the ATS by clicking the switch.



Generator frameworks deployment


Use Designer to copy and paste the generator framework to the power meter. Repeat this process for every power meter in the system that records generator data. The generator framework is designed to capture generator status changes when they occur, and then to log generator-specific field data when the generator is active.

This framework is a template that should be adjusted to meet the requirements of your site. GEN Start or GEN Run can be used to initiate logging, and the frequency can be adjusted in the periodic timer.

- The status signals for status events GEN Start, GEN Run, and GEN Stop are recorded in the Gen State Log whenever any one of them changes state.



- The logic is designed to record analog and general electrical data when the generator is running. The data is logged at one minute intervals.



- The external Boolean Gen Log En must be linked to a control object in a Vista diagram and enabled before any data is logged. This allows users to notify the system that they are running a test and to log data accordingly.

Pasting Generator Frameworks

Before you deploy generator frameworks, you need to be aware of the implications of free pasting and lock pasting modules.

Use free pasting to paste a new module with a different name if a module with the same name already exists. This helps to ensure that existing modules and their functionality are not replaced.


Use lock pasting to overwrite an existing module and its functionality with a new module, while retaining the module name. However, you need to understand what the modules are currently being used for before you lock paste the modules. A lock paste replaces the functionality of those modules.

- If a power meter already uses all modules of a certain type that are a necessary part of the framework, then a lock paste operation is required.
- If all of the available digital or analog input modules are in use, a lock paste of the analog or digital input modules is required to help ensure that the parameter settings are updated


Copying the generator framework to ION power meters

Use Designer to copy the generator framework to the power meter. Repeat this process for every power meter in the system that records generator data.


1. In **Management Console** click **Tools > System > Designer**. The Designer login window appears.
2. Enter the login credentials with administrator or supervisor access and click **OK**.
3. Click **File > Open**, select the power meter that has the generator connected to it, and then click **OK** to open the meter's framework.



4. Once the meter's framework is open, navigate to **Advanced Setup** and double-click the **Frameworks** folder to open it.




5. Ensure that the Toolbox is open. Select **Options > Show Toolbox**, to open the Toolbox.
6. Select **Edit > Paste from framework** to open the **Paste from framework** window, from which you paste the generator framework to the **Frameworks – SPM Advanced Configuration** folder.




7. Navigate to `... \product install location \config \fmwk \EPSS`, select the generator framework `.fwn` file, and click **Open**.


For example, in the following image the generator framework file is `EPSS GEN.fwn`.



8. Press **Shift** and left-click to lock paste all of the Analog Input and Digital Input modules listed in the **Paste Summary** dialog, and free paste all of the remaining modules.

NOTE: The lock paste overwrites a module if it already exists on the meter. For additional information see ["ATS frameworks for EPSS deployment" on page 218](#).






9. Do not select **Maintain external inputs**.

10. Click **OK** to paste the generator framework.

Configuring the generator framework

Configure the generator framework with site-specific data. Refer to the *ION Reference* for more information about configuring setup registers.


1. After the generator framework has been pasted, double-click the folder **EPSS GEN** to open its node diagram.



The nodes of the generator framework shown below support the three single state status signals: GEN Start, GEN Run, and GEN Stop. These status signals are received by their respective digital input modules GEN Start, GEN Run, and GEN Stop.

The names of the digital input modules are simply placeholders that are used as examples to identify how the components in the framework should be labeled. You can rename them to match the system being deployed. For example, GEN could be GEN1. The remaining descriptions in this section use these example labels to illustrate the updates made to the framework.


The framework also supports three analog signals. In the following image, these are Ex Gas L (exhaust gas left), Ex Gas R (exhaust gas right), and Coolant T (coolant temperature), and these signals are received by their respective analog input modules: Ex Gas L, Ex Gas R, and Coolant T. These module are examples only and they can be modified to any other parameters that need to be monitored and recorded.



A. Analog Input Modules

B. Digital Input Modules

- Right-click a Digital Input module to access its setup registers. The following image shows the registers for the digital input module GEN Start. The generator controller hardware that this module interfaces with governs how it needs to be configured.



- To update a register, select the register and click **Modify**. The **Modify Registers** screen appears.

4. Change the values to the site-specific sources and quantities, and click **OK** to return to the node diagram. For example:
 - The Setup Register *Input Mode* is set to KYZ, which forces a pulse output on both leading and trailing edges of the signal. This causes the data recorder to record the state on each transition of the signal.
 - The Output Register label `EPSS_Start` is the name associated with the signal received by the digital input module GEN Start. The maximum number of characters for the label is 15. Examples of Output Register labels for digital input modules GEN Run and GEN Stop are `EPSS_Run` and `EPSS_Stop`, respectively.

Make sure that Output Register labels are consistent across the entire system. For example, if you plan to represent the GEN Start state as `EPSS_Start`, or the GEN Normal state as `EPSS_Norm`, then you need to use the same label for all of the generators.


For systems that use a single meter to record EPSS status measurements for multiple EPSS devices, the Output Register naming convention for digital input modules must be modified from *quantity* to *quantity@source*.

For example, change `EPSS_Test` to `EPSS_Test@GENxx` where `xx` uniquely identifies the generator device.

The *quantity@source* format allows the data it represents to be uniquely identified.

NOTE: The quantities remain the same (`EPSS_Test`, `EPSS_Emerg`, `EPSS_Norm`) but the source name is now unique (`GENxx`). If this change is not made, data for all generators recorded on the meter cannot be uniquely identified.

5. Right-click an Analog Input module to access its registers. Shown below are the registers for the analog input module Ex Gas L. The generator controller hardware that this module interfaces with governs how it needs to be configured.



- The Output Register label `ExGasL` is the name associated with the signal received by the analog input module Ex Gas L. The maximum number of characters for the label is 15. Examples of Output Register labels for analog input modules Ex Gas R and Coolant T are `ExGasR` and `CoolTemp`, respectively.
 - Output Register labels should be consistent across the entire system. For example, if you plan to represent Exhaust Gas Left as `ExGasL` then you need to use the same label for all of the generators.
6. When you have completed all of the necessary site-specific modifications, click **File > Send & Save** from the node diagram to write your changes to the power meter.
 7. Restart the ION Log Inserter Service after configuring the generator frameworks.

Non-ION power meter configuration

This section provides information about configuring non-ION power meters for the Power Monitoring Expert 8.2 solution.

⚠ WARNING
UNINTENDED OPERATION • Do not use the power meters for critical control or protection applications where human or equipment safety relies on the operation of the control circuit. Failure to follow these instructions can result in death, serious injury, or equipment damage.

Refer to your meter's technical documentation for more information on its operation.

Supported non-ION power meters

Power Monitoring Expert solutions can use the following non-ION power meters for the EPSS:

- PM800 series power meters. Refer to ["PM800 series meter configuration" on page 236](#).
- PowerLogic Circuit Monitor Series 3000 and 4000 Power Meters. Refer to ["CM3000 and CM4000 series meter configuration" on page 254](#).

Supported Sequence of Event Recorders

- SER-2408/SER-3200. Refer to ["Adding the SER-2408/SER-3200 to Management Console" on page 272](#).

Prerequisites

The following prerequisites must be completed before attempting to configure a non-ION power meter to record data from generators and other equipment:

- The Power Monitoring Expert solution is installed and operational.
- All meters must be installed and communicating.

- The following status signals for each ATS are physically wired to the digital inputs on the appropriate meters.
 - Normal
 - Emergency
 - Test
 - Power Outage (optional)
- The following status signals for each generator are physically wired to the digital inputs on the appropriate meters.
 - Start (optional)
 - Emergency Power Source Available (optional)
 - Run
 - Stop
- The following generator electrical data are metered and available for each generator:
 - Currents: A, B, C, N, Avg
 - Minimum Apparent Power Total
 - Minimum Real Power Total
 - Frequency
 - Real Power Total
 - Apparent Power Total
 - Voltages: A-B, B-C, C-A, L-L Avg, A-N, B-N, C-N, L-N Avg
- The following signals for each generator are physically wired to the analog inputs on the appropriate meters. The number of analog inputs required depends on how many measurements are being recorded. For example, analog data can include the following:
 - Exhaust Gas Temperature left and right
 - Engine Coolant Temperature in and out
 - Engine Oil Pressure

PM800 series meter configuration

This chapter describes how to use PowerLogic™ ION Setup to configure meters. This section does not explain how to add power meters to the system or how to use ION Setup.

- For information about adding meters to the system, refer to the Management Console online help or the Management Console section of the *StruxureWare Power Monitoring Expert 8.2 User Guide*.
- For information about ION Setup software, refer to ION Setup online Help or the *PowerLogic ION Setup User Guide*.

For more information about configuring the PM800 series meters using ION Setup software:


- *Additional Device Support in ION Setup* in the ION Setup online help
- *PowerLogic ION Setup Device Configuration Guide*

You can configure the PM800 series meter for switching the ATS into test mode remotely. See ["Configuring Auto-Enable data logs for CM4000 and PM800 series" on page 268](#) for instructions.


Adding PM800 series meters to a site using ION Setup

Use ION Setup to add PM850 or PM870 meters to the site.

1. In the devices area, right-click and select **Insert Item**. The **New Network Item** screen appears.




2. Select **Meter** and click **OK**. The **New Device** screen appears.
3. Select the **General** tab
4. In the **Type** list, select **PowerLogic PM800 Series Power Meter**.
5. Select the **Display** tab. In the **Template Options** box, select the type of meter you are adding.



6. Click **OK** to add the meter.

7. In the Network Viewer (left pane), click the meter icon. The setup screens appear in the Content Viewer (right pane).

The following image shows a partial list of the setup screens. Use the **I/O Setup**, **Onboard Alarms/Events**, and **Data Log** setup screens to access the parameters that need to be configured. The remaining topics in this chapter describe the parameter changes that are required.



For more information about adding PM850 or PM870 meters to a site in ION Setup, refer to the following:

- ION Setup online help
- *PowerLogic ION Setup Device Configuration Guide*, "PM800 series power meter" section
- *PowerLogic ION Setup User Guide*, "Adding and Configuring Devices" section

Digital and analog input configuration

This section describes how to configure the digital and analog inputs for the PM800 meters. The instructions assume that you are using separate PM800 series power meters to record data for ATSS and generators.

⚠ WARNING

UNINTENDED OPERATION

- Do not use the meters for critical control or protection applications where human or equipment safety relies on the operation of the control circuit.


Failure to follow these instructions can result in death, serious injury, or equipment damage.

Refer to your meter's technical documentation for more information on its operation.

Configuring digital inputs

1. In the Content Viewer, double-click **I/O Setup** to access the Digital Inputs for the meter.
2. Select the I/O point that you want to configure and click **Edit**.

The following image shows **Digital In A-S1** selected.



3. Update the **Label** field with a name that ends with the \$ character.

The \$ character activates the translated device dynamic labeling feature. If the \$ character is not used, the default label is used.

- For an ATS, examples of labels that conform to the naming convention are EPSS_Test\$, EPSS_Emerg\$, EPSS_Norm\$, and EPSS_Util\$.
 - For a generator, examples of labels are EPSS_Start\$, EPSS_Run\$, and EPSS_Stop\$.
4. Set **Mode** to Normal, **Pulse Weight** to a non-zero value, for example 100, and leave **Units** set as No Units.
 5. Click **OK** to update the parameters and to close the dialog.
 6. Repeat the steps above for each I/O point that you want to configure.
 7. Click **Send** to save the changes and send the configuration to the meter.

Configuring analog inputs


PM800 series power meter Analog Inputs are only available when you install the PM8M2222 Input/Output module on the meter.

Refer to the *Power Meter Input/Output Module PM8M2222, PM8M26, PM8M22 Installation Manual* for more information about installing the input/output module. Obtain this installation manual at www.powerlogic.com. Select the country, and then **Energy and Power Quality Meters > PowerLogic Multifunction Power Meters > PM800 Series > Downloads > Tech Publications**.

To configure analog inputs:

1. In the Content Viewer, double-click **I/O Setup** to access the Analog Inputs for the meter.
2. Select the I/O point that you want to configure and click **Edit**.


The following image shows **Analog In A-AI1** selected.



3. Click **Edit** to open the parameter window for the I/O point and update the **Label** field with a name that ends with the \$ character.

For a generator, examples of labels for analog inputs are Exhaust Gas L\$, Exhaust Gas R\$, and Coolant T\$.

The following image shows the label updated to Exhaust Gas L\$.



4. Click **OK** to update the parameters and to close the dialog.
5. Repeat the steps above for each I/O point that you want to configure.
6. Click **Send** to save the changes and send the configuration to the meter.

Onboard alarm and event configuration

For each digital input configured in I/O Setup, you need to configure the alarms to record when the digital input on an ATS or a generator changes from OFF to ON, and also from ON to OFF.

Configuring digital input alarms for ATSS


This section assumes that you configured digital inputs **Digital In A-S1** as EPSS_Test\$, **Digital In A-S2** as EPSS_Emerg\$, and **Digital In A-S3** as EPSS_Norm\$. You must configure an alarm for the digital input change from OFF to ON and from ON to OFF.

Digital input change from OFF to ON

To configure an alarm when a digital input changes from OFF to ON:


1. In the Content Viewer, double-click **Onboard Alarms/Events** to open the **Setup** dialog.
2. Select **Digital** and click **Edit** to open the **Digital Alarm Setup** dialog.
3. Select one of the Digital Input/Output points.

The following figure shows the **Digital In A-S1** input selected and its label EPSS_Test\$.



4. Select **Status Input On** from the list to set the alarm when the digital input changes from OFF to ON.
5. Make sure that **Enable** is selected.

6. In the **Label** field, change the digital alarm name from **Digital In A-S1** to **Test ON**.



7. Set **Priority** to High(1), and select Data Log 1 as the data log to use. Select **Waveform Capture** if you want to trigger a waveform capture on alarm.


When the status for EPSS_Test\$ changes to ON, Data Log 1 records all channels currently configured on it.

Digital input change from ON to OFF

To configure an alarm when a digital input for EPSS_Test\$ changes from ON to OFF:

1. Click **Add** to add another digital input alarm parameter to the list in the left pane of the **Digital Alarm Setup** dialog.

NOTE: If the 12 available digital input alarms have been configured, you need to re-configure an existing alarm for the ON to OFF status change.



2. Select **Status Input Off** from the list to set the alarm when the digital input changes from ON to OFF.
3. Select EPSS_Test\$ from the list.

4. Make sure that **Enable** is selected.
5. In the **Label** field, change the digital alarm name to **Test OFF**.
6. Set **Priority** to High(1), and select Data Log 1 as the data log to use. Select **Waveform Capture** if you want to trigger a waveform capture on alarm.
7. Repeat the steps above to configure alarms for digital input changes from OFF to ON and from ON to OFF for all of the applicable I/O points.

The following table summarizes the configuration of the alarms, assuming that the I/O points are Digital In A-S1, Digital In A-S2, and Digital In A-S3:

Digital Input Label	Maps to	Alarm Status	Alarm Name
EPSS_Test\$	Digital In A-S1	Status Input On	Test ON
EPSS_Test\$	Digital In A-S1	Status Input Off	Test OFF
EPSS_Emerg\$	Digital In A-S2	Status Input On	Emerg ON
EPSS_Emerg\$	Digital In A-S2	Status Input Off	Emerg OFF
EPSS_Norm\$	Digital In A-S3	Status Input On	Normal ON
EPSS_Norm\$	Digital In A-S3	Status Input Off	Normal OFF

8. Click **OK** to close the dialog.
9. Click **Send** to save the changes and send the configuration to the meter.

Configuring digital input alarms for generators


This section assumes that you configured digital inputs **Digital In A-S1** as EPSS_Start\$, **Digital In A-S2** as EPSS_Run\$, and **Digital In A-S3** as EPSS_Stop\$. You must configure an alarm for the digital input change from OFF to ON and from ON to OFF.

EPSS_Start\$: Digital input change from OFF to ON


To configure an alarm when a digital input changes from OFF to ON:

1. In the Content Viewer, double-click **Onboard Alarms/Events** to open the **Setup** dialog.
2. Select **Digital** and click **Edit** to open the **Digital Alarm Setup** dialog.
3. Select one of the Digital Input/Output points.

The following figure shows the **Digital In A-S1** input selected and its label EPSS_Start\$



4. Select **Status Input On** from the list to set the alarm when the digital input changes from OFF to ON.
5. Make sure that **Enable** is selected.
6. In the **Label** field, change the digital alarm name from **Digital In A-S1** to **Start ON**.



7. Set **Priority** to High(1), and select Data Log 1 as the data log to use. Select **Waveform Capture** if you want to trigger a waveform capture on alarm.

When the status for `EPSS_Start$` changes to ON, Data Log 1 records all channels currently configured on it.

EPSS_Start\$: Digital input change from ON to OFF

To configure an alarm when a digital input for `EPSS_Start$` changes from ON to OFF:

1. Click **Add** to add another digital input alarm parameter to the list in the left pane of the **Digital Alarm Setup** dialog.

NOTE: If the 12 available digital input alarms have been configured, you need to re-configure an existing alarm for the ON to OFF status change.

2. Select **Status Input Off** from the list to set the alarm when the digital input changes from ON to OFF.
3. Select EPSS_Start\$ from the list.
4. Make sure that **Enable** is selected.
5. In the **Label** field, change the digital alarm name to **Start OFF**.
6. Set **Priority** to High(1), and select Data Log 1 as the data log to use. Select **Waveform Capture** if you want to trigger a waveform capture on alarm.
7. Repeat the steps above to configure alarms for digital input changes from OFF to ON and from ON to OFF for all of the applicable I/O points.

The following table summarizes the configuration of the alarms, assuming that the I/O points are Digital In A-S1, Digital In A-S2, and Digital In A-S3:

Digital Input Label	Maps to	Alarm Status	Alarm Name
EPSS_Start\$	Digital In A-S1	Status Input On	Start ON
EPSS_Start\$	Digital In A-S1	Status Input Off	Start OFF
EPSS_Run\$	Digital In A-S2	Status Input On	Run ON
EPSS_Run\$	Digital In A-S2	Status Input Off	Run OFF
EPSS_Stop\$	Digital In A-S3	Status Input On	Stop ON
EPSS_Stop\$	Digital In A-S3	Status Input Off	Stop OFF

8. Click **OK** to close the dialog.
9. Click **Send** to save the changes and send the configuration to the meter.

Define a Digital Alarm for a Single Digital Input

If a single digital input is used to record signals indicating when the generator is running, and also when the generator has stopped, you need to define the digital alarm as follows:

1. In the **Digital Alarm Setup** dialog, select the Digital Input/Output point that will be used to record the alarm. For example, if you configured **Digital In A-S1** with a label of `EPSS_Run$`, select this I/O point.
2. Select **Status Input On** from the list to set the alarm when the digital input changes from OFF to ON.
3. Make sure that **Enable** is selected.
4. In the **Label** field, change the digital alarm name from **Digital In A-S1** to **Run ON**.
5. Set **Priority** to High(1), and select Data Log 1 as the data log to use.

EPSS_Run\$: Digital input change from ON to OFF

1. Click **Add** to add another digital input alarm parameter to the list in the left pane of the **Digital Alarm Setup** dialog.
2. Select **Status Input Off** from the list to set the alarm when the digital input changes from ON to OFF.
3. Select `EPSS_Run$` from the list.
4. Make sure that **Enable** is selected.
5. In the **Label** field, change the digital alarm name to **Stop ON**.
6. Set **Priority** to High(1), and select Data Log 1 as the data log to use.
7. Click **OK** to close the dialog.
8. Click **Send** to save the changes and send the configuration to the meter.

As a result of this alarm configuration where `EPSS_Run$` represents both the Running and Stopped states for the generator, when **Run ON** is TRUE, the signal is recorded as "1", and when **Stop ON** is TRUE, the signal is recorded as "0".

Data log parameter definition


This section explains how to define data log parameters for the digital inputs, analog inputs, and load profile data. The instructions assume that you use Data Logs 1 and 2. However, you can use any Data Log that meets your requirements.

Defining data log parameters for digital inputs


To define the data log parameters for the digital inputs:

1. In the Content Viewer, double-click **Data Log #1** to open the **Setup** dialog for the data log parameters.
2. Set **Status** to Enable and **Interval** to Only On Event. The Only On Event mode appears as 0 in the **Interval** field of the **Setup** dialog.

3. Select **Channels**, click **Edit**. The Parameter Selection dialog appears.



4. In the **Available** box, navigate to **Inputs/Outputs** and select a custom label, such as `EPSS_Emerg$`.
5. Select the **IO Point xx Digital State**, where xx is the number of the I/O point present on the meter. Click **>>** to move the parameter to the **Selected** box.



6. Repeat steps 4 - 5 for all I/O points available for the ATS or generator.
7. In the **Available** box, expand **Miscellaneous** and select **Present MilliSeconds**. Click **>>** to move it to the **Selected** column.

NOTE: Add all I/O points for a given ATS or generator to the data log to help ensure that all of the states are recorded in the data log when any state changes.

8. Click **OK** to close the dialog.
9. Click **Send** to save the changes and send the configuration to the meter.

Defining data log parameters for analog inputs and load profile data

Configure the system to log the analog inputs and load profile data automatically when the generator state changes to Running. When the generator state is Running, the alarm status for digital input EPSS_Run\$ is ON.


Using ION Setup, the process to configure automatic logging is:

1. Associate Data Log 2 with the digital input alarm **Run ON** that you previously defined for EPSS_Run\$.
2. Select the parameters for the Analog Input data to be logged in Data Log 2.
3. Select the parameters for the Load Profile data to be logged in Data Log 2.
4. Set the status of Data Log 2 to Auto-Enable.

These steps assume that you use Data Log 2.

Associate Data Log 2 with the Digital Input Alarm Run ON


1. In the Content Viewer, double-click **Onboard Alarms/Events** to open the **Setup** dialog.
2. Select **Digital** and click **Edit** to open the **Digital Alarm Setup** dialog.
3. Select the digital input alarm **Run ON** that was defined for I/O point EPSS_Run\$. You previously selected Data Log 1 when you configured this digital input alarm for the generator.
4. In the **Data Logs:** group, select **2**. Now both **1** and **2** are selected.




5. Click **OK** to close the dialog.
6. Click **Send** to save the changes and send the configuration to the meter.

Select Parameters for Analog Input Data to be logged in Data Log 2

1. In the Content Viewer, double-click **Data Log #2** to open the **Setup** dialog for the data log parameters.
2. Select **Interval** and click **Edit** to open the **Enter Logging Interval** dialog. Select **Continuous** from the list in **Mode**, set **Interval** to 1 minute, and click **OK** to close the dialog.



3. Select **Channels**, click **Edit**. The Parameter Selection dialog appears.
4. In the **Available** box, navigate to **Inputs/Outputs** and select a custom label, such as Exhaust Gas L\$.
5. Under **Analog Input**, select the **IO Point xx Analog Input Value**, where xx is the number of the I/O point present on the meter. Click **>>** to move the parameter to the **Selected** box.




6. Repeat steps 4 - 5 for each analog input available for the generator.

7. Click **OK** to close the dialog.
8. Click **Send** to save the changes and send the configuration to the meter.

Select Parameters for Load Profile Data to be logged in Data Log 2

1. In the **Setup** dialog for Data Log 2, select **Channels** and click **Edit**. The **Parameter Selection** dialog appears.
2. Expand each of the following categories. Within each category select the parameters indicated. For each parameter click **>>** to move it to the **Selected** column:
 - a. In **Currents**, select Current A, Current B, Current C, Current N, and Current Avg.
 - b. In **Minimum Readings**, select Min Apparent Power Total, Min Real Power Total.
 - c. In **Miscellaneous**, select Frequency.
 - d. In **Powers**, select Real Power Total and Apparent Power Total.
 - e. In **Voltages**, select Voltage A-B, Voltage B-C, Voltage C-A, Voltage L-L Avg, Voltage A-N, Voltage B-N, Voltage C-N, and Voltage L-N Avg.




3. Click **OK** to close the dialog.
4. Click **Send** to save the changes and send the configuration to the meter.

Set the Status of Data Log 2 to Auto-Enable

Auto-Enable is a special mode that allows logging to be triggered when an alarm occurs. Data is recorded in the data log at a defined interval if the logging mode is set to **Continuous**. Logging stops when the alarm ends.

1. In the **Setup** dialog for Data Log 2, select **Status** and click **Edit**. The **Select Status** dialog appears.

2. In the drop-down list, select **Auto-Enable** and click **OK** to close the dialog.



3. Click **Send** to save the changes and send the configuration to the meter.

You can also use Vista to set a Data Log to Auto-Enable. Refer to ["Configuring Auto-Enable data logs for CM4000 and PM800 series" on page 268](#) for more information.

Configuring remote ATS test mode for PM800 series meter

Switching an ATS to test mode remotely is done by linking a control object in a Vista diagram to a digital output on the PM800 series meter that is connected to the ATS controller.


Refer to *StruxureWare Power Monitoring Expert 8.2 User Guide* for more instructions on working with Vista diagram control objects.

For details about configuring modules, refer to *ION Reference*.

Configuring the digital output

Configure the onboard KY output for the meter as follows:

1. In ION Setup for the meter, click I/O Setup. The **Gateway Site** screen appears.
2. In the **Parameters** box, select Digital Out KY and click **Edit**.



3. In the **Mode** field, select Normal.
The mode is dependent on the characteristics of the digital input port on the ATS controller.
4. In the **Control** field, select Externally Controlled.
This allows the meter to accept external commands from an application like Vista.
5. Click **OK**. The **Gateway Site** screen appears.
6. Select **Send** to update the meter.

Configure the Vista Diagram for the meter, as described next.


Configuring the Vista diagram

Follow these steps for the PM800 power meter. Make sure Designer is closed before linking any objects in Vista.


Because you will be adding control objects to a Vista diagram, consider who needs access to those control objects and assign permissions appropriately.

In Vista, open a new diagram and complete the setup as follows:


1. Open a new diagram in Vista.
2. Drag a Control object from the Toolbox and link it to KY Energize, as shown next.



3. Right-click the Control object.
4. On the **Action** tab, set the **Level to Operate** field to Controller, and click **OK**.
5. Drag another Control object from the Toolbox and link it to KY DeEnergize.
6. Right-click the Control object.
7. On the **Action** tab, set the **Level to Operate** field to Controller, and click **OK**.
8. Drag a Status object and link it to the Standard KY Digital Output Status, as shown next.



9. Save the diagram. The following image is an example of the Vista diagram.



You can now use the diagram to control and view the state of the onboard digital output port.

CM3000 and CM4000 series meter configuration

This section describes how to configure CM3000 and CM4000 series meters for the system.

To obtain the *CM3000 Installation Manual*, *CM3000 Reference Manual*, and related instructions, go to www.powerlogic.com and search for "CM3000 installation."

To obtain instructions for installing and configuring CM4000 series meters, go to www.powerlogic.com. Select the country, and then **Energy and Power Quality Meters > PowerLogic Energy and Power Quality Meters > CM4000 > Downloads > Tech Publications**.

- Installation Manual
- Reference Manual
- Series 4000T Reference Manual
- I/O Extender and Input/Output Option Card

You can configure the CM4000 series meter for switching the ATS into test mode remotely. See ["Configuring Auto-Enable data logs for CM4000 and PM800 series" on page 268](#) for instructions.

Add CM4000 Series Meters to a Site in ION Setup


Complete the following steps to add CM4000 series meters to a site in ION Setup.

1. In the Network Viewer, right-click the workstation icon and select **Insert Item > Site**. The **New Site** dialog appears.
2. Add a name to identify the site, select **Ethernet**, and click **OK**. The new site appears in the Network Viewer.
3. In the Network Viewer, right-click the new site name and select **Insert Item > Meter**. The **New Device** dialog appears.
4. Complete the following:
 - Name** - Enter a name to identify the meter.
 - Type** - Select Modbus TCP Device from the dropdown list.

IP Address - Enter the IP address for the Modbus TCP.

Port - Select 502 from the dropdown list.

Group - Select a group name from the list or enter a name to define a new group.




The 'New Device' dialog box is shown with the 'General' tab selected. It contains the following fields:

- Name: CM4
- Type: Modbus TCP Device
- IP Address: 10.168.69.80
- IP Port: 502
- Group: Group 1

Buttons at the bottom: OK, Cancel, Help.

- Click the **Display** tab and select the CM4000 (EPSS) template option.




The 'New Device' dialog box is shown with the 'Display' tab selected. It contains the following fields:

- Template Type: MODBUS
- Template Options: A list box with the following options: 6200 ION V203 or later, 6300 ION, 9200 ION, CM3000 (EPSS), **CM4000 (EPSS)** (selected), and Default.

Buttons at the bottom: OK, Cancel, Help.

- Click **OK**. The meter is added to the Network Viewer.
- In the Network Viewer, click the meter icon. The setup screens appear in the Content Viewer.

The following image shows the setup screens. Use the **I/O Setup**, **Onboard Alarms/Events**, and **Data Log** setup screens to access the parameters that need to be configured. The remaining topics in this chapter describe the parameter changes that are required.



Digital and analog input configuration


This section describes how to configure digital and analog inputs to record data on CM4000 series power meters for the ATSS and generators.

Configuring digital inputs

In the Content Viewer, double-click **I/O Setup** to access the Digital Inputs for the meter.

1. Select the I/O point that you want to configure and click **Edit**.

The following image shows **Dig In B-S1** selected.



2. Update the **Label** field with the name that ends with the \$ character.

The \$ character activates the translated device dynamic labeling feature. If the \$ character is not used, the default label is used.

- For an ATS, examples of labels that conform to the naming convention are EPSS_Test\$, EPSS_Emerg\$, EPSS_Norm\$, and EPSS_Util\$.
- For a generator, examples of labels are EPSS_Start\$, EPSS_Run\$, and EPSS_Stop\$.


3. Set **Mode** to Normal, **Pulse Weight** to a non-zero value, for example 100, and leave **Units** set as No Units.
4. Click **OK** to update the parameters and to close the dialog.
5. Repeat the steps above for each I/O point that you want to configure.
6. Click **Send** to save the changes and send the configuration to the meter.

Configuring analog inputs

In the Content Viewer, double-click I/O Setup to access the Analog Inputs for the meter.

1. Select the I/O point that you want to configure and click **Edit**.


The following image shows **Alog In C-A11** selected.



2. Click **Edit** to open the parameter window for the I/O point and update the **Label** field with a name that ends with the \$ character.

For a generator, examples of labels for analog inputs are Exhaust Gas L\$, Exhaust Gas R\$, and Coolant T\$.

The following image shows the label updated to Exhaust Gas L\$.



3. Click **OK** to update the parameters and to close the dialog.
4. Repeat the steps above for each I/O point that you want to configure.
5. Click **Send** to save the changes and send the configuration to the meter.

Onboard alarms and events configuration

For each digital input configured in I/O setup, configure the alarms to record when the digital input on an ATS or a generator changes from OFF to ON, and also from ON to OFF.


Configuring digital input alarms for ATSS

This section assumes that you configured digital inputs **Dig In B-S1** as EPSS_Test\$, **Dig In B-S2** as EPSS_Emerg\$, and **Dig In B-S3** as EPSS_Norm\$.

Changing digital input from OFF to ON


1. In the Content Viewer, double-click **Onboard Alarms/Events** to open the **Setup** dialog.
2. Select **Digital** and click **Edit** to open the **Digital Alarm Setup** dialog.
3. Select one of the Digital Input/Output points.

The following figure shows the **Dig In B-S1** input selected and its EPSS_Test\$ label, configured in **I/O Setup**.



4. Select **Status Input On** from the list to set the alarm when the digital input changes from OFF to ON.
5. Make sure that **Enable** is selected.

6. In the **Label** field, change the digital alarm name from **Dig In B-S1** to **Test ON**.




7. Set **Priority** to High(1), and select Data Log 2 as the data log to use.

When the status for EPSS_Test\$ changes to ON, Data Log 2 records all channels currently configured on it.

Changing digital input from ON to OFF

1. Click **Add** to add another digital input alarm parameter to the list in the left pane of the **Digital Alarm Setup** dialog.

NOTE: If all 40 available digital input alarms have been configured already, you need to re-configure an existing alarm for the ON to OFF status change.



2. Select **Status Input Off** from the list to set the alarm when the digital input changes from ON to OFF.
3. Select `EPSS_Test$` from the list.
4. Make sure that **Enable** is selected.
5. In the **Label** field, change the digital alarm name to **Test OFF**.
6. Set **Priority** to High(1), and select Data Log 2 as the data log to use.
7. Repeat the steps above to configure alarms for digital input changes from OFF to ON and from ON to OFF for all of the applicable I/O points.

The following table summarizes the configuration of the alarms, assuming that the I/O points are Dig In B-S1, Dig In B-S2, and Dig In B-S3:

Digital Input Label	Maps to	Alarm Status	Alarm Name
EPSS_Test\$	Digital In B-S1	Status Input On	Test ON
EPSS_Test\$	Digital In B-S1	Status Input Off	Test OFF
EPSS_Emerg\$	Digital In B-S2	Status Input On	Emerg ON
EPSS_Emerg\$	Digital In B-S2	Status Input Off	Emerg OFF
EPSS_Norm\$	Digital In B-S3	Status Input On	Normal ON
EPSS_Norm\$	Digital In B-S3	Status Input Off	Normal OFF

8. Click **OK** to close the dialog.
9. Click **Send** to save the changes and send the configuration to the meter.


Configuring Digital Input Alarms for Generators

This section assumes that you configured digital inputs **Dig In B-S1** as `EPSS_Start$`, **Dig In B-S2** as `EPSS_Run$`, and **Dig In B-S3** as `EPSS_Stop$`.


Digital input change from OFF to ON

1. In the Content Viewer, double-click **Onboard Alarms/Events** to open the **Setup** dialog.
2. Select **Digital** and click **Edit** to open the **Digital Alarm Setup** dialog.
3. Select one of the Digital Input/Output points.

The following screenshot shows the **Dig In B-S1** input selected and its `EPSS_Start$` label, as configured in **I/O Setup**.



4. Select **Status Input On** from the list to set the alarm when the digital input changes from OFF to ON.
5. Make sure that **Enable** is selected.
6. In the **Label** field, change the digital alarm name from **Dig In B-S1** to **Start ON**.



7. Set **Priority** to High(1), and select Data Log 2 as the data log to use.
When the status for EPSS_Start\$ changes to ON, Data Log 2 records all channels currently configured on it.

Digital input change from ON to OFF

1. Click **Add** to add another digital input alarm parameter to the list in the left pane of the **Digital Alarm Setup** dialog.

NOTE: If all 40 available digital input alarms have been configured already, you need to re-configure an existing alarm for the ON to OFF status change.

The screenshot shows the 'Digital Alarm Setup' dialog box. On the left, a list of digital input points includes 'End Inc Enr Int', 'End Dmd Int', 'End 1s Cyc', 'End 100ms Cyc', 'Pwr Up/Reset', 'Dig In B-S1', 'Dig In B-S2', 'Dig In B-S3', 'Dig In B-S4', 'Dig In C2', 'Dig In C3', 'Dig In C4', 'Dig In C5', and 'Digital 10'. 'Digital 10' is selected. On the right, the 'Status Input Off' dropdown is selected, and 'EPSS_Start\$' is entered in the input field. The 'Enable' checkbox is checked, and the 'Label' field contains 'Start OFF'. The 'Priority' dropdown is set to 'High (1)'. Under the 'Capture on Event' section, 'Data Log 2' is selected with a checked checkbox. There are also checkboxes for 'Data Log 01', 'Data Log 03', and 'Data Log 04'. An 'Outputs' button is located to the right of the 'Capture on Event' section. At the bottom, there are buttons for 'Add', 'Delete', 'OK', 'Cancel', and 'Help'.

2. Select **Status Input Off** from the list to set the alarm when the digital input changes from ON to OFF.
3. Select `EPSS_Start$` from the list.
4. Make sure that **Enable** is selected.
5. In the **Label** field, change the digital alarm name to **Start OFF**.
6. Set **Priority** to High(1), and select Data Log 2 as the data log to use.
7. Repeat the steps above to configure alarms for digital input changes from OFF to ON and from ON to OFF for all of the applicable I/O points.

The following table summarizes the configuration of the alarms, assuming that the I/O points are Dig In B-S1, Dig In B-S2, and Dig In B-S3:

Digital Input Label	Maps to	Alarm Status	Alarm Name
EPSS_Start\$	Dig In B-S1	Status Input On	Start ON
EPSS_Start\$	Dig In B-S1	Status Input Off	Start OFF
EPSS_Run\$	Dig In B-S2	Status Input On	Run ON

EPSS_Run\$	Dig In B-S2	Status Input Off	Run OFF
EPSS_Stop\$	Dig In B-S3	Status Input On	Stop ON
EPSS_Stop\$	Dig In B-S3	Status Input Off	Stop OFF

8. Click **OK** to close the dialog.
9. Click **Send** to save the changes and send the configuration to the meter.

Defining a Digital Alarm for a Single Digital Input

If a single digital input is used to record signals indicating when the generator is running, and also when the generator has stopped, you need to define the digital alarm as follows:

1. In the **Digital Alarm Setup** dialog, select the Digital Input/Output point that will be used to record the alarm. For example, if you configured **Dig In B-S1** with a label of `EPSS_Run$`, select this I/O point.
2. Select **Status Input On** from the list to set the alarm when the digital input changes from OFF to ON.
3. Make sure that **Enable** is selected.
4. In the **Label** field, change the digital alarm name from **Dig In B-S1** to **Run ON**.
5. Set **Priority** to High(1), and select Data Log 2 as the data log to use.

EPSS_Run\$: Digital Input Change from ON to OFF

1. Click **Add** to add another digital input alarm parameter to the list in the left pane of the **Digital Alarm Setup** dialog.
2. Select **Status Input Off** from the list to set the alarm when the digital input changes from ON to OFF.
3. Select `EPSS_Run$` from the list.
4. Make sure that **Enable** is selected.
5. In the **Label** field, change the digital alarm name to **Stop ON**.
6. Set **Priority** to High(1), and select Data Log 2 as the data log to use.
7. Click **OK** to close the dialog.
8. Click **Send** to save the changes and send the configuration to the meter.

As a result of this alarm configuration where `EPSS_Run$` represents both the Running and Stopped states for the generator, when **Run ON** is TRUE, the signal is recorded as "1", and when **Stop ON** is TRUE, the signal is recorded as "0".


Configure the Data Log Parameters

This section describes how to define data log parameters for the digital inputs, analog inputs, and load profile data. The instructions assume that you use Data Logs 2 and 3. However, you can use any Data Log that meets your requirements.


Define Data Log Parameters for Digital Inputs

Complete the following steps to define the data log parameters for the digital inputs.

1. In the Content Viewer, double-click **Data Log #2** to open the **Setup** dialog for the data log parameters.
2. Set **Status** to Enable and **Interval** to Only On Event.
3. Select **Channels**, click **Edit**. The Parameter Selection screen appears.



4. In the **Available** box, navigate to **Inputs/Outputs** and select a custom label, such as EPSS_Emerg\$.
5. Under **Digital Input**, select the **IO Point xx Digital State**, where xx is the number of the I/O point present on the meter. Click >> to move the parameter to the **Selected** box.



6. Repeat steps 4 - 5 for all I/O points available for the ATS or generator.

- In the **Available** box, expand **Miscellaneous** and select **Present MilliSeconds**. Click **>>** to move it to the **Selected** box.

NOTE: Add all I/O points for a given ATS or generator to the data log to help ensure that all of the states are recorded in the data log when any state changes.

- Click **OK** to close the screen.
- Click **Send** to save the changes and send the configuration to the meter.

Define Data Log Parameters for Analog Inputs and Load Profile Data

Configure the system to log the analog inputs and load profile data automatically when the generator state changes to Running. When the generator state is Running, the alarm status for digital input `EPSS_Run$` is ON.


Using ION Setup, the process to configure automatic logging is:

- Associate Data Log 3 with the digital input alarm **Run ON** that you previously defined for `EPSS_Run$`.
- Select the parameters for the Analog Input data to be logged in Data Log 3.
- Select the parameters for the Load Profile data to be logged in Data Log 3.
- Set the status of Data Log 3 to Auto-Enable.

These steps assume that you use Data Log 3.

Associate Data Log 3 with the Digital Input Alarm Run ON


- In the Content Viewer, double-click **Onboard Alarms/Events** to open the **Setup** dialog.
- Select **Digital** and click **Edit** to open the **Digital Alarm Setup** dialog.
- Select the digital input alarm **Run ON** that was defined for I/O point `EPSS_Run$`. You previously selected Data Log 2 when you configured this digital input alarm for the generator.
- In the **Capture on Event** list, select Data Log 3. Now both Data Logs 2 and 3 are selected.




5. Click **OK** to close the screen.
6. Click **Send** to save the changes and send the configuration to the meter.

Select Parameters for Analog Input Data to be logged in Data Log 3

1. In the Content Viewer, double-click **Data Log #3** to open the **Setup** dialog.
2. Select **Interval** and click **Edit** to open the **Enter Logging Interval** dialog.
3. In the **Mode** list, select **Continuous**. Set **Interval** to 1 minute, and click **OK** to close the dialog.




4. Select **Channels**, click **Edit**. The Parameter Selection screen appears.
5. In the **Available** box, navigate to **Inputs/Outputs** and select a custom label, such as Exhaust Gas L\$.
6. Under **Analog Input**, select the **IO Point xx Analog Input Value**, where xx is the number of the I/O point present on the meter. Click **>>** to move the parameter to the **Selected** box.



7. Repeat steps 4 - 5 for each analog input available for the generator.
8. Click **OK** to close the dialog.
9. Click **Send** to save the changes and send the configuration to the meter.

Select Parameters for Load Profile Data to be logged in Data Log 3

1. In the **Setup** dialog for Data Log 3, select **Channels** and click **Edit**. The **Parameter Selection** dialog appears.
2. Expand each of the following categories. Within each category, select the parameters indicated. For each parameter click **>>** to move it to the **Selected** column:
 - a. In **Currents**, select Current A, Current B, Current C, Current N, and Current Avg.
 - b. In **Minimum Readings**, select Min Apparent Power Total, Min Real Power Total.
 - c. In **Miscellaneous**, select Frequency.
 - d. In **Powers**, select Real Power Total and Apparent Power Total.
 - e. In **Voltages**, select Voltage A-B, Voltage B-C, Voltage C-A, Voltage L-L Avg, Voltage A-N, Voltage B-N, Voltage C-N, and Voltage L-N Avg.




3. Click **OK** to close the dialog.
4. Click **Send** to save the changes and send the configuration to the meter.

Set the Status of Data Log 3 to Auto-Enable

Auto-Enable is a special mode that allows logging to be triggered when an alarm occurs. Data is recorded in the data log at a defined interval if the logging mode is set to **Continuous**. Logging stops when the alarm ends.

1. In the **Setup** dialog for Data Log 3, select **Status** and click **Edit**. The **Select Status** dialog appears.

2. Select **Auto-Enable** in the dropdown list and click **OK**.



3. Click **Send** to save the changes and send the configuration to the meter.

You can also use Vista to set a Data Log to Auto-Enable. See ["Configuring Auto-Enable data logs for CM4000 and PM800 series" on page 268](#).

Configuring Auto-Enable data logs for CM4000 and PM800 series

This section explains how to use Vista to configure the data logs for PM800 Series Meters and the CM4000 Series Meters for auto-enable.

Auto-Enable is a special mode that allows logging to be triggered when an alarm occurs. Data is recorded in the data log at a defined interval if the logging mode is set to **Continuous**. Logging stops when the alarm ends. The following instructions assume that you associated Data Log 2 with the digital input alarm **Run ON** for the purpose of logging the analog inputs and load profile data.

For information about using ION Setup to set a Data Log to Auto-Enable, see:


- For PM800 series meters, see ["Set the Status of Data Log 2 to Auto-Enable" on page 250](#).
- For CM4000 series meters, see ["Set the Status of Data Log 3 to Auto-Enable" on page 267](#).

Use Vista to set a data log to Auto-Enable


Complete the following steps to use Vista to set the status of Data Log 2 to Auto-Enable.

1. Open Vista and select **File > New** to open an empty workspace.
2. Ensure that the Toolbox is open. If not, select **Options > Show Toolbox**.
3. In the Toolbox, select a **Control Object** and drag it to the workspace.
4. Right-click the control object. The **Control Object Configuration** screen appears.

- Click the **Link** tab. In the **Link** area, select **Custom**, and then click **Edit Link**. The **Create Link** screen appears.
- In the **Nodes** list, double-click the meter name. The associated module directories appear in the **Managers** list.



- In the **Managers** list, double-click **Resets and Triggers**.
- In the **Modules** list, double-click **Log Auto-Enables**.
- In the **Output Registers** list, select **Data Log 2 Auto-Enable**.
- Click **OK** to save the selection and to close the screen.
- Double-click the control object in the workspace to set Data Log 2 on the meter to Auto-Enable.




Verify that Data Log 2 has been set to Auto-Enable

You can verify that Data Log 2 has been set to Auto-Enable by adding a numeric object to the workspace and linking it to a setup register for the Data Log.

- In Vista, ensure that the Toolbox is open. If not, select **Options > Show Toolbox**.
- In the Toolbox, select a **Numeric Object** and drag it to the workspace.
- Right-click the numeric object. The **Numeric Object Configuration** screen appears.
- Click the **Link** tab. In the **Link** area, select **Custom** and press the **Ctrl** key while clicking **Edit Link**. The **Create Link** screen for Setup Registers.

- In the **Nodes** list, double-click the meter name. The associated module directories appears in the **Managers** list.



- In the **Managers** list, double-click **Data Recorders**.
- In the **Modules** list, double-click **Data Log 2**.
- In the **Setup Registers** list, select **RE2 Enabled**.
- Click **OK** to save the selection and to close the screen.

When the numeric object displays "Auto," you have confirmation that Data Log 2 has been set successfully to Auto-Enable by the control object.



Configuring SER-2408/SER-3200

The SER-2408/SER-3200 Sequence of Event Recorders can be used with the software to record status changes of the ATs and generator contacts in the onboard data logs.

NOTE: SER3200 are recommended for Power Monitoring Expert 8.2 – Data Center Edition.

The process to set up the SER-2408/SER-3200 with Power Monitoring Expert 8.2 – Healthcare Edition includes these steps:

- Install hardware and configure device communications and digital inputs.

The SER-2408/SER-3200 can be configured using the integral webserver of the device. Enter the IP address of the device in the browser to open the setup page. Refer to *SER-3200/SER-2408 Instruction Bulletin: User's Guide* for instructions.

Perform the following steps from the *SER-3200/SER-2408 Instruction Bulletin: User's Guide* before proceeding:

- In your browser, enter your device IP address and press **Enter**. Log in using your Login ID and password.
- Click **SETUP**, and then click **Time**. Set the time/clock correctly for your location.

CyTime Event Recorder | MONITORING | CONTROL | DIAGNOSTICS | **SETUP**

Communications

Time

Inputs

Inputs (Group)

Outputs

Groups

Administration

Date and Time: 04/27/2015 11:23:52 (UTC-08:00)

Time Source: NTP

Time Sync Master: ☐

Time Zone Offset: UTC-08:00

Hourly Time Update: ☒

NTP Polling Interval: 1 hour

Primary NTP Server: 131.107.13.100

Secondary NTP Server: 165.193.126.229

Last Successful NTP Sync: 04/27/2015 10:38:47 (UTC-08:00) 131.107.13.100

Manual Time Set: 2000 1 1 0 0 0
Year Month Day Hour Minute Second

Copy PC Clock

Cancel Defaults Apply

© Copyright 2009-2013, Cyber Sciences, Inc. All rights reserved.

- Click **SETUP**, and then click **Inputs**. Configure all necessary inputs and select the **Enabled** check box next to each input. When finished, click **Apply**.

CyTime Event Recorder | MONITORING | CONTROL | DIAGNOSTICS | **SETUP**

Communications

Time

Inputs

Inputs (Group)

Outputs

Groups

Administration

Enabled	Input Name	Filter	Debounce	Chatter	Off Text	On Text	Trigger	Inverted
☒	01 EPSS_E_TEST	3000	3000	0	Off	On	☐	☐
☒	02 EPSS_E_EMERGENCY	3000	3000	0	Off	On	☐	☐
☒	03 EPSS_E_NORMAL	3000	3000	0	Off	On	☐	☐
☒	04 EPSS_E_GEN_RUN	3000	3000	0	Off	On	☐	☐
☒	05 Input 05	3000	3000	0	Off	On	☐	☐
☒	06 Input 06	3000	3000	0	Off	On	☐	☐
☒	07 Input 07	3000	20	0	Off	On	☐	☐
☒	08 Input 08	3000	3000	0	Off	On	☐	☐
☐	09 Input 09	20	20	0	Off	On	☐	☐
☐	10 Input 10	20	20	0	Off	On	☐	☐
☐	11 Input 11	20	20	0	Off	On	☐	☐
☐	12 Input 12	20	20	0	Off	On	☐	☐
☐	13 Input 13	20	20	0	Off	On	☐	☐
☐	14 Input 14	20	20	0	Off	On	☐	☐
☐	15 Input 15	20	20	0	Off	On	☐	☐
☐	16 Input 16	20	20	0	Off	On	☐	☐

▲ [1 to 16] ▼ [17 to 24]

Cancel Defaults Apply

© Copyright 2009-2013, Cyber Sciences, Inc. All rights reserved.

- Click **SETUP**, and then click **Groups**. Assign a group to each input. When finished, click **Apply**.

CyTime Event Recorder

MONITORINGCONTROLDIAGNOSTICSETUP

Communications

Time

Inputs

Inputs (Group)

Outputs

Groups

Administration

#	Input Name	Data Log Group
01	EPSS_E_TEST	Group 01
02	EPSS_E_EMERGENCY	Group 01
03	EPSS_E_NORMAL	Group 01
04	EPSS_E_GEN_RUN	Group 01
05	Input 05	None
06	Input 06	Group 01
07	Input 07	Group 02
08	Input 08	Group 03
09	Input 09	Group 04
10	Input 10	Group 05
11	Input 11	Group 06
12	Input 12	Group 07
13	Input 13	Group 08
14	Input 14	None
15	Input 15	None
16	Input 16	None

▲ 1 to 16 ▼ 17 to 24

CancelDefaultsApply

© Copyright 2009-2013, Cyber Sciences, Inc. All rights reserved.

6. Make sure that you enable logging for all above groups.
- If you do not enable the logs in the groups section when configuring the device, the inputs will not be available and will not appear in the Generator Performance Configuration tool.
- For more information on configuring the communications and digital inputs for this device, see the *SER-3200/SER-2408 Instruction Bulletin: User's Guide*.
7. Add the device in Management Console.
8. Open Vista to verify communications.
9. Use the Generator Performance Configuration Tool to assign measurements for generators or ATS equipment.

After you complete the above steps, you can generate the EPSS or Generator Test Report for data recorded by the SER-2408/SER-3200.

⚠ WARNING

UNINTENDED OPERATION

- Do not use the SER-2408/SER-3200 with either Power Monitoring Expert or ION Setup for critical control or protection applications where human or equipment safety relies on the operation of the control circuit.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Refer to your power meter's technical documentation for more information on its operation.

Adding the SER-2408/SER-3200 to Management Console

In Management Console, add the SER-2408/SER-3200 as an Ethernet device.

NOTE: For proper operation, the device must have the **Unit ID** value set to 1.

Follow these steps to set the device **Unit ID**:

- 1. As you enter the device details in the Ethernet Device Configuration screen, right-click the screen and click **Advanced**.

Ethernet Device Configuration

Items in red are mandatory


Group	Healthcare
Name	SER2408
Device Type	SER 2408
TCP/IP Address	
Computer	STANDALONE
Enabled	Yes
Description	

Advanced Properties

Reset All to Default

The Advanced Properties for the device appear.

2. In the Unit ID field, enter 1.




The dialog box titled "Ethernet Device Configuration" contains a table with the following fields and values:

Group	Healthcare
Name	SER2408
Device Type	SER 2408
TCP/IP Address	
TCP/IP Port	502
Computer	STANDALONE
Enabled	Yes
Description	
Receive Timeout	10000
Maximum Attempts Multiple	3
Attempt Increment	3
Online Event Priority	10
Offline Event Priority	128
Offline Attempt Number	1
Offline Timeout Period	30000
Unit ID	1
Transmit Delay	0

The "Unit ID" field is highlighted with a red rectangle. Below the table, there is a text box with the label "Unit ID" and the description "Unit ID of the Ethernet device." At the bottom right are "OK" and "Cancel" buttons.

3. Click **OK**.
4. Verify the device status is "Device Connected" as shown next.



The screenshot shows the "Management Console - supervisor - Power Monitoring Expert for Healthcare" window. On the left is a sidebar with icons for Servers, Sites, and Devices. The main area displays a table with the following data:



Enabled	Group	Name	Type	Address	Site	Status	Protocol	Description
✓	Healthcare	SER2408	SER 2408	10.168.XX.XXX/502/1	<Ethernet/STANDALONE>	Device Connected	MODBUS	

A "Column Selector" pane is visible on the right side of the table.

Verify Device Communications in Vista

After you add the device to Management Console, you can open Vista to view the device's counter, input/output status, and data logs.

The following examples show the device diagram and recorded data details.



Assign Measurements for Generators or ATS Equipment

After device data is logged into the database, you can assign device measurements using the Generator Performance Configuration Tool or Generator Performance Configuration Tool with EPSS Test Module.

Add the device and select the measurements for the generator or ATS as explained in these sections:

- ["Define generators" on page 73](#)
- ["Define EPSS generators" on page 38](#)
- ["Define EPSS transfer switches" on page 47](#)

The required status measurements for the SER-2408/SER-3200 are "Digital Input Status X" where X = input of the SER-2408/SER-3200. On the **Generators** tab, the selected source and measurement are similar to the following example.

The screenshot displays a configuration window for 'Status Measurements'. A red box highlights the 'Source' dropdown menu, which is set to 'SER.2408'. Below this, there are three sections: 'Starting:', 'Running:', and 'Stopped:'. Each section has a dropdown menu for selecting a measurement and an 'Active Value' input field. The 'Starting:' section shows 'No Measurement selected.' and a value of '1'. The 'Running:' section shows 'Digital Input 1 Status' and a value of '1'. The 'Stopped:' section shows 'Digital Input 2 Status' and a value of '1'. All dropdown menus have a green checkmark icon.

Interpreting the Energy Regression Analysis Report results

The Energy Regression Analysis Tool is a highly configurable tool that allows you to monitor and manage a building or facility's energy and resource consumption. This practice, called energy modeling, involves analyzing building energy systems, monitoring energy consumption, and detecting anomalies or changes in system behavior that may require that you perform energy efficiency upgrades or fixes. The Energy Regression Analysis Report allows you to model energy data one independent variable at a time with a wide range of desired independent variables, such as weather or occupancy rate.

It is recommended that users have a basic understanding of energy modeling and understand how to create an Energy Regression Analysis Report. This section discusses in detail the purpose of each parameter in the report and how to read and interpret meaningful results of an Energy Regression Analysis Report. After generating the report, conclusions can be drawn from the generated tables and charts to monitor energy consumption and make cost saving decisions.

Energy Regression Analysis Report results provide a characterization of a building's performance. You can perform different types of energy analysis with this information, including the following:

- Energy Benchmarking
- Energy Budgeting
- Energy Savings

Glossary of terms

Term	Definition
Cooling Degree Days (CDD)	Measurement designed to reflect the demand for energy needed to cool a building.
Cost Savings Analysis	Comparing energy profiles against expected profiles and identifying outlying data that may signify areas of improvement.
Degree Day	One degree of departure, on a single day, of the daily mean temperature from a given standard temperature.
Energy Benchmarking	Comparing the energy performance of similar buildings, or comparing the energy performance of a single building over time.

Energy Budgeting	Determining future energy use and associated costs for different times of the year.
Energy Modeling	Computerized simulation of a building that focuses on energy consumption, utility bills and life cycle costs of various energy related items such as air conditioning, lights and hot water.
Energy Savings	Measuring savings by comparing performance profiles before and after energy efficiency modifications.
Energy Use Breakdowns	Disaggregating building energy into different categories, such as weather-dependent energy use or weather-independent energy use.
Heating Degree Days (HDD)	Measurement designed to reflect the demand for energy needed to heat a building.
Performance (Regression) Line	The statistical line of best fit.
Regression Analysis	Statistical process for estimating the relationships among variables. Includes many techniques for modeling and analyzing several variables, when the focus is on the relationship between a dependent variable and one or more independent variables.

Reading the report

This section discusses how to read the different types of information in the report.

For information on how to configure and use this report, see ["Configure and generate the Energy Regression Analysis Report" on page 27](#).

Report Parameters Summary table

The Report Parameters Summary table appears at the beginning of the report. Based on what you select for the **Show Report Parameters Summary** option on the prerequisite page, you can make this table appear or be hidden in the report.

Report Parameters Summary			
Driver Data Source	WeatherStation.VancouverBC	Driver Data Quantity	Weather Temperature (°C)
Model Data Source	GasIncomer.GasMeter	Model Data Quantity	Natural Gas Volume (m ³)
X Axis Calculation Method	Average	Degree Days Pivot Point	18
Y Axis Calculation Method	Delta		
Regression Type	Broken Line	Aggregation Period	Week
Deviation Type	Absolute Value	Max Authorized Deviation	330


This table provides important details, such as data sources, calculation methods, and other parameters about how the report inputs are configured that can help the user understand report results.

Regression Analysis Chart

The Regression Analysis Chart shows the relationship between the driver and model data.

In this chart, the blue dots represent real data points. In this case, the data is aggregated weekly over the course of one year, therefore, there are 52 data points with each data point representing one week of the year. The yellow line is the regression line, or performance line, of the building. The performance (regression) line is the best fit line—a line that indicates the expected energy

consumption. The slope of the performance line is a measure of how much extra fuel, energy, or other resource is consumed for an increase in the independent variable (such as degree days, production units, and so forth).



Deviations between building performance lines over time means that something has changed in the way the facility consumes energy. This may be a result of energy efficiency modifications, or it could indicate an issue with building systems, equipment, or processes. The performance line provides a benchmark by which changes in energy consumption can be monitored, and appropriate actions can be taken if variations are detected.

The point of intersection between the two performance lines is called the breakpoint. For energy consumption analyzed with respect to average temperature, the breakpoint indicates the temperature at which heating or cooling of a facility begins. Therefore, having a breakpoint further to the right is better because this indicates that heating or cooling systems are running for less time, which results in less energy usage.

Regression Analysis Main Characteristics Table

The Regression Analysis Main Characteristics Table provides information about the Regression Analysis Chart.

Regression Analysis Main Characteristics Tables

Side	Slope	Y-Intercept	R ²	RMSE
Left	-300.67	5257.20	-0.971	290.14
Right	-32.52	1581.66	-0.822	43.92

	X Value	Y Value
Changepoint	13.71	1135.97

The **Side** column shows the left and right sides. The **Slope** column shows the slope values of the two best-fitting lines intersect. This intersection point is called the *breakpoint*. The **Y-Intercept** column shows a point where the graph of a function or relation intersects with the y-axis of the coordinate system. Therefore, these points satisfy $x = 0$.


The **R2** column shows a value that indicates how well the data fits the model. The **RMSE** column shows the square root of the mean/average of the square of all of the error. The **X Value** and **Y Value** columns show the coordinates of the Change point.

Monitoring the slopes and breakpoint values provides useful information about a facility’s energy consumption. Flatter slope lines are better as they indicate a smaller increase in energy consumption for every additional unit of the independent X-axis variable.

For more information on interpreting the report results, see ["Interpreting the report" on page 281](#).

Measured Values Against Expected Values Chart

The Measured Values Against Expected Values Chart shows the relationship between the model data and time.



In this chart, the blue line indicates the real energy usage over time and the performance line indicates the expected energy usage over time based on the regression analysis.

The time axis, or X-axis, has different units depending on the selected aggregation period. For weekly aggregation, the numbers on the X-axis represent the weeks of the year and for daily aggregation, they represent the days of the year. The year or years contained within the reporting period are displayed on the chart directly below the X-axis values.

Exceptions Table

The Exceptions Table below shows information for any data point that falls outside of the exception range defined by the Deviation Type and Max Authorized Deviation parameters.

Exceptions Table

Device Name	Aggregation Period (Week)	X-Axis Value (Average)	Y-Axis Value (m ³)	Regression Value (m ³)	Delta Value (m ³)	Delta Value Percent (%)
GasIncomer.GasMeter	2014-49	1.94	5116.00	4674.06	441.94	9.46 %
GasIncomer.GasMeter	2014-46	2.71	4974.30	4442.87	531.43	11.96 %
GasIncomer.GasMeter	2014-52	5.02	4281.00	3749.08	531.92	14.19 %
GasIncomer.GasMeter	2014-07	5.26	3344.70	3676.72	-332.02	-9.03 %
GasIncomer.GasMeter	2014-48	5.62	3904.60	3567.70	336.90	9.44 %
GasIncomer.GasMeter	2014-51	6.26	3907.00	3374.41	532.59	15.78 %
GasIncomer.GasMeter	2014-50	8.92	2925.00	2574.40	350.60	13.62 %

If there are no exception points, this table does not appear in the report.

Full Table

The Full Table below shows information for all data points.

Full Table

Device Name	Aggregation Period (Week)	X-Axis Value (Average)	Y-Axis Value (m ³)	Regression Value (m ³)	Delta Value (m ³)	Delta Value Percent (%)
GasIncomer.GasMeter	2014-06	-1.95	5859.70	5844.23	15.47	0.26 %
GasIncomer.GasMeter	2014-49	1.94	5116.00	4674.06	441.94	9.46 %
GasIncomer.GasMeter	2014-09	2.43	4309.50	4525.20	-215.70	-4.77 %
GasIncomer.GasMeter	2014-46	2.71	4974.30	4442.87	531.43	11.96 %
GasIncomer.GasMeter	2014-04	3.65	3900.87	4158.31	-257.44	-6.19 %
GasIncomer.GasMeter	2014-05	3.79	3839.60	4118.93	-279.33	-6.78 %
GasIncomer.GasMeter	2014-08	4.35	3681.70	3948.91	-267.21	-6.77 %
GasIncomer.GasMeter	2014-02	4.77	3501.95	3823.01	-321.06	-8.40 %
GasIncomer.GasMeter	2014-52	5.02	4281.00	3749.08	531.92	14.19 %
GasIncomer.GasMeter	2014-07	5.26	3344.70	3676.72	-332.02	-9.03 %
GasIncomer.GasMeter	2014-47	5.45	3922.70	3618.82	303.88	8.40 %
GasIncomer.GasMeter	2014-03	5.48	3376.11	3608.86	-232.75	-6.45 %
GasIncomer.GasMeter	2014-48	5.62	3904.60	3567.70	336.90	9.44 %
GasIncomer.GasMeter	2014-12	5.75	3391.40	3527.70	-136.30	-3.86 %
GasIncomer.GasMeter	2014-51	6.26	3907.00	3374.41	532.59	15.78 %
GasIncomer.GasMeter	2014-10	6.76	2959.10	3223.53	-264.43	-8.20 %
GasIncomer.GasMeter	2014-11	7.79	2679.40	2914.45	-235.05	-8.06 %
GasIncomer.GasMeter	2014-13	8.34	2528.80	2749.79	-220.99	-8.04 %
GasIncomer.GasMeter	2014-14	8.43	2526.00	2723.49	-197.49	-7.25 %
GasIncomer.GasMeter	2014-50	8.92	2925.00	2574.40	350.60	13.62 %
GasIncomer.GasMeter	2014-17	9.57	2085.60	2381.11	-295.51	-12.41 %

Within the Full Table, there is a row with missing values.

Warp.GeneratorOne	2009-8	12.63	73.74	51.70	-22.04	-42.64 %
Warp.GeneratorOne	-	15.14		62.07		
Warp.GeneratorOne	2009-7	16.83	150.60	122.89	-27.71	-22.55 %

This row stores information about the breakpoint from the Regression Analysis Chart.

This report generates with almost any set of data and regardless of other parameter selections. However, the generated report is only of assistance in monitoring energy consumption if the parameters are configured correctly and with specific intent.

The following section provides specific examples of how to use the Energy Modeling Report to monitor certain aspects of a facility's energy consumption.


Interpreting the report

After generating the report, the data can be analyzed in different ways to draw different conclusions about energy and resource consumption. Below are two examples involving different independent variables.

Example 1: Justifying Energy Efficiency Upgrades

Regression analysis of energy or resource consumption with respect to Degree Days can provide valuable information about a facility's energy efficiency with respect to outside changes in temperature. Such information can be used to determine when energy efficiency upgrades are necessary, and to monitor the effectiveness of such solutions after implementation.

For example, a facility manager could compare the Heating Degree Day energy profile of their building to another facility in a similar climate. If the other building proves to be much more energy efficient, an analysis could be performed on the differences in building design that could cause these results. Perhaps the only significant difference is that the more efficient building recently upgraded their insulation. The less efficient building could then use this information, along with the Regression Analysis charts to pitch the case that an insulation upgrade should take place to reduce natural gas usage at the facility.




If the upgrade is successful, a change appears in the Regression Analysis chart the following year. The chart above shows a possible Regression analysis for the year before the energy efficiency modifications. The red line in the chart shows how the performance lines and breakpoint could change when the upgrades are successful. The slopes of the lines in the second figure are flatter, indicating less energy usage for every additional degree day. The breakpoint also occurs later, indicating that heating does not have to begin at as low of a temperature as before, thereby saving additional resources.

Example 2: Identifying Equipment Failure

Regression analysis can also be used to detect equipment deterioration or failure. Below are two Regression Analysis charts showing natural gas consumption with respect to production units.

The red line in the chart has a steeper slope and an earlier X-axis intersection point. This indicates that more natural gas is being used for every unit of production. If data for these charts is collected over different periods of time, but with no changes to manufacturing processes or equipment, the steeper regression line in the second chart could indicate deterioration of equipment.



Plotting energy consumption data against any independent variable, not just time, allows you to analyze in greater detail the energy efficiency of your buildings or facilities, and to make necessary upgrades or cost analysis decisions.

Conclusion

Energy modeling is a relatively new practice for monitoring and analyzing energy consumption in buildings and facilities. It involves using computerized simulations to analyze energy consumption, and it allows customers to understand their expected energy consumption and use this information to make system design decisions and perform cost benefit analysis.

The Energy Modeling Report, or XY Regression Report, allows users to create energy profiles for their buildings or facilities. These benchmark energy models provide valuable information about energy and resource consumption that can help facility managers identify and address consumption issues in order to save resources.

Recommendations

Many of the report parameters on the prerequisite page are interdependent and configuring this page requires close attention. It is recommended to rely on documentation to correctly configure the report. Note that there is no filtering of parameters on the prerequisite page.

Generator system redundancy types

You can create a generator system to achieve power redundancy for IT equipment loads in different ways, depending on how the generators are grouped together and how they are connected to the equipment power supplies. This configuration tool supports several industry standard configurations.


The generator system supports the following redundancy design types:

- ["N Type" on page 283](#)
- ["N+1 Type" on page 283](#)
- ["N+2 Type" on page 284](#)
- ["2N Type" on page 284](#)
- ["2\(N+1\) Type" on page 285](#)
- ["2\(N+2\) Type" on page 286](#)

Before generator-related reports can be produced you need to define a generator system in the Generator Power Configuration Utility.

N Type


The N system configuration is for one or more generators that work together to supply power to the IT load, when the utility or utilities' power is unavailable. There is no redundancy. The intention is to size the generator system to match the peak IT load on the utility power.



N+1 Type

The N+1 system configuration is for one or more generators that work together to supply power to the IT load. There is simple generator redundancy in that one of the generators can stop functioning or be taken off-line, in the event that the utility power is interrupted. The load is spread among all generators, but the peak load is such that if one generator stops working, the others will be able to assume its load. Another way to look at it is, N generators will be able to support the peak IT load. If the peak IT load is more than N can support, then system design redundancy will be lost.


For example, if three generators are connected to the IT loads, in an N+1 system, the peak utility load must not exceed the non-redundant capacity of two of the generators. If it does, the designed redundancy will be lost.



N+2 Type

The N+2 system configuration is for a group of generators that work together to supply power to a medium voltage substation and is then distributed to low voltage loads. There is simple generator redundancy in that any two of the generators can stop functioning or be taken off-line, in the event that the utility power is interrupted. The load is spread among all generators, but the utility peak load is such that if two generators stop working, the others will be able to assume their load. Another way to look at it is, N generators will be able to support the peak utility load. If the peak utility load is more than N can support, then system design redundancy will be lost.


For example, if five generators are connected to the IT loads, in an N+2 system, the peak utility load must not exceed the non-redundant capacity of three of the generators. If it does, the designed redundancy will be lost.



2N Type

The 2N system configuration is for two groups of generators that supply power to the IT loads. In a 2N system, an entire group of generators can stop functioning or be taken off-line and the equipment will still be supplied with power, in the event that the utility power is interrupted. The load is spread among all generators, but the peak load is such that, if an entire group of generators stop working, the remaining generators will be able to assume the entire load. Another way to look at it is, N generators will be able to support the peak utility load. If the peak utility load is more than N can support, then system design redundancy will be lost.


In this example, there are two groups with three generators in each. In a 2N configuration, one group of generators can go offline and the system will still have the designed redundancy. Therefore, the value for N is three. So, the total peak utility load cannot exceed the derated nameplate of three of the generators.



2(N+1) Type

The 2(N+1) system configuration is for two groups of generators that supply power to the IT loads. In an 2(N+1) system, an entire group of generators plus one more generator from each of the remaining groups can stop functioning or be taken off-line, and the equipment will still be supplied with power, in the event that the utility power is interrupted. The load is spread among all generators, but the peak load is such that if an entire group's worth of generators goes offline, plus one more from each of the other groups stop working, the remaining generators will be able to assume the entire load. Another way to look at it is, N generators will be able to support the peak utility load. If the peak utility load is more than N can support, then system design redundancy will be lost.


In this example, there are two groups with five generators in each. In a 2(N+1) configuration, one group of generators can go offline, plus one more generator from the remaining group and the system will still have the designed redundancy. Therefore, the value for N is four. So, the total peak utility load cannot exceed the derated nameplate of four of the generators.



2(N+2) Type

The 2(N+2) system configuration is for two groups of generators that supply power to the IT loads. In an 2(N+2) system, an entire group of generators plus two more generators from each of the remaining groups can stop functioning or be taken off-line and the equipment will still be supplied with power, in the event that the utility power is interrupted. The load is spread among all generators, but the peak load is such that if an entire group's worth of generators goes offline, plus two more from each of the other groups goes offline, the remaining generators will be able to assume the entire load. Another way to look at it is, N generators will be able to support the peak utility load. If the peak utility load is more than N can support, then system design redundancy will be lost.

In this example, there are two groups with four generators in each. In a 2(N+2) configuration one group of generators can stop working, plus two more generators from the remaining group and the system will still have the designed redundancy. Therefore, the value for N is two. So, the total peak utility load cannot exceed the derated nameplate of two of the generators.



UPS system redundancy types

You can create a UPS system to achieve power redundancy for IT equipment loads in different ways, depending on how the UPS units are grouped together and how they are connected to the equipment power supplies. This configuration tool supports several industry standard configurations.


The UPS system supports the following redundancy design types:

- ["N Type" on page 287](#)
- ["N+1 Type" on page 287](#)
- ["N+2 Type" on page 288](#)
- ["2N Type" on page 288](#)
- ["UPS system redundancy types" on page 286](#)
- ["UPS system redundancy types" on page 286](#)

N Type

The N system configuration is for one or more UPS modules which work together to supply power to the IT load. There is no redundancy, except optionally to the second power supply of each piece of equipment.

Each UPS system with an N configuration can have multiple UPS groups, where each group is connected to a different load. The number of modules within each UPS group can be different. Within each group, all UPS modules must have the same derated nameplate rating value (kW).




N+1 Type

The N+1 system configuration is for one or more UPS modules that work together to supply power to the IT load. There is simple module redundancy in that one of the modules can be rendered inoperative or be taken off-line. The load is spread among all remaining UPS modules, but the peak load is such that if one module stops working, the others will be able to assume its load. Another way to look at it is, N UPS modules will be able to support the peak IT load. If the peak IT load is more than N can support, then system design redundancy will be lost.

There is the option to connect the system of modules to the second power supply of each piece of equipment, but both power supplies are connected to the group of UPS modules.

Each UPS system with an N+1 configuration can have multiple UPS groups, where each group is connected to a different load. The number of modules within each UPS group can be different. The modules within a UPS group must have the same derated nameplate rating value (kW).




N+2 Type

The N+2 system configuration is for a group of UPS modules that work together to supply power to the IT load. There is simple module redundancy in that any two of the modules can be rendered inoperative or be taken off-line. The load is spread among all remaining UPS modules, but the peak load is such that if two modules stop working, the others will be able to assume their load. Another way to look at it is, N UPS modules will be able to support the peak IT load. If the peak IT load is more than N can support, then system design redundancy will be lost. An example of an N+2 system is five UPS modules connected to the IT load, but the peak IT load never exceeds the capacity of three of the UPS modules.

There is the option to connect the system of modules to the second power supply of each piece of equipment, but both power supplies are connected to the group of UPS modules.

Each UPS system with an N+2 configuration can have multiple UPS groups, where each group is connected to a different load. The number of modules within each UPS group can be different. The modules within a UPS group must have the same derated nameplate rating value (kW).




2N Type


The 2N system configuration is for two or three groups of UPS modules that supply power to two different power supplies in each IT load. For redundancy, an entire UPS group can stop working or be taken off-line, and the IT equipment will still be supplied with power. It also means that either one of the two power supplies in an IT load can be rendered inoperative. The load is spread among all UPS modules, but the peak load is such that if an entire group's worth of modules are not working, the remaining modules will be able to assume their load. Another way to look at it is, N UPS modules will be able to support the peak IT load. If the peak IT load is more than N can support, then system design redundancy will be lost.

Each UPS system with a 2N configuration can have two or three UPS groups. If there are two groups, both of them must be connected to the same load. If there are three groups, then there are three separate loads and each group is connected to two of the loads. The number of modules within each UPS group in a UPS system must be the same in a 2N configuration. Additionally, all UPS modules within a UPS group must have the same derated nameplate rating value (kW).

In the first example, there are two groups with four UPS modules each. In a 2N configuration, one group can stop working and the system will still have the designed redundancy. Therefore, the value for N is four. So, the total IT load cannot exceed the derated nameplate rating of four of the UPS modules.



In the second example, there are three groups with four UPS modules each. In a 2N configuration, one group's worth of UPS modules can be rendered inoperative and the system will still have the designed redundancy. Therefore, the value for N is eight. So, the total IT load (for all three IT load groups shown below) cannot exceed the derated nameplate rating of eight of the UPS modules.




2(N+1) Type

The 2(N+1) system configuration is for two or three groups of UPS modules that supply power to two different power supplies in each IT load. The redundancy provided means that an entire group of UPS modules, plus one more module from the remaining groups, can stop working or be taken off-


line, and the IT equipment will still be supplied with power. It also means that either one of the two power supplies in an IT load can be rendered inoperative. The load is spread among all UPS modules, but the peak load is such that if an entire group's worth of modules be rendered inoperative, plus one more from each other group, the remaining modules will be able to assume their load. Another way to look at it is, N UPS modules will be able to support the peak IT load. If the peak IT load is more than N can support, then system design redundancy will be lost.

Each UPS system with a $2(N+1)$ configuration can have two or three UPS groups. If there are two groups, both of them must be connected to the same load. If there are three groups, then there are three separate loads and each group is connected to two of the loads. The number of modules within each UPS group in a UPS system must be the same in a $2(N+1)$ configuration. Additionally, all UPS modules within a UPS group must have the same derated nameplate rating value (kW).

In the first example, there are two groups with four UPS modules in each group. One group plus one UPS module from the other group can be rendered inoperative, and the system will still have the designed redundancy. Therefore, the value for N is three. So, the total IT load cannot exceed the derated nameplate rating of three of the UPS modules.



In the second example, there are three groups with four UPS modules in each group. One group plus one module from each of the other two groups can stop working and the system will still have the designed redundancy. Therefore, the value for N is six. So, the total IT load (for all three IT load groups shown below) cannot exceed the derated nameplate rating of six of the UPS modules.




2(N+2) Type


The 2(N+2) system configuration is for two or three groups of UPS modules that supply power to two different power supplies in each IT load. The redundancy provided means that an entire group of UPS modules, plus two more modules from the remaining groups, can stop working or be taken off-line and the IT equipment will still be supplied with power. It also means that either one of the two power supplies in an IT load can stop working. The load is spread among all UPS modules, but the peak load is such that, if an entire group stops working, plus two more from the other group, the remaining modules will be able to assume their load. Another way to look at it is, N UPS modules will be able to support the peak IT load. If the peak IT load is more than N can support, then system design redundancy will be lost.

Each UPS system with a 2(N+2) configuration can have two or three UPS groups. If there are two groups, both of them must be connected to the same IT load. If there are three groups, then there are three separate loads and each group is connected to two of the loads. The number of modules within each UPS group must be the same. All UPS modules within a group must have the same derated nameplate rating value (kW).

In the first example, there are two groups with four UPS modules each. One group can be rendered inoperative, plus two more UPS modules from the other group and the system will still have the designed redundancy. Therefore, the value for N is two. The total IT load cannot exceed the derated nameplate rating of two of the UPS modules.



In the second example, there are three groups with four UPS modules each. One group plus two modules from each of the other two groups can stop working, and the system will still have the designed redundancy. Therefore, the value for N is four. So, the total IT load cannot exceed the derated nameplate rating of four of the UPS modules.



UPS Battery Health Report calculations

The following terms and explanations of various calculations are used in the **UPS Battery Health Report**:

First Drop Analysis – Minimum Drop Voltage (V), Maximum Drop Voltage (V) and

Difference (%): The voltage drop minimum, maximum and percentage difference values are shown in the Drop Analysis table section. To calculate these values, a valid waveform voltage drop must be found first by sampling the waveform data.

A valid voltage drop is defined as the first waveform section of size n, where the relative minimum and maximum voltage values have a percentage difference d. In addition, the next sample n+1 must be greater in value than the minimum voltage, to ensure that the lowest value has been found in the voltage drop.

The sampling section size n and the percentage difference d are determined by the user-defined report parameters Waveform Drop Sample Size and Waveform Drop Percentage, respectively.

After the voltage drop has been found, the Minimum Voltage and Maximum Voltage are simply the min and max values in that drop samples, and the Difference is the percentage of the maximum voltage over the minimum voltage. For example:

$$\text{Minimum Drop Voltage} = \text{Min}(ws1 \leq \text{WaveformValues} \leq wsN)$$

$$\text{Maximum Drop Voltage} = \text{Max}(ws1 \leq \text{WaveformValues} \leq wsN)$$

ws1 is the first point in the sample and wsN is the last point in the sample

$$\text{Difference (\%)} = [(\text{Maximum Drop Voltage} - \text{Minimum Drop Voltage}) / \text{Maximum Drop Voltage}]$$

Recovery Analysis – Target Recovery Voltage (V), Actual Recovery Voltage (V) and Recovery Time (ms):

Target Recovery Voltage (V): This value is calculated for the reference waveform only. This is calculated as follows:

$$\text{Target Recovery Voltage (V)} = [\text{Recovery Voltage} * \text{Recovery Value Multiplier}]$$

$$\text{Where Recovery Voltage} = \text{Average}(w1 \leq \text{WaveformValues} < wN)$$

w1 is the very first point in the waveform and wN is the lowest point in the waveform voltage drop and Recovery Value Multiplier is a user-defined value in the report pre-requisite page

Actual Recovery Voltage (V): The first point in the reference and comparison waveforms that occurs after the voltage drop, that is equal or greater than the Target Recovery Voltage value.

Recovery Time (ms): This is the time elapsed from the Minimum Voltage Drop time and the Actual Recovery Voltage time, expressed in milliseconds.

Additional calculations

Voltage Threshold: This is the red horizontal area that is highlighted in the waveform drop chart. It represents a nominal voltage value, therefore there are no calculations for the Voltage Threshold.

For example, if the user sets the Voltage Threshold to 50V, then a red line will be drawn at 50v (based on the Y-axis) and the area below the red line appears shaded in red.

Power Factor Rate File Calculation

This appendix explains the power factor calculations in the default rate files. To learn how to modify the rate files, please refer to the [PME Billing Module Toolkit](#).

Power Factor Impact – Active Energy Billing with PF Adjustment Option 1

The utility charges according to the active energy and adds a surcharge or adjustment for power factor.

$$PF_{cost} = (kWh_{billable} - kWh) \times Rate_{kWh}$$

$$kWh_{billable} = kWh \times \left(\frac{PF_{target}}{PF} \right) (C1)$$

Power Factor Impact – Active Energy Billing with PF Adjustment Option 2

The utility charges according to the active energy and adds a surcharge or adjustment for power factor.

$$PF_{cost} = (kWh_{billable} - kWh) \times Rate_{kWh}$$

$$kWh_{billable} = kWh \times (1 + PF_{target} - PF)$$

Power Factor Impact – Apparent Energy Billing.xml

The utility bills all consumed energy, including the reactive energy.

$$PF_{cost} = kVAh \times \left(1 - \frac{PF}{PF_{target}} \right) \times Rate_{kVAh}$$

Power Factor Impact – Reactive Energy Billing.xml

$$PF_{cost} = (kVARh - kWh \times \frac{\sqrt{1 - PF_{target}^2}}{PF_{target}}) \times Rate_{kVARh}$$

PQ Advisor - Supported meters

The meter support list provides detailed information of Power Quality Advisor feature dependencies on meters. Use it for both greenfield and brownfield designs.

PQ Events and Disturbances	Used by	Supported Meters	Supported Meter Template
Interruptions	PQ Advisor Diagrams PQ Rating Gadget PQ Rating Trend Gadget PQ Events Breakdown Gadget PQ Events Impact Gadget PQ Events Location Gadget PQ Impact Gadget PQ Impact Trend Gadget PQ Impact Report	ION 7350, 7400, 7550, 7650, 8600A, 8600B, 8650A, 8650B, 8650C, 8800A, 8800B, 8800C, PM8000, PM870, CM3350, CM4000 DDD Support: ION7550 V350 and newer, ION7650 V350 and newer, ION8650A/B V4.20 and newer, PM8000, CM4000	All default meter template
Voltage Sag	Same as Interruptions	Same as Interruptions	All default meter template
Voltage Swell	Same as Interruptions	Same as Interruptions	All default meter template
Transient Voltage	Same as Interruptions	ION 7650, 8600A, 8650A, 8650B, 8800A, CM4000T DDD Support: ION7650 V350 and newer, ION8650A/B V4.20 and newer, CM4000T	All default meter template

PQ Events and Disturbances	Used by	Supported Meters	Supported Meter Template
Over Voltage	Same as Interruptions	ION 7350, 7400, 7550, 7650, 8600A, 8600B, 8650A, 8650B, 8650C, 8800A, 8800B, 8800C, PM8000	All default meter template
Under Voltage	Same as Interruptions	ION 7350, 7400, 7550, 7650, 8600A, 8600B, 8650A, 8650B, 8650C, 8800A, 8800B, 8800C, PM8000	All default meter template
Voltage Unbalance	PQ Advisor Diagrams PQ Rating Gadget PQ Rating Trend Gadget PQ Analysis Report	Logged By Default: ION 7330, 7400, 7350, 7550, 7650, 8600A, 8600B, 8650A, 8650B, 8800A, 8800B, PM8000, CM3000, CM4000, TesysT, Micrologic 5.0/6.0/7.0 E/P/H (including IFE/IFM) Not Logged By Default: PM800 ¹ , PM3250, PM3255, PM5100, PM5300, PM5350, PM5500, EM6400, EM7000, Micrologic 5.2/6.2/5.3/6.3 E	All default meter template
Current Unbalance	PQ Advisor Diagrams PQ Rating Gadget PQ Rating Trend Gadget PQ Analysis Report	Logged By Default: TesysT, Micrologic 5.0/6.0/7.0 E/P/H (including IFE/IFM) Not Logged By Default: PM800 ¹ , CM3000, CM4000, PM3250, PM3255, PM5100, PM5300, PM5350, PM5500, EM6400, EM7000, Micrologic 5.2/6.2/5.3/6.3 A/E	n/a
Voltage Harmonics	PQ Advisor Diagrams PQ Rating Gadget PQ Rating Trend Gadget PQ Analysis Report	Logged By Default: ION 7330, 7350, 7400, 7550, 7650, 8600A, 8600B, 8650A, 8650B, 8800A, 8800B, PM8000, CM3000, CM4000 Not Logged By Default: ION 6200, 7300, 8600C, 8650C, 8800C, PM200, PM700, PM800 ¹ , PM1200, PM3250, PM3255, PM5100, PM5300, PM5350, PM5500, EM3460, EM6400, EM7000, Micrologic 5.2/6.2/5.3/6.3 E, Micrologic 5.0/6.0/7.0 H (including IFE/IFM)	All default meter template except PM8000 with IEEE 519 template
Current Harmonics	PQ Advisor Diagrams PQ Analysis Report	Logged By Default: ION 7330, 7350, 7400, 7550, 7650, 8600A, 8600B, 8650A, 8650B, 8800A, 8800B, PM8000, CM3000, CM4000 Not Logged By Default: ION 6200, 7300, 8600C, 8650C, 8800C, PM200, PM700, PM800 ¹ , PM1200, PM3250, PM3255, PM5100, PM5300, PM5350, PM5500, EM3460, EM6400, EM7000, Micrologic 5.2/6.2/5.3/6.3 E, Micrologic 5.0/6.0/7.0 H (including IFE/IFM)	All default meter template except PM8000 with IEEE 519 template
Frequency Variation	PQ Advisor Diagrams PQ Rating Gadget PQ Rating Trend Gadget PQ Analysis Report	Logged By Default: ION 7330, 7350, 7400, 7550, 7650, 8600A, 8600B, 8650A, 8650B, 8800A, 8800B, PM8000	All default meter template
Flicker	PQ Advisor Diagrams PQ Rating Gadget PQ Rating Trend Gadget PQ Analysis Report	Logged By Default: ION 7400, 7650, 8600A, 8650A, 8800A, 8800B	PQ Framework and EN50160 evaluation enabled

NOTE: ¹ PM800 series is supported except PM810 without PM810LOG.

Detailed information specifically for Power Factor:

Power Factor	Used by	Supported Meters
	Power Factor Impact Gadget Power Factor Impact Trend Gadget	All meters that have measurements required by the calculation of the defined rate structure. For example: • Active energy • Reactive energy • Active power • Reactive power
	PQ Analysis Report	All meters that measures active energy, reactive energy, and power factor

PQ Advisor - Supported measurements

The measurement support list provides detailed information about the supported measurements that are compatible with the Power Quality Advisor module.

NOTE: For each disturbance category, choose only the appropriate/necessary measurements from the supported list to log. Do NOT Log all of them. Logging all measurements can cause unwanted database growth, and performance issues.

PQ Disturbances	Used by	Supported Measurements	Label Name
Voltage Unbalance	PQ Advisor Diagrams PQ Rating Gadget PQ Rating Trend Gadget PQ Analysis Report	ION Devices Voltage Unbalance Mean	V unbal mean
		Non-ION Devices Voltage Unbalance L-L Worst Voltage Unbalance L-N Worst	Voltage Unbalance L-L Worst Voltage Unbalance L-N Worst
Current Unbalance	PQ Advisor Diagrams PQ Rating Gadget PQ Rating Trend Gadget PQ Analysis Report	Non-ION Devices Current Unbalance Worst	Current Unbalance Worst

PQ Disturbances	Used by	Supported Measurements	Label Name
Voltage Harmonics	PQ Advisor Diagrams PQ Rating Gadget PQ Rating Trend Gadget PQ Analysis Report	ION Devices Voltage Total Harmonic Distortion on Input V1 ¹ Voltage Total Harmonic Distortion on Input V2 ¹ Voltage Total Harmonic Distortion on Input V3 ¹ Voltage Total Harmonic Distortion Mean on Input V1 Voltage Total Harmonic Distortion Mean on Input V1 Voltage Total Harmonic Distortion Mean on Input V1	V1 Total HD ¹ V2 Total HD ¹ V3 Total HD ¹ V1 THD mean V2 THD mean V3 THD mean
		Non-ION Devices THD Voltage A-B THD Voltage A-N THD Voltage B-C THD Voltage B-N THD Voltage C-A THD Voltage C-N THD Voltage L-L THD Voltage L-N	THD Voltage A-B THD Voltage A-N THD Voltage B-C THD Voltage B-N THD Voltage C-A THD Voltage C-N THD Voltage L-L THD Voltage L-N
Current Harmonics	PQ Advisor Diagrams PQ Analysis Report	ION Devices Current Total Harmonic Distortion Phase A ¹ Current Total Harmonic Distortion Phase B ¹ Current Total Harmonic Distortion Phase C ¹ Current Total Harmonic Distortion Phase A Mean Current Total Harmonic Distortion Phase B Mean Current Total Harmonic Distortion Phase C Mean	I1 Total HD ¹ I2 Total HD ¹ I3 Total HD ¹ I1 THD mean I2 THD mean I3 THD mean
		Non-ION Devices Current Total Harmonic Distortion Phase A Current Total Harmonic Distortion Phase B Current Total Harmonic Distortion Phase C	THD Current A THD Current B THD Current C
Frequency Variation	PQ Advisor Diagrams PQ Rating Gadget PQ Rating Trend Gadget PQ Analysis Report	ION Devices Frequency Mean	Freq mean

PQ Disturbances	Used by	Supported Measurements	Label Name
Flicker	PQ Advisor Diagrams PQ Rating Gadget PQ Rating Trend Gadget PQ Analysis Report	ION Devices Voltage Flicker Plt on Input V1 Voltage Flicker Plt on Input V2 Voltage Flicker Plt on Input V3 Voltage Flicker Pst on Input V1 Voltage Flicker Pst on Input V2 Voltage Flicker Pst on Input V3	V1-Flick Plt V2-Flick Plt V3-Flick Plt V1-Flick Pst V2-Flick Pst V3-Flick Pst

NOTE: ¹ Use only for ION 6200, 7300, 8600C, 8650C and 8800C. These measurements are NOT logged by default.

NOTE:

- PM8000 is categorized as an ION device.
- ION6200 is categorized as a non-ION device.

Schneider Electric

35 rue Joseph Monier
92500 Rueil Malmaison – France
www.schneider-electric.com

As standards, specifications, and designs change from time to time, please ask for confirmation of the information given in this publication.

© 2017 Schneider Electric. All Rights Reserved.

7EN42-0148-00 03/2017
Replaces Document 7EN42-0126-00 04/2016