

[1.1 SIMPLY START] (5 / 17-)

Parâmetros das macroconfigurações

Atribuição das entradas / saídas

Entrada/saída	[Start/stop]	[M. handling]	[Gen. Use]	[Hoisting]	[PID regul.]	[Network C.]	[Mast./slave]
AI1	[Ref.1 channel]	[Ref.1 channel]	[Ref.1 channel]	[Ref.1 channel]	[Ref.1 channel] (Referência PID)	[Ref.2 channel] ([Ref.1 channel] = Modbus integrada) (1)	[Ref.1 channel]
AI2	[No]	[Summing ref. 2]	[Summing ref. 2]	[No]	[PID feedback]	[No]	[Torque ref.]
AO1	[Motor freq.]	[Motor freq.]	[Motor freq.]	[Motor freq.]	[Motor freq.]	[Motor freq.]	[Sign torque]
R1	[No drive flt]	[No drive flt]	[No drive flt]	[No drive flt]	[No drive flt]	[No drive flt]	[No drive flt]
R2	[No]	[No]	[No]	[Brk control]	[No]	[No]	[No]
LI1 (2 fios)	[Forward]	[Forward]	[Forward]	[Forward]	[Forward]	[Forward]	[Forward]
LI2 (2 fios)	[Reverse]	[Reverse]	[Reverse]	[Reverse]	[Reverse]	[Reverse]	[Reverse]
LI3 (2 fios)	[No]	[2 preset speeds]	[Jog]	[Fault reset]	[PID integral reset]	[Ref. 2 switching]	[Trq/spd switching]
LI4 (2 fios)	[No]	[4 preset speeds]	[Fault reset]	[External fault]	[2 preset PID ref.]	[Fault reset]	[Fault reset]
LI5 (2 fios)	[No]	[8 preset speeds]	[Torque limitation]	[No]	[4 preset PID ref.]	[No]	[No]
LI6 (2 fios)	[No]	[Fault reset]	[No]	[No]	[No]	[No]	[No]
LI1 (3 fios)	Stop	Stop	Stop	Stop	Stop	Stop	Stop
LI2 (3 fios)	[Forward]	[Forward]	[Forward]	[Forward]	[Forward]	[Forward]	[Forward]
LI3 (3 fios)	[Reverse]	[Reverse]	[Reverse]	[Reverse]	[Reverse]	[Reverse]	[Reverse]
LI4 (3 fios)	[No]	[2 preset speeds]	[Jog]	[Fault reset]	[PID integral reset]	[Ref. 2 switching]	[Trq/spd switching]
LI5 (3 fios)	[No]	[4 preset speeds]	[Fault reset]	[Fault reset]	[2 preset PID ref.]	[Fault reset]	[Fault reset]
LI6 (3 fios)	[No]	[8 preset speeds]	[Torque limitation]	[No]	[4 preset PID ref.]	[No]	[No]
Placas opcionais							
LI7 a LI14	[No]	[No]	[No]	[No]	[No]	[No]	[No]
LO1 a LO4	[No]	[No]	[No]	[No]	[No]	[No]	[No]
R3 / R4	[No]	[No]	[No]	[No]	[No]	[No]	[No]
AI3, AI4	[No]	[No]	[No]	[No]	[No]	[No]	[No]
RP	[No]	[No]	[No]	[No]	[No]	[No]	[No]
AO2	[I motor]	[I motor]	[I motor]	[I motor]	[I motor]	[I motor]	[I motor]
AO3	[No]	[Sign. torque]	[No]	[Sign. torque]	[PID output]	[No]	[Motor freq.]
Teclas do terminal gráfico							
Tecla F1	[No]	[No]	[No]	[No]	[No]	Comando p/ terminal gráfico	[No]
Teclas F2, F3, F4	[No]	[No]	[No]	[No]	[No]	[No]	[No]

Em comando a 3 fios a atribuição das entradas LI1 a LI6 é defasada.

(1) Para dar partida com Modbus integrado, é necessário configurar primeiramente [Modbus Address] (Add) página 277.

Nota: Estas atribuições são reinicializadas a cada mudança de macroconfiguração.