







Start→Schneider electric→SoMachine Software  
→V4.1→Tools→Exec Loader for M218

## First Step




## Step 2



After FW select, click “next step”

After click next step, new window will open.  
Ask you to power up M218.



## Step 3

FW in your PC →

FW in M218 →

After check the FW , please click next step

The screenshot shows the 'M218 固件更新工具 -- 文件和设备属性' window. It is at '第 3 步 (共 4 步): 比较文件和设备属性'. The window compares '文件属性' (File Attributes) and '设备属性' (Device Attributes). The file attributes are 0x101A0500 (Hardware ID) and 04.00.01.24 (Version). The device attributes are 0x101A0502 (Hardware ID), 04.00.01.24 (Version), and 已停止 (Stopped). The 'Next Step' button is highlighted with a red box.


| 文件属性:       | 设备属性:       |
|-------------|-------------|
| 0x101A0500  | 0x101A0502  |
| 04.00.01.24 | 04.00.01.24 |
|             | 已停止         |

文件: C:\Program Files (x86)\Schneider Electric\SoMachine\So...\M218v4.0.1.24.mfw


控制器描述: 紧凑型控制器 - 数字量输入输出, 2路高速计数器, (某些型号具有2路脉冲输出, 2路模拟量输出, 2路模拟量输入)。内嵌实时时钟。可拆卸端子。2个串行通信口, 可外接至7个扩展模块。

<上一步 下一步> 关闭

## Step 4



Update the FW



FW update complete