




Return to Factory Default Setting Function

The set values for all of the parameters can be returned to the factory default setting. This function is useful in various situations, such as when you want to redo the settings.

Setting the Return to Factory Default Setting Function

Follow the steps below to return all values to the factory default setting.

- 1 Display the password setup PAS Ch11 ("PAS Ch 11").
- 2 Display "PAS 1" and set FE01 ("FE01").
- 3 Display "PAS2" and set FE02 ("FE02").
- 4 Display "PAS3" and set FE03 ("FE03").
- 5 Press the  key to return to the PV display.
- 6 Press and hold the  key to display "F2 1".
- 7 Press the  key to display "PASS" and set FE00 ("FE00").
- 8 When the "PASS" setting returns to 0000 ("0000"), the values have finished returning to their factory default settings.