



How to uninstall SFT2841 completely

Applicable to Product Range (s) : SFT 2841 - SFT2848 (Sepam series 20; 40; 80 software)
Resolution Number: 192192

Revision: 1.0

Question

How to uninstall SFT2841 completely

Answer

- 1) Uninstall SFT in "Add or Remove Program" in Control Panel
- 2) Delete the remainders installed in the registry (Start > Run > type "REGEDIT" > delete the entries "sft2841" present in HKEY_LOCAL_MACHINE \ SOFTWARE \ Schneider Electric)

In selecting only that the values and data

- 3) remove the key to the GUID Installshield

HKEY_LOCAL_MACHINE \ SOFTWARE \ Microsoft \ Windows \ CurrentVersion \ Uninstall \
(CAF3552B-1D25-4CB9-9755-CAAF749B3C38)

Last Revised: June 2008

Applies To: SFT2841

Original Author: EC

Internal PMO/PMC

All content © 1992-2008 Schneider Electric
