

EcoStruxure Operator Terminal Expert



Which License for which Hardware (supported features) Supported Companion Offers

Hardware	Basic Operator Panel		Advanced Operator Panel		Harmony industrial PC and 3 rd party PC
	Basic Features	+ "Network"	GTU Premium Box	GTU Open Box	
	ST07••/ ST6/STM6/STM6BOX	ST0735 using Web Server API ST6/STM6/STM6BOX using Web Server API or/and OPC UA Server	G3U	G5U2*/G5U22 <i>*A SW patch is needed to use this HW. Please, contact the local Customer Care Center.</i>	
Build Time License required	Basic License	Professional License			
Runtime License required?	---NO---	---NO---	---NO---	---NO---	---YES---
Web Viewer License	<p>To visualize and operate the HMI screen remotely with mirroring function on standard browsers for PC, tablet or smartphone devices, a web viewer license needs to be purchased and activated in the hardware.</p> <p>Notes: 1.) Web Viewer is not supported in ST07•• 2.) For STM6BOX, Web Viewer license doesn't need to be purchased separately as the license is embedded and activated by default in this hardware 3.) For ST6/STM6/STM6BOX, the support is independent of the build time license being used: Basic or Professional</p>				
Supported companion offers	EcoStruxure Secure Connect Advisor is supported with EcoStruxure Operator Terminal Expert in ST6/STM6/STM6BOX and G3U (for ST6/STM6/STM6BOX, the support is independent of the build time license being used: Basic or Professional)				
	EcoStruxure Augmented Operator Advisor is supported with EcoStruxure Operator Terminal Expert in Harmony GTU Open Box, Harmony industrial PC and 3 rd party Windows PC				