

How we check EM6400 communication compatibility ??

Ans. In EM6400 series we have various items with varieties of inbuilt features and cost is also dependent based on upon these features.

To check communication compatibility we have two methods :-

1.

The **RS485** is **printed** between D1 & D0 for EM6400 model having communication compatibility.

In item code description RS is mentioned

2.

In item code description RS is mentioned with RS485 enabled model.

30001994 EM6436 1.0 (Without communication compatible)

30001999 EM6436 1.0 **RS (Communication compatible)**

Please see the back side images of 30001994 which not communication compatible. Please see the arrow mark where **RS485** is **printed** with communication enabled meter.



Hope it Clarify!!!

Thanks & Regards

Technical Support-Customer Care Excellence

Phone:+91172-3324626 ext. | Toll Free: 1800 103 0011/ 1800 425 4272 |

Email: customercare.in@schneider-electric.com | Site: www.schneider-electric.com | Address: Tower -A Bestech Business Tower, Sector 66, Mohali –160059, Punjab India

