


The M340 EGD Configuration Utility


Using the M340 EGD Configuration Utility

The M340 EGD configuration utility is used to:

- backup or restore your M340 EGD configuration
- create an M340 EGD configuration report

Perform the steps in the following table to run the M340 EGD utility:

Step	Action
1	The Unity Loader tool can be found on the M340 Modbus Plus Proxy Documentation and User Tools CD shipped with the M340 EGD.
2	Select the User Tools folder on the CD.
3	Select the M340 EGD Configuration Utility folder.
4	Select and open the M340 EGD configuration utility. 

Step	Action
5	Enter a valid IP address in the M340 EGD for M340 IP Address field. 
6	Select the action you require: ● Backup M340 EGD Configuration This action creates a copy of the configuration on your hard disk. ● Restore M340 EGD Configuration This action opens a configuration from your hard disk. ● M340 EGD Configuration Report This action converts data into a readable format that can be imported into a Microsoft Excel file.