

XIP Driver

Exemplo de configuração do XIP Driver para conexão via ethernet para o Modicon TSX Micro e Premium.

XIP Driver

- Configuração:

The main configuration window shows the following details:

- Profile:** XIP01
- Local host:** XWAY address: 6 . 23
- New remote host:**
 - Station: tsx_micro
 - XWAY address: 6 . 7
 - IP address: 10 . 161 . 47 . 45
 - Enable automatic detection: ☒
- Remote hosts configured:**

Station	XWAY address	IP address	Action
tsx_micro	006.007	010.161.047.045	*
tsx_premiu...	006.009	010.161.047.051	*
tsx_premiu...	006.005	010.161.047.044	*
TSX_PREMIU...	006.006	010.161.047.041	*

The 'XIP profil bind' dialog box shows:


- XIP:** XIP01
- TCP/IP - Network Adapter:** 10.161.47.4 (Broadcom NetXtreme 57xx Gigabit Controller)

Annotations:

- Endereço XWAY do PC: 6.23
- Endereço XWAY do CLP: 6.7
- Endereço IP do CLP: 10.161.47.45
- Lista de conexões para CLP configuradas.



XIP Driver

- Configuração:



XIP Driver

- PL7:



XIP Driver

- UnityPro:

