

Here’s what happens if the ESC key is depressed after an update

|                         |       |           |      |
|-------------------------|-------|-----------|------|
| FWUP                    | 0.0Hz | 0.00A     | Term |
| Firmware update diag    |       |           |      |
| Firmware Update Statu.. |       | Succeeded |      |
| Firmware Update Error   |       | No Error  |      |

The Update status should indicate Inactive

## Resolution

Select Menu 7.3

|                          |       |       |      |
|--------------------------|-------|-------|------|
| FWUP                     | 0.0Hz | 0.00A | Term |
| 7 File management        |       |       |      |
| 7.1 Transfer config file |       |       |      |
| 7.2 Factory settings     |       |       |      |
| 7.3 Firmware update      |       |       |      |

Select Firmware update

|                       |       |       |      |
|-----------------------|-------|-------|------|
| RDY                   | 0.0Hz | 0.00A | Term |
| 7.3 Firmware update   |       |       |      |
| Firmware update diag  |       |       |      |
| Identification        |       |       |      |
| Package version       |       |       |      |
| Abort Firmware Update |       | No    |      |

|                       |       |       |      |
|-----------------------|-------|-------|------|
| RDY                   | 0.0Hz | 0.00A | Term |
| Abort Firmware Update |       |       |      |
| No ✓                  |       |       |      |
| Yes                   |       |       |      |

select Abort Firmware Update

Select Yes

Then the drive will go to RDY state.